


TOSHIBA

SERVICE HANDBOOK
DIGITAL MULTI FUNCTION

e-STUDIO160/200/250




GENERAL PRECAUTIONS REGARDING THE INSTALLATION AND SERVICE FOR e-STUDIO160/200/250 SERIES

The installation and service should be done by a qualified service technician.

1. Transportation

- When transporting/installing the copier, employ two persons and be sure to use the positions as indicated below.

The copier is fairly heavy and weighs approximately 50 kg (110 lb), therefore pay full attention when handling it.



2. Installation

- Be sure to use a dedicated outlet with AC 115 or 120V/15A (220V, 230V, 240V/10A) or more for its power source.
- The copier must be grounded for safety.
Never ground it to a gas pipe or a water pipe.
- Select a suitable place for installation.
Avoid excessive heat, high humidity, dust, vibration and direct sunlight.
- Also provide proper ventilation as the copier emits a slight amount of ozone.
- To insure adequate working space for the copying operation, keep a minimum clearance of 80 cm (32") on the left, 80 cm (32") on the right and 10 cm (4") in the rear.
- After having installed the copier, be sure to push the carrying handles into the copier.

3. Service of Machines

- Basically, be sure to turn the main switch off and unplug the power cord during service.
- Be sure not to touch high-temperature sections such as the exposure lamp, the fuser unit, the damp heater and their periphery.
- Be sure not to touch high-voltage sections such as the chargers and the high-voltage transformer.
- Be sure not to touch rotating/operating sections such as gears, belts, pulleys, fans, etc.
- When servicing the machines with the main switch turned on, be sure not to touch live sections and rotating/operating sections. Avoid exposure to laser radiation.
- Use suitable measuring instruments and tools.

- Avoid exposure to laser radiation during servicing.
 - Avoid direct exposure to beam.
 - Do not insert tools, parts, etc. that are reflective into the path of the laser beam.
 - Remove all watches, rings, bracelets, etc. that are reflective.

4. Main Service Parts for Safety

- The breaker, door switch, fuse, thermostat, thermofuse, thermistor, etc. are particularly important for safety. Be sure to handle/install them properly.

5. Cautionary Labels

- During servicing, be sure to check the rating plate and the cautionary labels such as “Unplug the power cord during service”, “Hot area”, “Laser warning label” etc. to see if there is any dirt on their surface and whether they are properly stuck to the copier.

6. Disposition of Consumable Parts/Packing Materials

- Regarding the recovery and disposal of the copier, supplies, consumable parts and packing materials, it is recommended to follow the relevant local regulations or rules.

7. When parts are disassembled, reassembly is basically the reverse of disassembly unless otherwise noted in this manual or other related documents. Be careful not to reassemble small parts such as screws, washers, pins, E-rings, toothed washers in the wrong places.

8. Basically, the machine should not be operated with any parts removed or disassembled.

9. Precautions Against Static Electricity

- The PC board must be stored in an anti-electrostatic bag and handled carefully using a wristband, because the ICs on it may become damaged due to static electricity.

Caution: Before using the wrist band, pull out the power cord plug of the copier and make sure that there is no uninsulated charged objects in the vicinity.

Caution: Dispose of used batteries and RAM-ICs including lithium batteries according to the manufacturer's instructions.

Attention: Se débarrasser de batteries et RAM-ICs usés y compris les batteries en lithium selon les instructions du fabricant.

Vorsicht: Entsorgung des gebrauchten Batterien und RAM-ICs (inklusive der Lithium-Batterie) nach Angaben des Herstellers.

CONTENTS

1. ADJUSTMENT ITEMS	1-1
1.1 Error Code List	1-1
1.2 Self-Diagnosis Modes	1-6
1.2.1 Adjust mode (05)	1-8
1.2.2 System mode	1-13
1.2.3 User test mode	1-18
1.2.4 Function test	1-21
1.2.5 MAINTENANCE	1-38
1.2.6 SERVICE LIST	1-43
1.2.7 Country/Region code	1-49
1.2.8 Scanner parking mode	1-50
1.2.9 Speaker volume	1-51
1.2.10 Adjustment of document width sensor	1-52
1.3 Image Quality Control	1-53
1.4 Copy Image Dimension Adjustment	1-54
1.4.1 Adjustment of paper aligning value	1-55
1.4.2 Printer unit adjustment	1-56
1.4.3 Scanner unit adjustment	1-61
1.5 Sharpness (HPF) Adjustment	1-66
1.6 Gamma Slope Correction	1-67
1.7 High-Voltage Adjustment	1-68
1.7.1 Adjustment	1-68
1.7.2 Precautions	1-71
1.8 Adjusting the Scanner Section	1-74
1.8.1 Installing glass	1-74
1.8.2 Installing scanner motor	1-76
1.8.3 Adjusting the carriage 1	1-77
1.8.4 Installing carriage 2	1-79
1.8.5 CCD unit	1-82
1.9 Adjusting the main drive gear assembly	1-86
1.10 MAIN PWA replacement procedure	1-90
1.11 Measurement of Transfer Guide Bias	1-92
1.12 Adjustment of the doctor-sleeve gap	1-94

2. PREVENTIVE MAINTENANCE (PM)	2-1
2.1 Maintenance Performed Every 81,000 (e-STUDIO160/200 Series) and 99,000 Copies (e-STUDIO250 Series)	2-1
2.2 Preventive Maintenance Check List	2-1
2.3 PM Kit	2-14
2.4 List of Adjustment Tools	2-15
2.5 List of Grease	2-15
3. PRECAUTIONS FOR STORING & HANDLING SUPPLIES	3-1
3.1 Precautions for Storing TOSHIBA Supplies	3-1
3.2 Checking and Cleaning of the Pressure Roller	3-2
3.3 Checking and Cleaning of the Cleaning Roller	3-2
3.4 Checking and Cleaning of the Heat Roller	3-3
3.5 Checking and Replacing of the Transfer Guide Roller	3-3
3.6 Checking and Cleaning of Photoconductive Drum	3-4
3.7 Checking and Cleaning of Drum Cleaning Blade	3-5
4. TROUBLESHOOTING	4-1
4.1 Troubleshooting Based on Error Code	4-2
4.1.1 Transporting jam in the main body	4-2
4.1.2 Paper feeding jam	4-7
4.1.3 Transporting jam for the optional trays	4-13
4.1.4 Paper jam if some cover is opened	4-18
4.1.5 Paper transporting jam at the ADF	4-22
4.1.6 Paper transporting jam at the RADF	4-24
4.1.7 Paper jam in finisher	4-26
4.1.8 Drive system service call	4-30
4.1.9 Temporary paper supply mechanism service call	4-33
4.1.10 Optical system service call	4-39
4.1.11 Process system service call	4-41
4.1.12 Fuser system service call	4-41
4.1.13 Communications system service call	4-42
4.1.14 ADF or RADF system service call	4-44
4.1.15 Other abnormal service call	4-48
4.1.16 Laser optical system service call	4-49
4.1.17 Finisher related service call	4-50
4.1.18 Scanner related service call	4-55
4.1.19 Printer related service call	4-56
4.1.20 Fax related service call	4-56
4.1.21 OCT system service call	4-57
4.1.22 Other service call	4-57
4.2 Troubleshooting of Image	4-58

5. UPDATING THE FIRMWARE	5-1
5.1 Outline	5-1
5.2 Using the Recovery PWA	5-2
5.2.1 Using main recovery PWA	5-2
5.2.2 Using the scanner recovery PWA	5-5
5.3 Using the Batch File	5-8
5.3.1 Creating Download Disks	5-8
5.3.2 Downloading	5-13
5.4 Using the TOSHIBA Viewer	5-20
 6. WIRE HARNESS CONNECTION DIAGRAMS	 6-1
6.1 AC Wire Harness	6-1
 APPENDIX	 A-1
Appendix A. Specifications	A-1
Appendix B. Accessories	A-5
Appendix C. Options	A-6
Appendix D. Replacement Units/Supplies	A-6
Appendix E. System List	A-7
Appendix F. Power Supply Unit	A-8

1. ADJUSTMENT ITEMS

2. PREVENTIVE MAINTENANCE (PM)

3. PRECAUTIONS FOR STORING & HANDLING SUPPLIES

4. TROUBLESHOOTING

5. UPDATING THE FIRMWARE

6. WIRE HARNESS CONNECTION DIAGRAMS

1. ADJUSTMENT ITEMS

1.1 Error Code List

While the error message or “Call for service” symbol is flashing, pressing the [CLEAR/STOP] key and the [8] key on the digital keys at the same time shows one of the following error codes on the copy-quantity indicator as long as those keys are pressed.

Classification	Error code	Machine status
Transporting jam in the main body	E01	Paper jam inside the machine
	E02	Paper jam near the fuser unit
	E03	Paper remaining inside the machine at power on (Except for ADF/RADF)
	E04 to E07	Reserved
	E08	Transporting jam inside the ADU
	E09	Time out error that occurs at the paper feeding sensor
	E10	Reserved
Paper feeding jam	E11	Paper feeding jam at the ADU
	E12	Paper feeding jam at the SFB
	E13	Cassette 1 feeding jam
	E14	Cassette 2 feeding jam (PFU)
	E15	Cassette 3 feeding jam (PFP)
	E16	Cassette 4 (CM) feeding jam (e-STUDIO200/250 series)
	E17 to E18	Reserved
	E19	LCF feeding jam (e-STUDIO200/250 series)
	E20 to E30	Reserved
Transporting jam for the optional trays	E31	Paper not reach to feed sensor from cassette 2, so paper jam inside the main unit during cassette 2 feed
	E32	Paper not reach to feed sensor from cassette 3 or 4, so paper jam inside the main unit during the feed
	E33	Paper not reach to feed sensor from LCF cassette. (e-STUDIO200/250 series)
	E34	Paper not reach to 2nd cassette feed sensor from cassette 3 or 4. (Cassette 4 is e-STUDIO200/250 series)
	E35	Paper jam in cassette 4 transport path (e-STUDIO200/250 series)
	E36	Paper jam in LCF transport path (e-STUDIO200/250 series)
	E37 to E40	Reserved

Classification	Error code	Machine status
Paper jam if some cover is opened	E41	Copier front cover or side cover is opened during copying (Copier front cover, side cover, or transport cover of job separator/offset tray/bridge cover is opened during copying)
	E42	Side cover of cassette 2 or cassette 3 is opened during copying
	E43	ADU is opened during copying
	E44	Reserved
	E45	Side cover of LCF is opened during copying (e-STUDIO200/250 series)
	E46 to E70	Reserved
Paper transporting jam at the ADF or RADF	E71	Original feeding jam at the feeding area of the ADF or RADF
	E72	Original transporting jam at the transporting area of the ADF or RADF
	E73	Original exiting jam at the exiting area of the ADF or RADF
	E74	Original reversing jam at the reversing area of the RADF
	E75 to EA0	Reserved
Paper jam in the finisher (e-STUDIO200/250 series)	EA1	Paper transport delay jam
	EA2	Paper transport stop jam
	EA3	Paper remaining on the finisher transport path at power ON
	EA4	Finisher is opened during copying
	EA5	Finisher staple jam
	EA6	Finisher early arrival jam
	EA7	Set transport jam before stapling
	EA8 to EAE	Reserved
	EAF	Stapled set transport jam
	EB1 to EZ9	Reserved
Life end	-	Process unit life nearly end
	-	Toner is nearly empty
Other operator calls	-	No toner cartridge
	-	Toner empty
	-	No process unit
	-	Process unit life end
	-	Upper tray of the job separator is full
	-	Lower tray of the job separator is full
	-	Offset tray is full
	-	Finisher tray is full (e-STUDIO200/250 series)

Classification	Error code	Machine status
Other operator calls	-	Internal tray full (when finisher bridge installed) (e-STUDIO200/250 series)
	-	No paper in the cassette 1
	-	No paper in the cassette 2
	-	No paper in the cassette 3
	-	No paper in the cassette 4 (e-STUDIO200/250 series)
	-	No paper in the LCF (e-STUDIO200/250 series)
	-	Cassette 1 is not ready
	-	Cassette 2 is not ready
	-	Cassette 3 is not ready
	-	Cassette 4 is not ready (e-STUDIO200/250 series)
	-	LCF is not installed (e-STUDIO200/250 series)
		Front cover or side cover of the copier is open
		Cover of the job separator is open
		Cover of the off set catch tray is open
		Cover of the bridge cover is open (e-STUDIO200/250 series)
		Cover of the ADU is open
		Side cover of the cassette 2 is open
		Side cover of the cassette 3 is open
		Side cover of the LCF is open (e-STUDIO200/250 series)
		Finisher joint is open (e-STUDIO200/250 series)
CALL SERVICE from drive system		No staples (displayed only when stapling is designated) (e-STUDIO200/250 series)
	C01	Main motor drive error
	C02 to C03	Reserved
	C04	PFP main motor drive error
	C05	Reserved
Temporary paper supply mechanism error	C06	LCF feed motor error (e-STUDIO200/250 series)
	C07 to C10	Reserved
	C11 to C12	Reserved
	C13	Cassette 1 error
	C14	Cassette 2 error
	C15	Cassette 3 error
	C16	Cassette 4 error (e-STUDIO200/250 series)
	C17	Reserved
	C18	LCF tray error (e-STUDIO200/250 series)
	C19	LCF feed motor abnormal (e-STUDIO200/250 series)
	C20	Reserved

Classification	Error code	Machine status
CALL SERVICE from the optical system	C21	Carriage initialization error
	C22 to C24	Reserved
	C25	Scanner unit watch dog error
	C26	Exposure lamp disconnection or peak detection error
	C27 to C30	Reserved
CALL SERVICE from the process system	C31 to C37	Reserved
	C38	Replaced process unit error
	C39 to C40	Reserved
CALL SERVICE from fuser area	C41	Abnormal thermistor or heater disconnection at power ON
	C42	Reserved
	C43	Warming up mode after disconnection judgment, or abnormal thermistor after ready
	C44	Warming up mode after disconnection judgment, or heater abnormal after ready
	C45	Thermistor disconnection at the end part of heater
	C46 to C50	Reserved
CALL SERVICE from communication	C51 to C55	Reserved
	C56	Communication error between PFC and main unit
	C57	Communication error between main unit and IPC (e-STUDIO200/250 series)
	C58	Communication error between IPC and finisher (e-STUDIO200/250 series)
	C59 to C70	Reserved
CALL SERVICE from ADF or RADF	C71	Paper supply motor lock error
	C72	Reserved
	C73	EE-PROM initialization error
	C74	Defective adjustment by the exit/reversal sensor detected
	C75 to C80	Reserved
	C81	Fan motor lock error
	C82	Document aligning lower sensor (RADF)/Aligning sensor (ADF) adjustment error
	C83	Size length adjustment error
	C84 to C89	Reserved

Classification	Error code	Machine status
CALL SERVICE from others	C90	Reserved
	C91	SRAM abnormality (Lithium battery or SRAM chip are abnormal.)
	C92 to C94	Reserved
	C95	Power supply unit fan motor abnormality
	C96	Process unit fan motor abnormality
CALL SERVICE from laser optical system	C97	Vacuum fan motor abnormality
	C98	Clock IC abnormality
	C99	PFC microcomputer abnormal
CALL SERVICE from finisher (e-STUDIO200/250 series)	CA1	Polygon motor abnormal
	CA2	HSYNC abnormal
	CA3 to CB0	Reserved
	CB1	Reserved
	CB2	Exit motor abnormal
	CB3	Reserved
	CB4	Reserved
	CB5	Staple motor abnormal
	CB6 to CC2	Reserved
	CC3	Set processing motor abnormal
	CC4 to CC7	Reserved
	CC8	Front aligning motor abnormal
	CC9	Upper tray elevator motor abnormal
	CCA	Lower tray elevator motor abnormal
	CCB	Rear aligning motor abnormal
	CCC to CD0	Reserved
Reserved	F01 to F10	Reserved
Scanner I/F	F11	Scanner I/F error
	F12	Write error at downloading the scanner unit program
	F13	Download sector error of the scanner unit program
	F14	Scanner unit F-ROM error
	F15 to F20	Reserved
FAX unit	F31	Modem IC does not work normal
	F32 to F40	Reserved
Offset catch tray	F41	Initial detection error of the offset catch tray
Reserved	F42 to F99	Reserved

1.2 Self-Diagnosis Modes

The self-diagnosis functions are used to make the settings for the various PPC functions. This document describes the self-diagnosis functions.

For the FAX functions, refer to the SERVICE HANDBOOK (GD-1061).

For the method to enter each mode of the self-diagnosis functions, refer to the following chart.


Mode	How to enter	Definition	How to clear
Country/Region code	Turn the power on while pressing the 0 and 2 keys.	Selects the country/region code.	*1
Adjust mode	Turn the power on while pressing the 0 and 5 keys.	Finely adjusts copy image quality. Confirmation printing enabled by pressing the INTERRUPT key.	Turn the power off.
System mode	Turn the power on while pressing the 0 and 8 keys.	Performs setups for the system, maintenance, operations, printer, scanner, etc.	Turn the power off.
Scanner parking mode	Turn the power on while pressing the 0 and 9 keys.	Fixes the scanner carriage in place when transporting the copier.	Turn the power off.
RAM clear	Turn the power on while pressing the 1, 3, and * keys.	Clears values excluding the ones set in 08-446/447 and in the Adjust mode (05).	*2
Service mode *3	Press the PROGRAM key while REDAY is indicated, and then press the *, #, *, then * keys.	Performs setups for FUNCTION TEST and MAINTENANCE, and prints the Service List.	Press the PROGRAM key, and then press the *, #, *, then * keys. Or turn the power off. Or press the COPY key, or press the MAIN MENU key. *4
FUNCTION TEST	After entering the service mode, select it on the screen. This mode is selected by turning the power on while pressing the 1 and 3 keys.	Conducts OPE. PANEL TEST, PRINT TEST, MODEM TEST, etc.	
MAINTENANCE	After entering Service Mode, select it on the screen.	Performs setups for Memory Clear, facsimile function, etc.	
Service list	After entering Service Mode, select it on the screen.	Prints PROTOCOL TRACE, Total Error, FUNCTION LIST, etc.	

*1: After inputting the country/region code, the copier automatically enters the warm up mode.

*2: After the RAM clear, the machine automatically enters the warm up mode.

*3: In the SERVICE MODE, each function of the FUNCTION TEST, MAINTENANCE, or SERVICE LIST in each test item of the TEST MODE (displayed by pressing the PROGRAM key), are added. When the copier enters this mode, these functions are available.


*4 The copier enters into the service mode by pressing 1 and 3 keys while turning the power on. To exit from the service mode, turn the power off.



Note: Power ON Turn on the power switch.
 Power OFF Turn on the power switch.
 INT Press the INTERRUPT key.
 C/S Press the CLEAR/STOP key.


Menu map

The menu below can be selected by pressing the program key. (However, the menu in the broken-dotted box are displayed only when the copier enters the SERVICE MODE.)




1.2.1 Adjust mode (05)

<Key used in operation>



<Display messages>



ADJUST MODE (05) ITEMS

Process unit adjustment

Code	Factor	Adjustment item (05)	Mode	Default	Acceptable value	Refer to page
205	Development	Developer bias DC adjustment • Increment/decrement by U/D (Up/Down) key • Real-time high voltage output • Developer bias DC ON	ALL	156 (166)	0-255	1-70
210	Charging	Grid voltage initial value adjustment • Increment/decrement by U/D key • Real-time high voltage output (Charge ON)	ALL	104 (118) *1	0-255 Guaranteed value 0-223	1-70
220	Transfer	Transfer transformer DC output High adjustment • Increment/decrement by U/D key • Real-time high voltage output (Transfer High ON)	ALL	180	0-255	1-70
221	Transfer	Transfer transformer DC output Center adjustment • Increment/decrement by U/D key • Real-time high voltage output (Transfer Center ON)	ALL	142 (155) *1	0-255	1-70
233	Separation	Separation output High adjustment • Increment/decrement by U/D key • Real-time high voltage output (Separation-High ON)	ALL	67	0-255	1-70
234	Separation	Separation output Center adjustment • Increment/decrement by U/D key • Real-time high voltage output (Separation-Center ON)	ALL	49	0-255	1-70
235	Separation	Separation output Low adjustment • Increment/decrement by U/D key • Real-time high voltage output (Separation-Low ON)	ALL	35	0-255	1-70
261	Laser	Laser power 600 DPI Initial value adjustment • Increment/decrement by U/D key • No polygon rotation • Real-time laser output (Results of automatic laser adjustment) (Laser ON)	ALL	39 (53) *1	0-255	

*1 : The value in parentheses is for the model e-STUDIO200/250 series.

Scanning adjustment

Code	Factor	Adjustment item (05)	Mode	Default	Acceptable value	Refer to page
304	Scanner mechanism	Scanner feed magnification 0.1 %/step	ALL	128	0-255	1-62
305	Scanner mechanism	Scanner feed misalignment 0.126 mm/step (600 DPI)	ALL	128	85-171	1-63
306	Scanner mechanism	CCD scanning misalignment 0.04233 mm/step	ALL	128	5-251	1-61
354	R/ADF	R/ADF aligning amount (surface) 0.5 mm/step	ALL	10	0-20	
355	RADF	RADF aligning amount (back) 0.5 mm/step	ALL	10	0-20	
356	R/ADF	ADF position sensor adjustment or RADF sensor automatic adjustment	ALL	-	*1	
357	R/ADF	R/ADF transport speed fine adjustment 0.1 %/step	ALL	50	0-100	
358	R/ADF	R/ADF horizontal misalignment adjustment 0.04233 mm/step	ALL	128	0-255	
365	R/ADF	RADF top position adjustment (surface) 0.1 mm/step	ALL	50	0-100	
366	RADF	RADF top position adjustment (back) 0.1 mm/step	ALL	50	0-100	
380	ADF	ADF document width sensor adjustment, narrowest document guide width	ALL	-	*1	1-52
381	ADF	ADF document width sensor adjustment, widest document guide width	ALL	-	*1	1-52

*1 : The entry of code enables automatic adjustment.

Printer adjustment

Code	Factor	Adjustment item	Mode	Default	Acceptable Value	Refer to page
400	Printer system	Polygon motor speed fine adjustment 600 DPI 0.2%/step	PPC	128	108-148	1-56
410	Printer system	Laser start position 600 DPI Cassette 1	PPC	108	0-255	1-57
417	Printer system	Laser start position 600 DPI Cassette 2	PPC	106	0-255	1-57
418	Printer system	Laser start position 600 DPI Cassette 3/LCF	PPC	119	0-255	1-57
419	Printer system	Laser start position 600 DPI Cassette 4	PPC	128	0-255	1-57
421	Printer system	Main motor speed fine adjustment Approx. 0.1%/step	PPC	124 (130)	78-178	1-58
430	Printer system	Top margin 0.7 mm/step	PPC	0	0-30	1-64
431	Printer system	Left margin 0.1 mm/step	PPC	0	0-255	1-64
432	Printer system	Right margin 0.1 mm/step	PPC	0	0-255	1-65
433	Printer system	Bottom margin 0.1 mm/step	PPC	0	0-255	1-65
440	Printer system	Top position Cassette 1 0.4 mm/step	ALL	23	0-40	1-59
441	Printer system	Top position Cassette 2 0.4 mm/step	ALL	7	0-15	1-59
442	Printer system	Top position Bypass (SFB) 0.4 mm/step	ALL	8	0-15	1-59
443	Printer system	Top position LCF 0.4 mm/step	ALL	8	0-15	1-59
444	Printer system	Top position PFP 0.4 mm/step	ALL	7	0-15	1-59
445	Printer system	Top position ADU 0.4 mm/step	ALL	8	0-15	1-59
450	Printer system	Aligning amount Copier cassette (Cassette 1) Long size (0.52 mm/step) Paper length of min. 259 mm	ALL	14	0-31	1-55
451	Printer system	Aligning amount Copier cassette (Cassette 1) Short size (0.52 mm/step) Paper length of max. 258 mm	ALL	14	0-31	1-55
452	Printer system	Aligning amount Cassette 2 (PFU) Long size (0.52 mm/step) Paper length of min. 322 mm	ALL	22	0-31	1-55

*1 : The value in parentheses is for the model e-STUDIO200/250 series.

Printer adjustment

Code	Factor	Adjustment item	Mode	Default	Acceptable Value	Refer to page
453	Printer system	Aligning amount Cassette 2 (PFU) Short size (0.52 mm/step) Paper length of max. 321 mm	ALL	16	0-31	1-55
455	Printer system	Aligning amount ADU (e-STUDIO160: 0.7 mm/step, e-STUDIO200/250: 0.47 mm/step)	ALL	26 (23) *1	0-31	1-55
456	Printer system	Aligning amount PFP Short size (0.52 mm/step) Paper length of max. 321 mm	ALL	16	0-31	1-55
457	Printer system	Aligning amount LCF 0.52 mm/step	ALL	16	0-31	1-55
458	Printer system	Aligning amount Bypass (SFB) Short size (0.52 mm/step) Paper length of max. 258 mm	ALL	21	0-31	1-55
463	Printer system	Aligning amount PFP Long size (0.52 mm/step) Paper length of min. 322 mm	ALL	18	0-31	1-55
465	Printer system	Aligning amount Bypass Long size (0.52 m/step) Paper length of min. 259 mm	ALL	28	0-31	1-55
497	Printer system	Laser start position 600 DPI Bypass	PPC	101	0-255	1-57

*1 : The value in parentheses is for the model e-STUDIO200/250 series.

Scan image processing parameter 600 DPI


Code	Factor	Adjustment item	Image mode	Image quality mode	Default	Acceptable value *1	Refer to page
501	Density	Manual density fine adjustment Center value	PPC	Photo	139	0-255 L ← V → D	1-53
503	Density	Ditto	PPC	Text/Photo	133	0-255 L ← V → D	1-53
504	Density	Ditto	PPC	Text	130	0-255 L ← V → D	1-53
505	Density	Manual density fine adjustment Light step value	PPC	Text/Photo	28	0-255 V → L	1-53
506	Density	Ditto	PPC	Photo	18	0-255 V → L	1-53
507	Density	Ditto	PPC	Text	20	0-255 V → L	1-53
508	Density	Manual density fine adjustment Dark step value	PPC	Text/Photo	13	0-255 V → D	1-53
509	Density	Ditto	PPC	Photo	20	0-255 V → D	1-53
510	Density	Ditto	PPC	Text	18	0-255 V → D	1-53
512	Density	Auto density fine adjustment	PPC	Photo	140	0-255 L ← V → D	1-53
514	Density	Ditto	PPC	Text/Photo	133	0-255 L ← V → D	1-53
515	Density	Ditto	PPC	Text	130	0-255 L ← V → D	1-53
593	Density	Y' data inclination correction	PPC	Text/Photo	0	0-9	1-67
594	Density	Y' data inclination correction	PPC	Photo	0	0-9	1-67
595	Density	Y' data inclination correction	PPC	Text	0	0-9	1-67

*1 L: Light, V: Value, D: Dark

Scan image processing parameter 600 DPI

Code	Factor	Adjustment item	Image mode	Image quality mode	Default	Acceptable value *1	Refer to page
620	Image quality	No. of units: HPF table number 0: Use of default value 1: Text/Photo mode 2: Photo mode 3: For Text mode 4 - 9: Unused No. of tens: Filter combination intensity 0: Use of default value 1 - 9: Filter combination intensity	PPC	Text/Photo	1	0-99 The larger the intensity coefficient the stronger the intensity.	1-66
621	Image quality	Ditto	PPC	Photo	2	0-99	1-66
622	Image quality	Ditto	PPC	Text	3	0-99	1-66
693	Density	Range correction on original set on the ADF or RADF. Set whether the value of the background peak and text peak are fixed or not. If they are fixed, the range correction is performed with standard values. The values of the background peak and text peak affect the reproduction of the background density and text density respectively. The number of units: Data while automatic density is selected. The number of tens: Data while manual density is selected. Background peak Text peak 1: fixed fixed 2: varied fixed 3: fixed varied 4: varied varied	PPC	Text/Photo	12	11-14 21-24 31-34 41-44	
694		Photo		12			
695		Text		44			

1.2.2 System mode



SYSTEM MODE (08) ITEMS

Code	Factor	Setting item	Mode	Image quality mode	Default	Acceptable value *1	Refer to page
202	SYS	Selection of external counter 0: No external counter 1: With coil controller 2: Non-standard: With copylizer/key card 3: With key counter	ALL		0	0-3	
204	SYS	Auto clear [sec] 0: Invalid 1: 15s 2: 30s 3: 45s 4: 60s 5: 75s 6: 90s 7: 105s 8: 120s 9: 135s 10: 150s 11: 180s 12: 210s 13: 240s 14: 270s 15: 300s	ALL		3	0-15	
205	SYS	Auto low power 0: Invalid 1: Valid (Time is set on panel.)	ALL		1	0-1	
206	SYS	Auto sleep 0: Invalid 1: Valid (Time is set on panel.)	ALL		1	0-1	
207	SYS	Display for key counter setting 0: Set key copy counter 1: ASK CASHIER TO SWITCH ON * Valid when 08-202 is set to 3 (With key counter).	ALL		0	0-1	

*1 : The entry of code enables automatic execution.

SYSTEM MODE (08) ITEMS

Code	Factor	Setting item	Mode	Image quality mode	Default	Acceptable value *1	Refer to page
224	SYS	SFB paper size 0: A3 (8K) 1: A4 (16K) 2: A4R (16KR) 3: A5R 4: B4 5: B5 6: B5R 7: LETTER 8: LETTER-R 9: LEDGER 10: LEGAL 11: STATEMENT-R 12: COMPUTER 13: FOLIO 14: Undefined 15-17: Reserved			14	0-14	
225	SYS	Copier cassette paper size 0: A3 (8K) 1: A4 (16K) 2: A4R (16KR) 3: A5R 4: B4 5: B5 6: B5R 7: LETTER 8: LETTER-R 9: LEDGER 10: LEGAL 11: STATEMENT-R 12: COMPUTER 13: FOLIO 14: Reserved 15: Reserved			NAD: 7 Other: 1	0-13	
226	SYS	Cassette 2 paper size (Same as 08-225)			NAD: 7 Other: 1	0-13	
227	SYS	Cassette 3 paper size (Same as 08-225) (e-STUDIO200/250 series)			NAD: 7 Other: 1	0-13	
228	SYS	Cassette 4 paper size (Same as 08-225) (e-STUDIO200/250 series)			NAD: 7 Other: 1	0-13	
246	SYS	Clearing copy jobs at auto clear 0: No clearing 1: Clearing	ALL		0	0-1	
250	MAINT	Service personnel telephone number	ALL			20 digits Own M/C registration area	
251	MAINT	PM counter setting value	ALL		NAD: e-STUDIO160/ 200: 81000 e-STUDIO250: 99000 Other: 0	0-999999	
252	MAINT	PM counter present value 08-251: Operates when other than 0 Object of 08-352	ALL		0	0-999999	
255	MAINT	PFP installation status 0: Auto (Automatically changed to 1 or 2 by observing the PFC cassette installation status.) 1: PFP (Cassette 3) 2: PFP (Cassette 3,4) (e-STUDIO200/250 series) 3: Reserved 4: None	ALL		0	0-4	
256	MAINT	LCF paper size 0: A4 1: LT 2: Reserved	ALL		NAD: 1 Other: 0	0-2	
300	OPE.	MAX . 9 0: 999 1: 99 2: 9	ALL		0	0-2	
340	MAINT	Drum end counter setting value.	ALL		e-STUDIO160/ 200: 27000 e-STUDIO250: 33000	0-99999 (0: Not displayed)	
351	COUNT	Display of total counter data (Confirmed by listing and changed by memory writing)	ALL			Display only	
352	COUNT	A3/LD double count 0: Single count 1: Double count	ALL		1	0-1	
355	COUNT	Display of drum life counter	ALL		0	Display only	
374	COUNT	ADF/RADF scan counter	ALL			0-999999	

*1 : The entry of code enables automatic execution.

Code	Factor	Setting item	Mode	Image quality mode	Default	Acceptable value *1	Refer to page
375	COUNT	COPY job (print) counter	ALL			Double counted if printing A3 or LD size paper	
376	COUNT	PRINTER job (print) counter	ALL			Double counted if printing A3 or LD size paper	
377	COUNT	FAX job (print) counter	ALL			Double counted if printing A3 or LD size paper	
385	COUNT	Total counter in scanner unit (display)	ALL			0-999999	
386	COUNT	Platen scan count	ALL			0-999999	
388	COUNT	LOAD instruction for total counter when replacing the main PWA Scanner unit → Copier	ALL			*1	1-90
389	COUNT	SAVE instruction for total counter when replacing the scanner unit Copier → Scanner unit	ALL			*1	
400	Process	Thermistor heater status counter 0: No error occurrence 1: C41 1st thermistor or heater error when starting W-UP 2: C41 2nd thermistor or heater error when starting W-UP 3: Reserved 4: C43 Thermistor error during W-UP 5: C44 Heater error during W-UP 6: C43 Thermistor error after ready 7: C44 Heater error after ready 8: C45 Heater end thermistor error after ready (High temperature) 9: C44 High temperature heater error 10: C45 Heater end thermistor error after ready (Low temperature)	ALL		0	0-10	
401	Process	Drum life counter			0	0-999999	
402	Process	Power on hours counter (7-digit display: Hour 5-digit, minute 2-digit) Total power ON hours			0	0-9999959 Counter area added	
403	Process	Fuser counter Always double count for A3, B4, LD, LG, COM, A4R, LTR, and FOLIO			0	0-999999 Counter area added	
404	Process	Developer material counter. Always double count for A3, B4, LD, LG, COM, A4R, LTR, and FOLIO. Clear by installing a new PU.			0	0-999999 Counter area added	
406	Process	Pre-run start time 0: Invalid 1: 30 sec 2: 35 sec 3: 40 sec 4: 45 sec 5: 50 sec 6: 55 sec 7: 60 sec	ALL		0	0-7	
407	Process	Pre-run operation time 0: Invalid 1: 5 sec 2: 10 sec 3: 15 sec 4: 20 sec 5: 25 sec 6: 30 sec 7: 40 sec 8: 50 sec 9: 60 sec 10: 150 sec	ALL		0 (2) *1	0-10	
408	Process	Pre-run operation time for thick paper 0: Invalid 1: 1 sec 2: 2 sec 3: 3 sec 4: 4 sec 5: 5 sec 6: 6 sec 7: 7 sec 8: 8 sec 9: 9 sec 10: 10 sec 11: 12 sec 12: 14 sec 13: 16 sec 14: 18 sec 15: 20 sec	ALL		10	0-15	

*1 : The entry of code enables automatic execution.

Code	Factor	Setting item	Mode	Image quality mode	Default	Acceptable value *1	Refer to page
410	Process	Fixing temperature when printing 4: 170°C 5: 175°C 6: 180°C 7: 185°C 8: 190°C 9: 195°C 10: 200°C 11: 205°C 12: 210°C 13: 215°C	ALL		8 (10) *1	4-13	
411	Process	Fixing temperature when ready 0: 170°C 1: 175°C 2: 180°C 3: 185°C 4: 190°C 5: 195°C 6: 200°C 7: Drop control ON	ALL		7	0-7	
412	Process	Fixing temperature in low power state 0: OFF 1: 120°C 2: 130°C 3: 140°C 4: 150°C 5: 160°C	ALL		NAD: 5 Other: 4 (NAD: 3) (Other: 2) *1	0-5	
413	Process	Fixing temperature for thick paper 0: Invalid 1: 195°C 2: 200°C 3: 205°C 4: 210°C	ALL		0 (2) *1	0-4	
446 *2	Process	Correction for transfer output ON timing. (0: -110 ms -----18: +70 ms)	ALL		11	0-18 10 ms/step	1-91
447 *2	Process	Correction for transfer output OFF timing. (0: +110 ms -----18: -70 ms)	ALL		1 (11) *1	0-18 10 ms/step	1-91
462		Setting for switchback operation to copy mixed-size originals form RADF 0: Invalid 1: Valid			0	0-1	
480	PRINT	Cassette priority selection 0: A4/LT 1: LCF 2: Cassette 1 3: Cassette 2 4: Cassette 3 5: Cassette 4	ALL		0	0-5	
481	PRINT	Auto cassette change 0: None 1: Normal	ALL		1	0-1	
483	PRINT	Polygon motor preceding start-up setting 0: Valid (DF, platen) 1: Invalid 2: DF only	ALL		0	0-2	
486	PRINT	Time for suspension of the Polygonal motor pre-running (0: 15 sec, 1: 30 sec, 2: 45 sec)	ALL		0	0-2	
503	Image processing	Density default in image quality mode 0: AUTO 1: Light 3 2: Light 2 3: Light 1 4: Center 5: Dark 1 6: Dark 2 7: Dark 3 Also reflected on panel.	PPC	ALL	0	0-8	
504	F/W	Special paper selection 0: FOLIO/B size 1: 13" LEGAL (South America only) 2: K size (China only)	PPC		0	0-2	
550	Image processing	Image mode default 0: Standard 1: Photo 2: Text	PPC	ALL	0	0-2	
603	F/W	Auto duplex mode (when document is loaded into DF) 0: Invalid 1: Simplex/Duplex 2: Duplex/Duplex	PPC		0	0-2	
604	F/W	APS priority selection 0: APS 1: AMS 2: None (100%) 3: Reserved	PPC		0	0-3	
611	F/W	Book duplex document selection 0: Left-hand open 1: Right-hand open	PPC		0	0-1	
614	F/W	The function clear LED blinks. Blinks when the value is different from the present default value after copying (until auto clear or all clear.) 0: Invalid (Always off) 1: Valid	PPC		1	0-1	

*1 : The value in parentheses is for the model e-STUDIO200/250 series.

*2 : This value should be adjusted at the factory. Do not change the value in the field. When the main PWA is replaced, it should be entered again.

Code	Factor	Setting item	Mode	Image quality mode	Default	Acceptable value *1	Refer to page
618	F/W	Default setting for mixed size originals 0: OFF 1: ON * Setting 08-618 to 1 (ON) and 08-641 to 4 (alternate) simultaneously is not allowed.	PPC		0	0-1	
620	F/W	APS forced start (Exclude RADF) 0: Valid (One time pressing) 1: Reserved 2: Invalid	Memory PPC		0	0-2	
635		Process for last page (one-sided original) at duplex copying 0: One-side copy 1: Double-sided copy (blank paper is added to as the last even numbered page to output the copy in the same orientation with previous pages.)	PPC		0	0-1	
641	F/W	Auto sort mode (when document is loaded into DF) Also set on panel. 0: Invalid 1: Staple 2: Sort 3: Invalid 4: Vertical and horizon. alternate 5: Sort offset * Setting 08-641 to 4 (alternate) and 08-618 to 1 (ON) simultaneously is not allowed.	PPC		2	0-5	
642	F/W	Sorter mode priority selection (at all clear) Also set on panel. 0: NON SORT 1: STAPLE 2: SORT 3: Reserved 4: ALTERNATION 5: SORT OFFSET 6: NON SORT OFFSET	PPC		0	0-6	
648	F/W	Initialization of finisher bin at all clear 0: Valid 1: Invalid	ALL		0	0, 1	
649	F/W	Magazine sort setting 0: Left-hand open 1: Right-hand open	Expansion PPC		0	0-1	
650	F/W	2in1/4in1 setting 0: Horizontal write 1: Vertical write	Expansion PPC		0	0-1	
652	F/W	Cascade operation setting (e-STUDIO200/250 series) 0: No cascade 1: 1 → 2 (Endless stack included) 2. Reserved	Expansion PPC		1	0-2	
665	F/W	Set PPC area default. 05: Adjust area, γ adjust store area 08: Setting (PPC-FUNC) area (Except the counter values)	Self-check			*1	1-90
673		Resetting drum-related counters, 08-355, 08-401. (Valid when 08-689 is set to 1.)	Self-check				
685		Paper feeding by turns at duplex copying 0: Invalid 1: Valid	PPC		1	0-1	
688		UI shortcut key 0: Invalid 1: Valid (REDUCE/ENLARGE and ZOOM UP/DOWN only) 2: Valid (Cassette paper size setting only) 3: Valid (All, REDUCE/ENLARGE, ZOOM UP/DOWN, and cassette paper size setting)	PPC		1	0-4	


*1 : The entry of code enables automatic execution.

1.2.3 User test mode

When you press the PROGRAM key and enter the TEST mode from the menu, the items that can be tested by the user are displayed.

(1) AUTO TEST

This mode allows the user to independently diagnose the machine by automatically performing a series of tests.




Test Items

- | | |
|--------------------------------------|---|
| a) Flash ROM test | Calculates and compares the check sums of the firmware, function data and language information with the previously stored corresponding check sum values. |
| b) SRAM test | Same as Function Test. |
| c) DRAM test | Same as Function Test. |
| d) MODEM test | Same as Function Test. |
| e) SCANNER test | Same as Function Test. |
| f) CODEC test | Same as Function Test. |
| g) Printer test | Checks each part of the printer (fan, HVPS, polygon, heater, LSU) and prints one page of test pattern (not performed when there is no paper). |
| h) Phonebook data test | Calculates and compares the check sum of the phonebook with the previously stored check sum value. |
| i) Network board test (with GF-1110) | |

(2) INDIVIDUAL TEST

The user can perform a test in interactive mode and locate the faulty point from the test result. The test result is printed in the form of a report.




Test Items

- | | |
|-----------------|--|
| a) ADF test | Transports and ejects originals to check the transport system. Transports and ejects a certain number of originals and displays the number of the originals. The tester checks that this value matches the number of the originals. A transport speed can be selected with the resolution key. |
| b) Key test | Press all the keys on the operation panel to check if they are detected normally. The key test ends when the STOP key is pressed in the end. If there is any key which is not detected when pressed before the STOP key is pressed, it will be judged to be an error. |
| c) LED test | When the test is performed, all the LEDs will come on. If there is any LED which is not lit when visually checked, it will be judged to be an error. |
| d) LCD test | All the dots on the display go off (turn black). When the Start key is then pressed, all the dots light (turn white). If there is any dot which does not light or go off when visually checked, it will be judged to be an error. |
| e) Speaker test | Check that the volume level from the speaker changes. |
| f) Sensor test | Sensor test.
Open and close the covers by following the guidance appearing on the display. |
| g) Printer test | Checks the printer function by printing two test patterns. |

(3) TEST RESULT LIST

Prints the results of (1) AUTO TEST and (2) INDIVIDUAL TEST.




If there is any NG in the RESULT column, the corresponding test is problematic. An test with an asterisk (*) cannot be executed unless the corresponding option is installed.

SELF TEST REPORT		XXXXXXXXXX XXXXXXXXXXXX	
		XXXXXXXXXX XXXXX	
		PAGE	: 001
		TIME	: JAN-15-03 04:09PM
		TEL NUMBER	: 12345678901234567890
		E-MAIL	: ABCDEFGHIJKLMNOPQRSTUVWXYZ12345678901234
		NAME	: ABCDEFGHIJKLMNOPQRSTUVWXYZABCDEFGHIJKLMN
TEST CONTENTS	RESULT	NOTE	DATE
AUTO TEST			
FLASH ROM			
PROGRAM	OK		JAN-15-03 10:47AM
FUNCTION	OK		JAN-15-03 10:47AM
LANGUAGE	OK		JAN-15-03 10:48AM
SRAM			
ADDRESS BUS	OK		JAN-15-03 10:48AM
			JAN-15-03 10:48AM

1.2.4 Function test

The function test checks each function of the copier. To enter the function test mode, follow the procedure below, or enter the Service mode (*, #, *, *) and select the menu for the function test



The following tests can be conducted in the Function test mode.



01. OPE. PANEL TEST
02. PRINT TEST
03. MODEM TEST *1 (Factory test)
04. SENSOR TEST
05. SRAM TEST
06. DRAM TEST
07. CLOCK IC TEST
08. SCANNER TEST
09. CODEC TEST
10. OUTPUT TEST
11. PRINTER BOARD TEST *2

*1: When the FAX kit (GD-1061) is not installed, the test is not present.

*2: When the PCL kit (GA-1031) is not installed, the test is not present.


(1) 01. OPE PANEL TEST

This test checks the control panel display. When any key other than START and CLEAR/STOP is pressed during the display test, O and X are displayed alternately in the lower right of the display.



(2) 02. PRINT TEST

The test pattern is printed when a number is entered according to the displayed instructions



*1: Be sure to press this key after printing starts.
(If this key is not pressed, the copier keeps printing)

TEST PRINT (02) ITEMS

Code	Factor	Test pattern item		Item to be confirmed
109	Electrical	All-surface halftone (latter part)	Error diffusion	All completely black at T=0. All completely white at T=255.
110	Electrical	Halftone density 0 to 255 panel setting	Error diffusion	
110	Electrical	Scanning 256 levels (latter part)	Error diffusion	The density should change smoothly between black and white.
111	Image processing	Scanning 33 levels (latter part)	Error diffusion	There should be 33 levels in a transition between black and white.
112	Electrical	Scanning 17 levels (latter part)	Error diffusion	There should be 17 levels in a transition between black and white.
113	Image processing	Feed 33 levels (latter part)	Error diffusion	There should be 33 levels in a transition between black and white.
114	Electrical	Feed 17 levels (latter part)	Error diffusion	There should be 17 level in a transition between black and white.
115	Electrical	Scanning 1 dot line (latter part) 2-level Character density 0 to 255 panel setting Background density 0 to 255 panel setting		Black when both T and B are 0. White when both T and B are 255.
116	Electrical	Scanning 24 dot line (latter part) 2-level Character density 0 to 255 panel setting Background density 0 to 255 panel setting		Black when both T and B are 0. White when both T and B are 255.
121	Image processing	All-surface halftone (foregoing part)	Error diffusion	All completely gray.
122	Image processing	Scanning 256 levels (foregoing part)	Error diffusion	The density should change smoothly between black and white.
123	Image processing	Scanning 33 levels (foregoing part)	Error diffusion	There should be 33 levels in a transition between black and white.
124	Image processing	Scanning 16 levels (foregoing part)	Error diffusion	There should be 16 levels in a transition between black and white.
135	Image processing	All-surface horizontal 1 dot line, horizontal 1 dot space		
136	Image processing	All-surface vertical 1 dot line, vertical 1 dots pace		
137	Image processing	All-surface horizontal 2 dot line, horizontal 2 dot space		
138	Image processing	All-surface vertical 2 dot line, vertical 2 dot space		
141	Image processing	1 dot grid pattern (10 mm pitch)		Grid of 10 by 10 mm square. The line width increases as the code increases (141→142→145→146). Test 142 is used for 1.4 Adjustment.
142	Image processing	2 dot grid pattern (10 mm pitch)		
145	Image processing	Grid pattern of 4 sets of 1 dot line, horizontal 2 dots space (10 mm pitch)		
146	Image processing	Grid pattern of 4 sets of 2 dot line, horizontal 2 dots space (10 mm pitch)		
149	Image processing	A3 all completely black		All completely black
150	Image processing	A3 all white		All completely white
151	Image processing	Rightward rising slant line 1 dot (5 mm pitch)		The line interval in the main scanning direction should be 5 mm. The line should be straight.

(3) 03. MODEM TEST (Factory test)


Refer to the Service Handbook (GD-1061).

(4) 04. SENSOR TEST

When the machine enters the SENSOR TEST Mode, the status of each sensor is indicated on the display.

The status can be checked by selecting the corresponding bit.

(For items to be checked, refer to the Sensor Test Items table.)



- Explanation of status display

When the sensor test is carried out, the status of each sensor is indicated on the display with 0 or 1.

Each signal is divided into 8-bit blocks.

The character on the left edge of the display indicates as follows:

A: Signal input to ASIC

I: Signal input to the IO port

S: Signal from the scanner or R/ADF

P: Signal from the option connected to the PFC

The display is switched using the \triangle or ∇ key.

Status display example

A	A1	A2	A3	▲
I	IO1	IO2	IO3	
	IO4	IO5	IO6	
	IO7	IO8		▼

S	S1	S2		▲
	S3	S4		
P	P1	P2	P3	
	P4	P5		▼

Example 1:

Confirm whether the front cover is open or close.

The front cover is equipped with the 24-V ON/OFF switch (Interlock switch) and the front cover switch.

The status of both switches is 1 when the cover is open, and 0 when it is close.

When the status of the one is 0 and that of the other is 1 as shown in the example, there is something wrong with either of these switches.

A	01001010	00100010	00000001	▲
I	01001010	00100010	00000001	
	01001110	00100000	00000001	
	00001010	00100110		▼

IO3 Bit1

IO4 Bit2

	Front cover	
	Open	Close
IO3 bit 1 (Interlock switch)	1	0
IO4 bit 2 (Front cover switch)	1	0


Example 2:

Confirm whether or not the optional memory PWA is installed, with the status of bits 6 and 7 of IO1 on the display.

As shown in the table below, bits 6 and 7 detect the upper slot and lower slot, respectively.

The installation of the memory PWA can be confirmed with these bits.


Memory expansion slot on the back of the copier



PWA	Bit 7	Bit 6
Not inserted (upper and lower slots)	1	1
Inserted into the upper slot	1	0
Inserted into the lower slot	0	1
Inserted into both slots	0	0

(1: No PWA inserted / 0: PWA inserted)

The capacity of memory installed can be confirmed, with bits 4 and 5 of IO1.



SENSOR TEST (04) ITEMS

Data	Bit	Input info.	Function	Value
1 (A1) ASIC1 A/D CH0	7	A/D CH0 b7	Fusing thermistor A/D value	00H-FFH
	6	A/D CH0 b6	The value for temperature data is expressed with 8 bits.	
	5	A/D CH0 b5		
	4	A/D CH0 b4		
	3	A/D CH0 b3		
	2	A/D CH0 b2		
	1	A/D CH0 b1		
	0	A/D CH0 b0		
2 (A2) ASIC1 A/D CH2	7	A/D CH2 b7	Fusing side thermistor A/D value	00H-FFH
	6	A/D CH2 b6	The value for temperature data is expressed with 8 bits.	
	5	A/D CH2 b5		
	4	A/D CH2 b4		
	3	A/D CH2 b3		
	2	A/D CH2 b2		
	1	A/D CH2 b1		
	0	A/D CH2 b0		
3 (A3) ASIC1 A/D CH3	7	A/D CH3 b7	Drum thermistor A/D value	00H-FFH
	6	A/D CH3 b6	The value for temperature data is expressed with 8 bits.	
	5	A/D CH3 b5		
	4	A/D CH3 b4		
	3	A/D CH3 b3		
	2	A/D CH3 b2		
	1	A/D CH3 b1		
	0	A/D CH3 b0		
4 (IO1) I/O E0100C	7	MEM2DET	Option MEM2 connection signal (PWA-F-MEM Optional memory PWA)	0: Connected 1: Not connected
	6	MEM1DET	Option MEM1 connection signal (PWA-F-MEM Optional memory PWA)	0: Connected 1: Not connected
	5	SDRAM2ID	Detection signal for MEM PWA2 256 M bit SDRAM	0: 256 M bit 1: 64 M bit/128 M bit
	4	SDRAM1ID	Detection signal for MEM PWA1 256 M bit SDRAM	0: 256 M bit 1: 64 M bit/128 M bit
	3	PCLSET	PCL PWA connection detection signal	0: Connected 1: Not connected
	2	AU1SET	I-FAX PWA connection detection signal	0: Connected 1: Not connected
	1	DRUM	Presence or absence detection of process unit	0: Without 1: With
	0	FUSE	Detection of new or old process unit	0: Normal 1: New
5 (IO2) I/O E01006	7	-	-	-
	6	-	-	-
	5	-	-	-
	4	-	Reserved	-
	3	-	Reserved	-
	2	-	Reserved	-
	1	-	Reserved	-
	0	FAXDET	FAX PWA (GD-1061) connection signal	0: Connected 1: Not connected

Data	Bit	Input info.	Function	Value
6 (IO3) I/O E01008	7	-	Reserved	-
	6	-	Reserved	-
	5	-	Reserved	-
	4	BUCS	Battery abnormal condition detection signal	0: Normal 1: Battery abnormal condition
	3	FDS2ON	EXT-SEN (Exit sensor)	0: No paper 1: Paper detected
	2	FDS1ON	FED-SEN (Feed sensor)	0: Paper detected 1: No paper
	1	24VONOFF	Cover open (Interlock SW) detection	0: Closed 1: Open
	0	COS1ON	TC-SW (Toner cartridge switch) *1	0: With 1: Without
7 (IO4) I/O E0100A	7	IPCDDET	IPC PWA (Finisher) connection signal	0: Connected 1: Not connected
	6	PCDET	PC-I/F PWA connection signal	0: Connected 1: Not connected
	5	-	-	-
	4	5ROMSEL	RCVROM (MAIN recovery PWA) installation detection	0: RCVROM installed 1: Not installed
	3	PSS3	CST-SW (Paper cassette switch)	0: Closed 1: Open
	2	FCOSON	FRCOV-SW (Front cover switch) *1	0: Closed 1: Open
	1	PESON	PE-SEN (Paper empty sensor) Cassette 1	0: Paper loaded 1: Paper empty
	0	LPSON	T-UP-SEN (Tray-up sensor) Cassette 1	0: Not lifted up 1: Lifted up
8 (IO5) I/O E02006	7	-	-	-
	6	-	-	-
	5	-	-	-
	4	JCONNECT	Connection of any of JSP or OCT	0: Connected 1: Not connected
	3	-	Reserved	-
	2	FSELECT	Connection of BRIDGE COVER	0: BRIDGE COVER connected 1: JSP or OCT
	1	-	-	-
	0	-	Reserved	-
9 (IO6) I/O E02008	7	TESTMON	TNRE-SEN (Toner empty sensor)	0: Toner empty 1: Toner detected
	6	PMSTS	Polygon motor synchronizing signal	0: Synchronous 1: Asynchronous
	5	JPASSW	Connection of OCT	0: OCT connected 1: BRIDGE COVER or JSP
	4	JJAMSW	Jam detection/jam detection/middle jam detection *2	0: No paper 1: Paper present (JSP/OCT) 0: No paper 1: Paper present (BRIDGE COVER)
	3	JCOSON	JSP cover open/OCT cover open/BRIDGE COVER cover open *2	0: Cover closed 1: Cover open
	2	JPOSON	Paper in upper stacker/-/BRIDGE COVER exit jam detection *2	0: No paper 1: Paper detected (JSP/OCT) 0: Paper detected 1: No paper (BRIDGE COVER)
	1	JFLS2ON	Upper stacker paper full/offset initial position/- *2	0: Normal/non-initial 1: paper full/initial position
	0	JFLS1ON	Lower stacker/paper full/paper full *2	0: Normal 1: Paper full (JSP/OCT) 0: Paper full 1: Normal (BRIDGE COVER)

*1: The detection of the presence or absence of a toner cartridge is correctly displayed only when the front cover is open.

*2: One of the three options is indicated (only one of them can be connect).

Data	Bit	Input info.	Function	Value
10 (IO7) I/O E0200A	7	-	Reserved	-
	6	-	Reserved	-
	5	-	Reserved	-
	4	-	Reserved	-
	3	16MBDET	Pix SDRAM 16MB/32MB recognition signal	0: 32 MB 1: 16 MB
	2	-	Reserved	-
	1	MMSYNC	Main motor synchronization	0: Synchronous (constant speed) 1: Asynchronous
	0	G/PCHK	Distinction between GDI and PCL	0: PCL 1: GDI
11 (IO8) I/O E50000 Low order 8 bits	7	CTR-CNT	Counter connection signal	0: Connected 1: Not connected
	6	ENABLE	Enable signal	0: Copy limited 1: Enable
	5	MCONNECT	SFB unit connection signal	0: Connected 1: Not connected
	4	MPSS3ON	SFB paper size sensor 3 ON signal	0: ON 1: OFF
	3	MPSS2ON	SFB paper size sensor 2 ON signal	0: ON 1: OFF
	2	MPSS1ON	SFB paper size sensor 1 ON signal	0: ON 1: OFF
	1	MPSS0ON	SFB paper size sensor 0 ON signal	0: ON 1: OFF
	0	MPESON	SET-SEN (SFB feed sensor)	0: Paper present 1: Paper empty
12 (S1) Scanner sensor status 1 Upper 8 bits	7		HOME-SEN (Home position sensor)	0: Not HP 1: HP
	6		Reserved	
	5		Reserved	
	4		ADF: ADFCOV-SW (ADF top cover open switch) RADF: JAM-SW (Jam access cover switch)	0: Closed 1: Open
	3		SIZE-SEN (Document length sensor)	0: No paper 1: Paper detected
	2		ADF: ADFOPN-SEN (ADF open sensor) RADF: RADF-OPN-SNS (RADF open/close sensor)	0: Closed 1: Open
	1		ADF: EMPTY-SEN (Document empty sensor) RADF: EMP-SNS (Empty sensor)	0: Paper empty 1: Paper detected
	0		ORCOV-SEN (Original cover sensor)	0: Closed 1: Open
13 (S2) Scanner sensor status 1 Low order 8 bits	7		Reserved	
	6		LENG-SNS (Original length sensor)	0: No paper 1: Paper present
	5		TRY-SNS (Tray sensor)	0: No paper 1: Paper present
	4		READ-SNS (Read sensor)	0: No paper 1: Paper present
	3		RVR-SNS (Reverse sensor)	0: No paper 1: Paper present
	2		ADF: REGST-SEN (ADF registration sensor) RADF: REG-SNS (Registration sensor)	0: No paper 1: Paper present
	1		POS-SEN (ADF read sensor)	0: No paper 1: Paper present
	0		ADF: HAISI-SEN (ADF exit sensor) RADF: EXIT-SNS (Exit sensor)	0: No paper 1: Paper present
14 (S3) Scanner sensor status 2 Upper order 8 bits	7		Reserved	
	6		APS-6 (Automatic paper size detection sensor)	0: No paper 1: Paper present
	5		APS-5 (Automatic paper size detection sensor)	0: No paper 1: Paper present
	4		APS-4 (Automatic paper size detection sensor)	0: No paper 1: Paper present
	3		APS-3 (Automatic paper size detection sensor)	0: No paper 1: Paper present
	2		APS-2 (Automatic paper size detection sensor)	0: No paper 1: Paper present
	1		APS-1 (Automatic paper size detection sensor)	0: No paper 1: Paper present
	0		Reserved	



Data	Bit	Input info.	Function	Value
15 (S4) Scanner sensor status 2 Low order 8 bits	7		Reserved	
	6		SIZE-SNS 3 (Original width sensor 3)	0: No paper 1: Paper present
	5		SIZE-SNS 2 (Original width sensor 2)	0: No paper 1: Paper present
	4		SIZE-SNS 1 (Original width sensor 1)	0: No paper 1: Paper present
	3		Reserved	-
	2		Reserved	-
	1		Reserved	-
	0		Reserved	-
16 (P1) PFC Input check 1	7	SIZPFU	2CST-SW (PFU Cassette switch)	0: Installed 1: Not installed
	6	-	Reserved	-
	5	-	Reserved	-
	4	-	Reserved	-
	3	PFUFD-SW	OCF-SEN (2nd feed sensor)	0: No paper 1: Paper present
	2	PFUCOV	2COV-SW (PFU cover open switch)	0: Closed 1: Open
	1	PFUEMP	2PE-SEN (PFU paper empty sensor)	0: Paper loaded 1: Paper empty
	0	PFUUP	2T-UP-SEN (PFU tray-up sensor)	0: Not lifted up 1: Lifted up
17 (P2) PFC Input check 2 *1	7	SIZCU LCTRBTM	CST-U-SW (Upper cassette detection switch) TRY-BTH-SNR (Tray bottom sensor)	0: Installed 1: Not installed 0: Other 1: Lower limit
	6	- CFENCL0	Reserved PR-MST-SS (Standby side paper mis-staking sensor)	- 0: OFF 1: Closed
	5	- SIZLC	Reserved Cassette detection switch (LCF)	- 0: Installed 1: Not installed
	4	FEDU -	FED-U-SNR (Upper feed sensor) Reserved	0: No paper 1: Paper loaded -
	3	- -	Reserved Reserved	- -
	2	COV-SW -	SIDE-COV-SW (Side cover open/close switch) Reserved	0: Closed 1: Open -
	1	PEMPU -	EMP-U-SNR (Upper cassette paper empty sensor) Reserved	0: Paper loaded 1: No paper -
	0	TUPU -	TOP-U-SNR (Upper cassette tray-up sensor) PST-SNR-FS (Feeding side paper stock sensor)	0: Not lifted up 1: Lifted up -
	7	SIZCL LMTBCKF	LST-L-SW (Lower cassette detection switch) EMD-F-HP-SNR (End fence home position sensor)	0: Installed 1: Not installed 0: Other 1: Fence back limit
	6	- LMTFWDK	Reserved END-F-STP-SNR (End fence stop position sensor)	- 0: OFF 1: Fence forward limit
	5	- LCEMPFD	Reserved EMP-SNR-SS (Standby side empty sensor)	- 0: OFF 1: Open
	4	FEDL LCSIDCOV	FED-L-SNR (Lower feed sensor) Side cover open/close switch (LCF)	0: No paper 1: Paper loaded 0: Open 1: Closed
18 (P3) PFC Input check 3 *1	3	PLL-OK LCMOTLD	PLL lock signal LCF transport motor	0: Stable 1: Other 0: Operating 1: Motor stopped
	2	- LCTRTOP	Reserved TOP-SNR (Tray-up sensor)	- 0: Other 1: Upper limit
	1	PEMPL LCRLYSW	EMP-L-SNR (Lower cassette paper empty sensor) FED-SNR (Feed sensor)	0: Paper loaded 1: No paper 0: Paper detected 1: No paper
	0	TUPL LCEMP	TOP-L-SNR (Lower cassette tray-up sensor) EMP-SNR-FS (Feeding side empty sensor)	0: Not lifted up 1: Lifted up 0: No paper 1: Paper present

*1: The upper value for each bit indicates the function assumed when the PFP is installed, and the lower value the function assumed when the LCF is installed.

Data	Bit	Input info.	Function	Value
19 (P4)	7		PFU connection signal	0: Connected 1: Not connected
PFC Input check 4	6	-	Reserved	-
	5	-	Reserved	-
	4	-	Reserved	-
	3		ADUCOV-SW (ADU cover open switch)	0: Closed 1: Open
	2		FED2-SEN (ADU paper jam sensor (Upper))	0: No paper 1: Paper present
	1		FED1-SEN (ADU paper jam sensor (Lower))	0: No paper 1: Paper present
	0	-	Reserved	
20 (P5)	7	EXIT-SW	EXT-SEN (Exit sensor)	0: No paper 1: Paper present
PFC Input check 5	6	PSTP-1	FED-SEN (Feed sensor)	0: Paper present 1: No paper
	5	24VCHK	24V down signal	0: Down 1: Normal
	4	ADCNT	ADU connection signal	0: Connected 1: Not connected
	3	-	Reserved	-
	2	LCFCNT	LCF connection signal	0: Connected 1: Not connected
	1	-	Reserved	-
	0	PFP CNT	PFP connection signal	0: Connected 1: Not connected



(5) 05. SRAM TEST

The read/write test is performed throughout the image memory. The test checks the whole SRAM. When an error is found, the address of the erroneous portion is displayed and the test is stopped.




(6) 06. DRAM TEST

The read/write test is performed on the DRAM (including page memory and image memory). When an error is found, the address of the erroneous portion is displayed and the test is stopped.




(7) 07. CLOCK IC TEST

After programming the fixed data and time on the clock IC, the test reads the programmed data and time and checks whether or not they are correct




(8) 08. SCANNER TEST

The read/write test is performed on the RAM built in the image processing LSI.



(9) 09. CODEC TEST


The test encodes data of 10 lines using the MH coding, decodes it and compares it with the original data.



(10) 10. OUTPUT TEST

This test checks the operation of the motor, clutch and fan separately.

This test can check the operations of two or more parts at the same time. For example, the motor is tuned on while the clutch is on.




OUTPUT TEST (10) ITEMS

Code	Compo.	Operation	Note
101	Copier	Main motor ON (discharge also ON)/OFF	
102	Copier	Toner motor ON/OFF	
103	Copier	Polygon motor ON (600 DPI)/OFF	
105	Copier	Polygon motor ON (16*15.4)/OFF	
106	Copier	Polygon motor ON (15.4*16)/OFF	
108	Copier	Registration roller clutch ON/OFF	
109	PFC	PFP main motor ON/OFF	
201	Copier	Pickup clutch ON/OFF	
202	PFC	PFU pickup clutch ON/OFF	
203	PFC	2nd feed clutch ON/OFF	
204	Copier	Bypass feed clutch ON/OFF	
205	PFC	LCF feed clutch	
206	PFC	LCF transport clutch	
222	PFC	ADU motor (Lower) ON/OFF	
223	PFC	ADU motor (Upper) forward ON/OFF	
224	PFC	ADU motor (Upper) reverse ON/OFF	
225	PFC	PFP transfer clutch ON/OFF	
226	PFC	Cassette 3 feed clutch ON/OFF	
227	PFC	Cassette 4 feed clutch ON/OFF	
242	Copier	Cassette 1 tray-up motor ON	
243	PFC	Cassette 2 tary-up motor ON	
250	Copier	Developer bias transformer ON/OFF	
251	Copier	Charging ON/OFF	
255	Copier	Transfer guide bias ON/OFF (Do it after having done ON of the output of Code 250)	
256	Copier	Laser ON/OFF	
261	Scanner	Scanner carriage motor ON (automatic stop at limit)	
263	Scanner	Exposure lamp ON/OFF	
268	PFC	LCF end fence motor ON (right and left)	
269	PFC	LCF end fence solenoid ON/OFF	
270	PFC	LCF transport motor ON/OFF	
271	PFC	LCF tray-up motor up/down	
275	PFC	Cassette 3 tary-up motor ON	
276	PFC	Cassette 4 tary-up motor ON	
281	RADF	RADF pick-up roller rotation ON/OFF (F MOT)	
282	RADF	RADF registration roller rotation ON/OFF (F MOT)	
283	RADF	RADF read roller CW rotation ON/OFF (RDMOT)	
284	RADF	RADF read roller CCW rotation ON/OFF (RDMOT)	
285	RADF	RADF reverse roller CW rotation ON/OFF (RVMOT)	
286	RADF	RADF reverse roller CCW rotation ON/OFF (RVMOT)	
287	RADF	RADF document reverse solenoid ON/OFF	
288	RADF	RADF exit solenoid ON/OFF	
296	ADF	ADF transport motor forward ON/OFF	
297	ADF	ADF transport motor reverse ON/OFF	
298	RADF	RADF fan motor ON/OFF	

Code	Compo.	Operation	Note
302	Copier	Transfer DC-ON-HIGH (05-220 value used)	
303	Copier	Transfer DC-ON-CENTER (05-221 value used)	
304	Copier	Transfer DC-ON-LOW (05-222 value used)	
308	Copier	Separation-ON-HIGH (05-233 value used, developer bias also output)	
309	Copier	Separation-ON-CENTER (05-234 value used, developer bias also output)	
310	Copier	Separation-ON-LOW (05-235 value used, developer bias also output)	
330	Copier	Process unit fan motor : H (High speed rotation), and vacuum fan motor rotation	
331	Copier	Process unit fan motor : L (Low speed rotation), and vacuum fan motor rotation	
333	Copier	JOB separator/FIN pass solenoid ON/OFF	
334	Copier	Offset tray Stack front/rear (OCT motor ON/OFF)	

(11) PRINTER BOARD TEST

The test checks whether or not the printer board operates normally, by exchanging simple commands with the printer board.




1.2.5 MAINTENANCE

(1) MEMORY CLEAR

There are two ways to perform memory clear; the power on while pressing the specified keys, and partial memory clear by selecting items to be cleared from the menu.


Operation Procedure

a) Memory clear at the startup



*1 : Continue pushing the key until "Please wait" message is displayed.
Moreover, do not turn off the power supply.

b) Item selection from menu



RAM clear table

RAM data RAM clear mode	Country/ Region setting	Service parameter setting								
		FUNC/ SYSFUNC/ UAD etc.	Service adjustment data ([0][5]) area	Service setting data ([0][8]) area	Journal report data	Error data on FAX communi- cation	Protocol trace data	Counter data *a)	Drum related data *b)	
[1] [3] [*] and turn ON *2) *3)		Set default value		Set default value *e)	Clear	Clear	Clear			
[1] [3] [#] and turn ON *2)							Clear	Clear		
[*] [#] and turn ON *2)					Clear	Clear	Clear			
[START] [STOP] and turn ON *2)		Set default value		Set default value *e)			Clear			
[0] [8] and turn ON, then [6] [6] [5] *1)			Set default value	Set default value			Clear			
[0] [2] and turn ON	Changeable	Set default value		Set default value *e)	Clear	Clear	Clear			
1. PIX MEMORY										
2. EXCEPT USER MEMORY		Set default value			Clear	Clear				
3. ALL *3) (Same as "[1] [3] [*] and turn ON")		Set default value		Set default value *e)	Clear	Clear	Clear			
4. USER AREA *3)							Clear			

*1) In case of replacing the main board in the field, you can initialize the parameters related to copy function stored on the board using this function.

Therefore when this function is performed, it is necessary to readjust the following items.

- 1) Adjustment of paper aligning value
- 2) Printer unit adjustment
- 3) Scanner unit adjustment
- 4) ADF/RADF installation setting

*2) When RAM clear is performed, no message is indicated on the LCD.

Once RAM clear has been completed, "Please wait" appears on the LCD.

*3) RAM clear may take more than 10 seconds. Note that the error (Broken Registration) results if the power is turned off during RAM clear.

User parameter setting								
Dial data *c)	One touch data	Department code data	Secure receive data	Station name	ID number	Password *d)	Pending FAX job data	Stored JOB data
Clear	Clear	Clear	Clear	Clear	Clear	Clear	Clear	Clear
							Clear	
								Clear
Clear	Clear	Clear	Clear	Clear	Clear	Clear	Clear	Clear
							Clear	
							Clear	
Clear	Clear	Clear	Clear	Clear	Clear	Clear	Clear	Clear
Clear	Clear	Clear	Clear	Clear	Clear	Clear	Clear	

*a) Total Scan, Print jam, Job counter, Counter for each paper size

*b) Total Print, Drum counter, Toner counter, etc.

*c) One touch, Speed, Group etc.

*d) Polling Password, Remote Access Code

*e) 08-446, 08-447 not cleared


(2) SET FUNCTION

Refer to the Service Handbook (GD-1061).

(3) MEMORY WRITE

You can refer to and change the data stored at each address in the SRAM and DRAM.

ADDRESS and DATA input it with hex data.



(4) ERROR COUNTER SHIFT

Refer to the Service Handbook (GD-1061).

(5) PIX MEMORY TRANSFER


Refer to the Service Handbook (GD-1061).

1.2.6 SERVICE LIST

This function allows you to print lists. There are six kinds of lists that can be printed.

- PROTOCOL TRACE *1
- TOTAL ERRORS *1
- FUNCTION (FUNC 05, 08 List)
- DRUM HISTORY
- FUNCTION (Jam counter, ROM ver.)

*1: To be printed when the FAX Kit (GD-1061) is installed.



(4) DRUM HISTORY

This list is for checking the use status of the drum. It provides a list of information on the drum being used and the previous drum.

Print Items

- CURRENT COUNTER : Current information
- TOTAL PRINT : Current total print count
- DRUM COUNTER : Current drum counter value (= Print count x10)
- A4/LT or A3/LD : Current print count by paper size
- HISTORY : History of replacing the drum (counter clear)
- DATE : Date when the drum is replaced (counter clear)
- DRUM COUNTER : Counter value at the time when the drum is replaced
- A4/LT or A3/LD : Print count by paper size at the time when the drum is replaced

XXXXXXXXXX XXXXXXXXXXXX			
XXXXXXXXXX XXXXX			
DRUM UNIT LIST			
PAGE	: 001		
TIME	: JAN-20-03 04:09PM		
TEL NUMBER	: 12345678901234567890		
E-MAIL	: ABCDEFGHIJKLMNOPQRSTUVWXYZ12345678901234		
NAME	: ABCDEFGHIJKLMNOPQRSTUVWXYZABCDEFGHIJKLMN		
<u>CURRENT COUNTER</u>			
TOTAL PRINT	36		
DRUM COUNTER	360		
A4/LT	36		
A3/LD	0		
<u>HISTORY</u>			
DATE	DRUM COUNTER	A4/LT	A3/LD
JAN-16-03	10	1	0

(5) MEMORY DUMP LIST

A list of dumped RAM data is printed. Designate a start address (6-digit) and size (4-digit) and press SET for printing.

Print Data

ADDRESS Memory dump start address. The last digit is always "0." *1
HEX The data in memory is printed in hexadecimal. The last digit is always "0." *2
ASCII Data obtained by converting the data in memory into ASCII code.

Notes: *1: The last digit is discarded when other than "0."


*2: The last digit is rounded up when other than "0."

MEMORY DUMP LIST			XXXXXXXXXX	XXXXXXXXXX
			XXXXXXXXXX	XXXXX
			PAGE	: 001
			TIME	: JAN-15-03 04:09PM
			TEL NUMBER	: 12345678901234567890
			E-MAIL	: ABCDEFGHIJKLMNOPQRSTUVWXYZ12345678901234
			NAME	: ABCDEFGHIJKLMNOPQRSTUVWXYZABCDEFGHIJKLMN
ADDRESS	HEX DATA		ASCII	
000D00	319464BE75DB3FB3	2598EDDC2465B25D	1 u ? % \$e]	
000D10	A82AB741A19C80C7	BF8B254964494884	* A %ldIH	
000D20	65BF5591B3418ECD	9A0CBEF3B07CB8D8	e U A .	
000D30	00F4BD1D383B		[_z 1 . 8;	
			vI S% n; b	

(6) FUNCTION (Jam counter ROM ver.)

Press the PROGRAM key and enter the SERVICE mode. Then, select LISTS and print a function list so that the user set information will be printed on the first sheet, and the jam counter on the second sheet.

The same data as printed in (3) is printed on the third and fourth sheets.



Print Data

JAM COUNTER	Jam information
DOCUMENT	Jammed original count
PAPER JAM	Total count of TYPE1 to 7
TYPE1 JAM	Total count of E13
TYPE2 JAM	Total count of E01
TYPE3 JAM	Total count of E02
TYPE4 JAM	Total count of E11, E12, E14, E15, E16, E19
TYPE5 JAM	Total count of E08, E31 to E36
TYPE6 JAM	Total count of E03, E09, E41, E42, E43, E45
TYPE7 JAM	Total count of EA1 to EA7, EAF
* Exx: Refer to the 1.1 Error Code List	

FLASH ROM	Version information
PROGRAM	Program version and creation date
FUNCTION	Function version and creation date
LANGUAGE	Language version and creation date
SCANNER	Scanner version and creation date

XXXXXXXXXX XXXXXXXXXXXX
XXXXXXXXXXXX XXXXX

FUNCTION LIST

PAGE : 002
TIME : JAN-15-03 04:09PM

JAM COUNTER		
DOCUMENT	:	2
PAPER	:	1
TYPE1 JAM	:	0
TYPE2 JAM	:	0
TYPE3 JAM	:	0
TYPE4 JAM	:	1
TYPE5 JAM	:	0
TYPE6 JAM	:	0
TYPE7 JAM	:	0

FLASH ROM
PROGRAM XXXXXXXXXXXX


1.2.7 Country/Region code

Setting for country or region.

Input code according to a table.


Model	Code	Paper type
NAD	1	LT series
ASD/AUD/CND/SAD/MJD	44	A4 series

Important: When FAX kit (GD-1061) is not installed, do not input code except 1 or 44.



Note: When FAX kit (GD-1061) is installed, refer to a service handbook (GD-1061).



1.2.8 Scanner parking mode



(To enable packing screws to be refitted in the scanner unit.)

1.2.9 Speaker volume

Adjust the volume of the alarm and key touch tones.



1.2.10 Adjustment of document width sensor

Code 05-380, 381 adjustment procedure.

<Key used in operation>

0 5 Power ON

Adjust the document guide to the narrowest.

(Fig. 1-2-10-1)

3 8 0

Enter code

SET

CANCEL

Adjust the document guide to the widest.

(Fig. 1-2-10-2)

3 8 1

Enter code

SET

Power OFF




Fig. 1-2-10-1




Fig. 1-2-10-2


1.3 Image Quality Control

If the user wants to change the image density, adjust the image density in adjust mode "05."

	Original mode			Adjustment item		Remarks
	Photo/Text	Photo	Text			
Code	503	501	504	Standard PPC	Manual density center value	The larger the value, the darker the image
	505	506	507	Light side	Manual density	The larger the value, the lighter the light range
	508	509	510	Dark side	Manual density	The larger the value, the darker the dark range
	514	512	515	Standard PPC	Automatic density	The larger the value, the darker the image

Follow the procedure below to adjust the image density to suit the user's preferences while comparing the image obtained in the test copy and the currently entered allowable values.

<Keys used in operation>



- Notes:** 1. Adjustment value is able to be input within the range of 0 - 255.
2. Default values are as following.

Code	Default value
501	139
503	133
504	130
505	28
506	18
507	20
508	13
509	20
510	18
512	140
514	133
515	130

1.4 Copy Image Dimension Adjustment



As for the print image adjustment, the adjustment items are listed below.

The adjustment should be performed in the following order.

Adjustment item	Code
(1) Aligning value	(450) - (453) (455) - (458) (463) (465)
(2) Printer unit adjustment 1	
a) Primary scanning reproduction ratio Polygonal motor 600 dpi	(400)
b) Primary scanning position Laser starting position 600 dpi	(410) (417) (418) (419) (497)
c) Secondary scanning reproduction ratio Main motor speed fine adjustment	(421)
d) Secondary scanning position Registration	(440) (441) - (445)
(3) Scanner unit adjustment	
a) Primary scanning position CCD primary scanning deviation	(306)
b) Secondary scanning reproduction ratio Scanner secondary scanning reproduction ratio	(304)
c) Secondary scanning position Scanner secondary scanning deviation	(305)
d) Top margin	(430)
e) Left margin	(431)
f) Right margin	(432)
g) Bottom margin	(433)


1.4.1 Adjustment of paper aligning value

<Procedure> (Use code 450 - 453, 455, 456, 457, 458, 463, 465 in the "05" mode.)



- (2) Check the copy for image void and if there is any, reduce the new value to "31" → "30" → "29"... until no void occurs. Check for paper misfeeding.

When the aligning value is increased, noise caused by the paper scraping against the Mylar may possibly be increased.



01-04-02

- (3) For the LCF, ADU and bypass, the same procedure can be used.


- Notes:**
1. When frequent paper jams occur near the aligning roller caused by using special thin paper other than that specified, the aligning value can be changed (reduced) as a measure. However, when the aligning value is reduced excessively, this may possibly cause the registration to be shifted. Therefore, make sure that no registration shifting occurs while adjusting the value.
 2. Long size adjustment is used as the base when there are both long and short adjustments.
 3. Adjusts the code only for option attached.

* As a tentative countermeasure, the service life of the feed roller can be extended by increasing the aligning amount.


1.4.2 Printer unit adjustment

a) Polygonal motor 600 dpi (Primary scanning reproduction ratio of the printer unit)

- (1) Set 0 for codes 430 to 433 of the margin setup in 05: Adjustment mode.
- (2) Make a test print and adjustment as in the following procedure.



- (3) Measure the distance "A" which is the distance between the 5th line and 15th line from the left side of the test print paper against the direction of the paper movement.



01-04-03

- (4) In order to set the distance "A" to 100 mm.


Notes: 1. A decrease in the value lengthen the distance "A". (0.2 % step)

2. Adjustment value is effective within the range of 108 - 148.


The default adjustment value is 128.

b) Laser starting position 600 dpi/PPC

(1) Make a test print and adjustment as in the following procedure.



(2) Measure the distance "B" which is the distance from the left side of the test print paper to the 6th line.



01-04-04

(3) In order to set the distance "B" to 50 mm.

Notes: 1. An increase in the value makes the distance B longer.


2. The adjustment is made for each paper cassette. Paper cassette selection values (1) and corresponding codes (3) in paper cassette adjustment.

3. Adjustment value is able to be input within the range of 0 - 255.


Paper cassette	Cassette selection value	Code	Default	Step
Cassette 1	1	410	108	0.043 mm
Cassette 2	2	417	106	
Cassette 3/LCF	3	418	119	
Cassette 4	4	419	128	
Bypass	0	497	101	

c) Main motor speed fine adjustment (Secondary scanning reproduction ratio of the printer unit)

(1) Make a test print and adjustment as in the following procedure.



(2) Measure the distance "C" which is the distance between the 5th line and 15th line from the leading edge of the test print paper.




(3) In order to set the distance "C" to 100 mm.

Notes: 1. A decrease in the value lengthen the distance "C" (0.1 %/step).
 2. Adjustment value is able to be input within the range of 78 - 178.
 The default adjustment value is 124.


d) Registration

< Adjustment order >




< Adjustment procedure >

(1) Make a test print and adjustment as in the following procedure.



(2) Measure the distance "D" which is the distance to the 6th line from the leading edge of the test print paper.



(3) In order to set the distance "D" to 50 mm.

Notes: 1. An increase in the value increases the distance "D" (0.4 mm/step).

2. Adjustment value is able to be input within the range of 0 - 15. Default adjustment value is 8.

In case of the cassette 1 feeding (Code "440"), adjustment value is within the range of 0 - 40 (Default adjustment value is 23).

3. Since the cassette 1 adjustment value becomes a standard for all adjustments, this adjustment must always be performed in the order stated above.

4. The adjustment is made for each paper cassette. Paper cassette selection values (1) and corresponding codes (3) in paper cassette adjustment.


Paper cassette	Cassette selection value	Code
Cassette 1	1	440
Cassette 2	2	441
Cassette 3/4	3/4	444
Bypass	0	442
LCF	3	443

5. To confirm the adjustment of ADU (code 445), do not print a test print in the procedure in (1), but copy the TEST CHART.

1.4.3 Scanner unit adjustment


a) CCD primary scanning deviation

- (1) Place the scale (its end to the rear side original scale and its side to the left side original scale) on the original glass and make an A4/LT 100% copy.



01-04-08


- (2) In order to correct the distance "E", which should be 100 mm from the position copied to the bottom of the paper, adjust as follows.



- Notes:** 1. An increase in the value makes the image shift to the paper edge (0.04233 mm/step).
2. Adjustment value is able to be input within the range of 5 - 251.
The default adjustment value is 128.

b) Secondary scanning reproduction ratio


(1) Place the scale (horizontal to the copy movement direction) and make an A3/LD 100% copy.



01-04-09

(2) Compare the copy and the scale.

(3) In order to adjust the divisions of the scale, do as follows.




Notes: 1. An increase in the value corresponds to an increase in the division of scale (0.1 %/step).

2. Adjustment value is able to be input within the range of 0 - 255.


The default adjustment value is 128.

c) Scanner secondary scanning deviation

(1) Set 0 for the top margin adjustment value.




(2) Place the scale (its end to the left side original scale) on the original glass and make an A3/LD 200% copy.



01-04-10

(3) In order to correct the distance "F", which should be 20 ± 0.5 mm from the leading edge of the paper, adjust as follows.




Notes: 1. An increase in the value makes the image move to the trailing edge (0.126 mm/step).

2. Adjustment value is able to be input within the range of "120 - 136".

The default adjustment value is 128.


d) Top margin

(1) While the original cover remains open, make an A4/LT 100% copy.



01-04-11


(2) To establish a 3.0 ± 1.0 mm blank space on the leading edge of the copy, adjust using the following procedure.



Notes: 1. An increase in the value corresponds to an increase in the blank image (0.7 mm/step).
2. Adjustment value is able to be input within the range of 0 - 30.
The default adjustment value is 0.


e) Left margin

(1) While the original cover remains open, make an A4/LT 100% copy.



01-04-13


(2) To establish a 2.0 ± 0.5 mm blank space on the left side of the copy, adjust using the following procedure.



Notes: 1. An increase in the value corresponds to an increase in the blank image (0.1 mm/step).
2. Adjustment value is able to be input within the range of 0 - 255.
The default adjustment value is 0.


f) Right margin

(1) While the original cover remains open, make an A4/LT-100% copy.



01-04-12


(2) To establish a 2.0 ± 0.5 mm blank space on the right side of the copy, adjust using the following procedure.



Notes: 1. An increase in the value corresponds to an increase in the blank image (0.1 mm/step).
 2. Adjustment value is able to be input within the range of 0 - 255.
 The default adjustment value is 0.


g) Bottom margin

(1) While the original cover remains open, make an A4/LT-100% copy.



01-04-14

(2) To establish a 3.0 ± 1.0 mm blank space on the trailing edge of the copy, adjust using the following procedure.




Notes: 1. An increase in the value corresponds to an increase in the blank image (0.1 mm/step).
 2. Adjustment value is able to be input within the range of 0 - 255.
 The default adjustment value is 0.

1.5 Sharpness (HPF) Adjustment

If the user wants to change the image sharpness to softer or harder, adjust the HPF intensity in adjust mode "05".

	Image mode			Adjustment item	Remarks
	Photo/Text	Photo	Text		
Code	620	621	622	HPF intensity	No. of units: HPF table number 0: Use of default value 1: Text/Photo mode 2: Photo mode 3: Text mode 4-9: Unused No. of tens: Filter combination intensity 0: Use of default value 1-9: Filter combination intensity (The larger the intensity coefficient the stronger the intensity.)

<Keys used in operation>



- Notes:** 1. Adjustment value is able to be input within the range of 0-99.
 2. Default value.


Code	Default value
620	1
621	2
622	3

1.6 Gamma Slope Correction

If the user wants to change the gamma curve, adjust the gamma slope correction in adjust mode "05."

	Image mode			Adjustment item	Remarks
	Photo/Text	Photo	Text		
Code	593	594	595	Gamma slope correction	If the value is increased, the image is darkened. (Default value is 0)

<Keys used in operation>



Note: Adjustment value is able to be input within the range of 0 - 9.



1.7 High-Voltage Adjustment

The developer bias, main charger, transfer charger and separation charger outputs must be adjusted when the high-voltage power supply unit is replaced.


1.7.1 Adjustment

(1) Measurement

		Developer Bias	Main Charger	Transfer Charger (On the drum)	Separation Charger (On the drum)
Process Unit		Remove from the copier. (Not use)			
Measuring jig		Not use	Mount on the machine Note1: Connect the green cable of the measuring to ground on the copier.		
Digital Tester	(+) terminal	Connect to the bias measuring plate (B) of the machine.	Connect to the main charger cable.	Connect to the red cable of measuring jig.	
	(-) terminal	Connect to frame ground (A).	Connect to the white cable of measuring jig. (Frame grounding)		
	Function switch	DC			
Full scale		1,000 V		2V	
Remarks		Use a digital tester having an input resistance of 10MΩ or more.			
How to turn the power ON		Use the door switch jigs.			
		Developer Bias	Main Charger	Transfer Charger (On the drum)	Separation Charger (On the drum)




High-Voltage measurement jig




01-07-01

Door switch jigs



01-07-07



01-07-05

(2) Operation


Note

When adjusting the high-voltage output, a measuring jig is required. (except the developer bias measurement.)

Connect the digital testers as instructed in (1) and follow the procedure below to adjust the developer bias, main charger, transfer, separation output.

<Keys used in operation>

<Display messages>



1.7.2 Precautions

(1) Developer bias

Caution during Adjustment

If fogging appears over the entire surface even though the grid voltage are appropriate, adjust the developer bias on the control panel. The following defects may occur if the developer bias is lowered too much:

- Image contrast becomes low.
- Image is patchy or blurred.
- Developer carrier adheres to the photosensitive body, making it easier for scratches to occur or the surface of photosensitive body by the cleaner blade.

(2) Transfer

Items to Check before Adjustment

Pockmarks or defective transfer also occur in defects besides transfer output adjustment defects. If this happens, check the following items. If an error is not found after carrying out the following checks, adjust the output.

- Is the charger wire out of position or dirty? Are the transfer guide and roller deformed?
- Are the developer magnetic brushes contacting with the drum?
Is the process unit rotating during copying? Is the toner low?
- Is the copy paper bending as it is being fed in? Is the copy paper abnormally moist?
- Is the aligning roller rotating normally?
- Is the separation output deviating from the set value?
- Is the developer bias an appropriate value?
- Is the transfer/separation charger case earthed? Is the photosensitive drum (shaft) earthed? Is the transfer/separation transformer earthed?

Caution during Adjustment

① When pockmarks occur:


- If pockmarks are occurring in halftone areas, lower the transfer output value. However, note that if the transfer output value is lowered too far, the transfer performance also will be reduced.

② When defective transfer occurs:

Increase the transfer output value under the following conditions. However, note that if the transfer output value is raised too far, pockmarks will occur.

- If defective transfer occurs even though the charger wire is not dirty.
- If thick paper is frequently used.

The adjustment code varies according to where pockmarks occur. Select the required adjustment code while referring to the following diagram.



(3) Separation

Items to Check before Adjustment

Defective separation from the drum also occurs in other than separation output adjustment defects. If this happens, check the following items. If an error is not found after carrying out the following checks, adjust the output.

- Is the charger wire out of position or dirty?
- Are the developer magnetic brushes contacting with the drum?
Is the process unit rotating during copying? Is the toner low?
- Is the copy paper bending as it is being fed in? Is the copy paper abnormally moist?
- Is the alignment roller rotating normally?
- Is the main charger outputting?
- Is the transfer output deviating from the set value?
- Is the transfer/separation charger case earthed? Is the transfer/separation transformer earthed?

Caution during Adjustment


① When defective separation occurs:

Increase the separation output value under the following conditions. However, note that if the separation output value is raised too far, pockmarks will occur, and separation performance will be reduced. (Adjustment code = 233)

- If defective separation occurs even though the charger wire is not dirty.
- If thin paper is frequently used.

② When defective transfer occurs:

- Lower the separation output value when defective transfer occurs. However, note that if the separation output value is lowered too far, the separation performance also will be reduced. The adjustment code varies according to where the defective transfer occurs. Select the required adjustment code while referring to the following diagram.




1.8 Adjusting the Scanner Section

1.8.1 Installing glass

(a) Installing ADF glass

To install new ADF glass, wipe off the mounting surface and mount the glass by placing it at the position shown right.




043-3

Fig. 1-8-1

(b) Installing original glass


Original glass should be installed in the following manner:

1. Place the ADF glass by aligning with the positioning tab.
2. Hold original glass to the stopper and tighten 4 screws.
3. Hold original glass stay to original glass and tighten 2 screws.



043-4

Fig. 1-8-2



043-5

Fig. 1-8-3

(c) Image skewing adjustment

After installing scanner unit, hold the document to the ADF glass and make a copy. Check the image for tilt. If tilt has occurred, make adjustments in the following manner:

1. If an Original Cover (KA-1600PC), ADF (MR-2012), or the RADF (MR-3011) is attached to the copier, detach it.
2. If a STP (KK-1600) is attached to the copier, disconnect the power cable.
3. Detach the manual pocket.
4. Detach top cover.
(See Fig. 2-6-2 of the Service Manual)
5. Loosen 6 screws retaining original glass.
6. If the tilt is as shown below, loosen 6 screws retaining stopper, move (adjust) original glass stopper plate to the front side, and then secure it.





Fig. 1-8-5

7. If the tilt is as shown below, loosen 6 screws retaining stopper, move (adjust) original glass stopper plate to the rear side, and then secure it.





Fig. 1-8-6

1.8.2 Installing the scanner motor

When mounting the scanner motor, adjust the tension of timing belt 142 and timing belt 157 in the following manner.

Note: When mounting, do not mix up the screws.

1. Loosely tighten the scanner motor and scanner motor bracket assembly using 2 screws and mount timing belt 142. (There should be sufficient play to enable the scanner motor and scanner motor bracket assembly respectively to move right-to-left.)




Fig. 1-8-7

048-3

2. Mount the belt tension jig and spring jig (wire). Rotate the scanner motor pulley two to three turns to allow the timing belt and pulley to be securely meshing.

Secure the 2 screws loosely tightened in step 1.

3. Apply screw lock paint to the 2 screws secured.
4. Remove the belt tension jig and spring jig used in step 2




Fig. 1-8-8

048-4

5. Loosely tighten the scanner motor bracket assembly to the scanner motor assembly using 4 screws.

(There should be sufficient play to enable the scanner motor bracket assembly to move right-to-left.)

Mount timing belt 157.

6. Mount the spring jig (belt). Rotate scanner motor pulley two to three turns to allow the tooth sides of timing belt 157 and gear to be securely meshing.

Secure the 4 screws loosely tightened in step 5.

7. Apply screw lock paint to the 4 screws secured.
8. Remove the spring jig used in step 6.




Fig. 1-8-9

048-5




Fig. 1-8-10

048-6

048-2-1

1.8.3 Adjusting the carriage 1

(a) Installing carriage 1

When installing carriage 1, make adjustments in the following manner:

1. Pass the lamp cable over the roller of carriage 2 and place carriage 1 on scanner.
2. Reliably hold the carriage 2 holding part to the left side frame.




Fig. 1-8-11

3. Securely hold the carriage 1 holding part to the left side frame.
4. Tighten 2 screws to secure carriage 1 to wire.




Fig. 1-8-12

(b) Image distortion adjustment

After installing scanner assembly in the copier, make an copy (LD: NAD model, A3: MJD/CND/AUD/ASD/SAD models) and check it for skew. If skew occurs, make adjustments in the following manner:

1. If the skew is as shown below, with carriage 1 securely held to the left side frame, loosen the wire fixing screw on the front side, separate (adjust) the front side of carriage 1, and then secure it.




Fig. 1-8-13

2. If the skew is as shown below, with carriage 1 securely held to the left side frame, loosen the wire fixing screw on the rear side, separate (adjust) the rear side of carriage 1, and then secure it.




Fig. 1-8-14

1.8.4 Installing carriage 2

(a) Wire tension adjustment

1. Install wire on carriage 2 by winding up as shown below.




Fig. 1-8-15

2. Remove the clip jig mounted on scanner drive shaft.
3. Place the spring jig (wire) tension gauge on wire holder and scanner drive shaft and then screw it.




Fig. 1-8-16

4. Remove the spring jig (wire) gauge and loosen 2 screws retaining slide plate.




Fig. 1-8-17

5. To take up the winding slack of wire, move carriage 2 back and forth once (to the center of scanner) and securely hold the carriage to the left side frame.
6. Tighten 2 screws to secure slide plate.





Fig. 1-8-18

7. Apply the screw lock paint to all the screws secured.

(b) Installing the wire to the pulleys


Winding the wire on pulley.

1. Fit the $\phi 3.2$ spherical terminal at the center of the wire into the hole in the wire winding pulley. Wind up the wires on the front and rear sides, respectively, as shown below and secure the wire with the clip jig to prevent it from getting loose.




065-10

Fig. 1-8-19



065-01

Fig. 1-8-20






065-11

Fig. 1-8-21

Notes:

1. When winding the wire on the pulley, keep the following points in mind.
 - Do not wind the wire while twisting.
 - Tensely wind the wire so that it will be placed in contact with the pulley.
 - Wind the wire without leaving gaps.
 - Be careful not to allow the wound wire to be shifted or come loose.
2. When fitting wire holder jigs, take care so that the turns wound on the pulleys do not move or unwind.

**Fig. 1-8-22****<Relationship between wound turns and wire holder jigs>****Fig. 1-8-23**

1.8.5 CCD unit

(a) Replacing the CCD unit

- Since the lens unit was precisely adjusted at the factory, it must not be readjusted in the field or some of its components must not be replaced. If necessary, the lens unit should be replaced as a unit.
- When replacing the CCD unit, remove the following 3 screws only. Do not loosen or remove other screws.





Fig. 1-8-24


065-15-1

- Use sufficient care when handling the lens unit. Never hold the precision-adjusted area of the lens unit.



065-17-1

Fig. 1-8-25



065-18-1

(b) Installing CCD unit

When changing CCD unit, install the unit in the following manner:

1. With CCD unit temporarily mounted, set the jig.

Note: When setting the CCD jig, there must be no space between CCD unit and the special CCD jig.




Fig. 1-8-26

065-03-1

2. Adjust the position of CCD unit for the offset value (unit: mm) provided on CCD unit and then secure it with the screw.

Note: Move the unit to the right of the center when the offset value is plus, and to the left of the center when minus. (one division: 1 mm) and then secure CCD unit.

Ex. The figure below shows an example where the offset value is “+2.00.”




Fig. 1-8-27

065-04-1

3. After assembling the copier completely, make a copy of document and check the image.
4. If the copy image is enlarged or reduced, readjust.


(c) Adjusting the CCD unit

1. Remove original glass. (See Fig. 7-8-7 of the Service Manual)
2. Remove the blind plate. (See Fig. 7-8-16 and 7-8-17 of the Service Manual)
3. Place the CCD jig on CCD unit and loosen 3 screws.
4. Using the marks on the scanner base as a guide, adjust the CCD unit in either forward or backward direction.

The following table shows the error in the reproduction ratio between the copies and actual rulers compared to be measured, and the amount of adjustment of the CCD unit.

Reproduction-ratio error	Amount of adjustment	Reproduction-ratio error	Amount of adjustment
-1.2%	4.77 mm	0.1%	-0.39 mm
-1.1%	4.37 mm	0.2%	-0.78 mm
-1.0%	3.98 mm	0.3%	-1.16 mm
-0.9%	3.58 mm	0.4%	-1.55 mm
-0.8%	3.18 mm	0.5%	-1.94 mm
-0.7%	2.78 mm	0.6%	-2.33 mm
-0.6%	2.39 mm	0.7%	-2.71 mm
-0.5%	1.99 mm	0.8%	-3.10 mm
-0.4%	1.59 mm	0.9%	-3.49 mm
-0.3%	1.19 mm	1.0%	-3.88 mm
-0.2%	0.80 mm	1.1%	-4.26 mm
-0.1%	0.40 mm	1.2%	-4.65 mm
0.0%	0.00 mm		


5. If the copy image is enlarged, move the unit to the right for adjustment.



065-04-2

Fig. 1-8-28

6. If the copy image is reduced, move the unit to the left for adjustment.



065-04-3

Fig. 1-8-29

7. After adjustment, apply the screw lock paint to 3 screws secured.

1.9 Adjusting the main drive gear assembly

1. Loosen 2 screws (A) retaining the backlash adjusting gear of the main drive gear assembly.
2. Locate the main drive gear assembly in the copier and temporarily tighten 7 screws (B).




Fig. 1-9-1

3. Loosen one screw and remove the bushing plate.




Fig. 1-9-2

4. Place the drive gear jig by aligning with the drum shaft and the process unit positioning stud.




Fig. 1-9-3

5. Loosen the wing screw and hold the drive gear jig arm to the registration roller.
6. Place the tab of the drive gear jig arm in the hole and tighten the wing screw.




Fig. 1-9-4

7. While pressing down the drive gear jig, tighten 7 finger-tight screws (B) of the main drive gear assembly.
8. Loosen the wing screw, release the tab of the drive gear jig arm, and remove the drive gear jig.




Fig. 1-9-5

9. Mount 2 screws.
10. Mount the bushing plate and tighten 2 screws.




Fig. 1-9-6

11. Turn the main motor counterclockwise two or three times.




Fig. 1-9-7

12. Release the jam lever of the fuser.




Fig. 1-9-8

13. Slowly rotate the main motor clockwise (2 or 3 turns) until the gear of the fuser unit starts rotating (for e-STUDIO160 series).




Fig. 1-9-9

14. Slowly turn the main motor clockwise two or three times and check that the stud no longer moves (for e-STUDIO200/250 series).




Fig. 1-9-10

15. Lock the jam lever of the fuser.




Fig. 1-9-11

16. Tighten the screw (A) while holding the plate so that the place will not be dislodged.




Fig. 1-9-12

11

Note: With the fuser reliably mounted, the collar of the main drive gear assembly should turn with a slight load when it is turned.





Fig. 1-9-13

12


1.10 MAIN PWA replacement procedure

1. Downloading of the MAIN PWA firmware
For details, see chapter 5 of the Service Handbook.


2. Execution of 08-388 mode. (Reading of the total counter value)




3. RAM Clear with the [1], [3], and [*] keys.



4. Execution of 08-665 mode (05: adjustment clear/08: programming clear)




5. RAM Clear with the [1], [3], and [#] keys.




6. Download the scanner PWA firmware, if necessary, after confirming the version of it.

7. Settings for the country code or region code



8. Settings for the date and time

For details, see chapter 5 of the Operator's Manual.



9. Writing in memory (entering the drum counter value (DRUM COUNTER), long size counter value (A3/LD) and short size counter value (A4/LT)).

For the setting value, refer to the DRUM UNIT LIST printed before replacing the MAIN PWA.

When the DRUM UNIT LIST is not printed, perform the following setting.

Drum counter value: Find a remainder by dividing the total counter value (08-351) by the process unit life value (27k or 33k).

Enter the value obtained by multiplying the remainder by 10.

Long size counter value: Enter "0."

Short size counter value: Enter the remainder obtained by dividing the total counter value (08-351) by the process unit life value (27k or 33k).

For the setting procedures, refer to section 1.2.5 of the Service Handbook.

10. Entering the adjustment value for the printing position.

Enter the setting value for the following 21 items.

For the setting values, refer to the FUNCTION LIST printed before replacing the MAIN PWA, or the FUNCTION LIST on the inside of the rear cover of the copier.

When the FUNCTION LIST is not printed in 08-404/401/251/252, perform the following setting.

08-404: Enter the remainder obtained by dividing the total counter value (08-351) by the process unit life value (27k or 33k).

08-401: Find a remainder by dividing the total counter value (08-351) by the process life unit value (27k or 33k).

Enter the value obtained by multiplying the remainder by 4.7 (for e-STUDIO160/200 series) or 4.5 (for e-STUDIO250 series).

08-251: When it was set before the MAIN PWA was replaced, perform the setting again.

08-252: Enter the remainder obtained by dividing the total counter value (08-351) by the PM life value (81k or 99k).

When 08-251 is "0," however, it is not necessary to enter the 08-252 value.

For the setting procedures, refer to sections 1.2.1 and 1.2.2 of the Service Handbook.

- 1: 05-205 (Developer bias DC adjustment)
- 2: 05-210 (Grid voltage initial value adjustment)
- 3: 05-220 Transfer H
- 4: 05-221 Transfer C
- 5: 05-233 Separation H
- 6: 05-234 Separation C
- 7: 05-235 Separation L
- 8: 05-400 (Printer primary scanning reproduction ratio)
- 9: 05-410 (Laser start position)
- 10: 05-421 (Printer secondary scanning reproduction ratio)
- 11: 05-440 (Leading edge)
- 12: 05-430 (Top margin)
- 13: 05-431 (Left margin)
- 14: 05-432 (Right margin)
- 15: 05-433 (Bottom margin)
- 16: 08-404 (Developer material counter)
- 17: 08-401 (Drum life counter)
- 18: 08-251 (PM counter setting value)
- 19: 08-252 (PM counter present value)
- 20: 08-446 Transfer ON position
- 21: 08-447 Transfer OFF position

11. Sensor test in the [1] [3] test mode.

- 1: Confirm whether the attached options are reflected on the bit information correctly.
- 2: Refer to 1.2.4 of the Service Handbook.

12. SRAM test/DRAM test/Clock IC test/CODEC test mode.

For details, see chapter 8 of the Operator's Manual.


1.11 Measurement of Transfer Guide Bias

The transfer charge bias is applied to the pinch roller and the paper guide plate to prevent the transfer charge from escaping through the recording paper during transfer. To analyze the cause of a transfer failure which has occurred, you can output the transfer guide bias in the output test at any time and then measure the voltage.

Important:

Measure the transfer guide bias with the toner cartridge and the process unit taken out from the copier and the front cover open. Also, keep the front cover switch and interlock switch (front cover) ON by using the switch jigs (big/small).

<Keys used in operation>



<Display messages and measurement methods >

FUNCTION TEST	
09.CODEC TEST	▲
10.OUTPUT TEST	
11.PRINTER BOARD TEST	▼

: Enter the "Developer Bias Transformer ON/OFF" code.


Important:

Before outputting the transfer guide bias, it is necessary to turn the developer bias ON.

: Developer bias ON

Warning:

High voltage is output from the developer bias terminal. NEVER touch the terminal while measuring.



01-11-01

: Enter the "Transfer Guide Bias ON/OFF" code.

From preceding page

START

: Turn the transfer guide bias ON.

Measure the transfer guide bias at the following two points:

Important:

The settings and conditions of the digital tester to be used for measurement are as follows:


Function switch: DC

Full scale: 1000V


Remark: The digital tester to be used should have an input resistance value of 10MΩ or more.

Measurement value: +375±20V

To measure on the pinch roller:



To measure on the paper guide plate:



CLEAR/STOP

: Turn the transfer guide bias OFF.

CANCEL

CANCEL

: End the output test.

Power OFF

1.12 Adjustment of the doctor-sleeve gap

Tool to be used: Doctor-sleeve jig

- (1) Remove the toner cartridge and process unit.
- (2) Detach the drum assembly and dispose the developer material (Chapter 3-4 [G] in the Service Manual).
- (3) Remove the 2 screws and detach the developer cover.
Place the drum assembly on a flat surface.
- (4) Loosen 3 screws fixing the doctor blade.
- (5) Insert the jig of the gauge "0.275" into the gap between the magnetic roller and doctor blade.
The jig should be inserted into the positions of 3 screws.
- (6) Tighten the screws while the doctor blade is pressed against the doctor-sleeve jig lightly.
- (7) Insert the jig of the gauge "0.25" into the gap between the magnetic roller and doctor blade.
Confirm that the jig moves smoothly to the front and rear sides and the jig of the gauge "0.30" cannot be inserted into the gap.




Fig. 1-13-1

3-4-26

- (8) Close the developer cover and reconfirm the gap. If the gap is out of the specified value, repeat the procedure from (4).

When closing the developer cover, do not push the magnetic roller guide.

- (9) Apply the screw lock paint to 3 screws.

Note: Do not rotate the magnetic roller until the adjustment is completed. If the magnetic roller is rotated during the adjustment, repeat the procedure from (4).

2. PREVENTIVE MAINTENANCE (PM)

2.1 Maintenance Performed Every 81,000 (e-STUDIO160/200 Series) and 99,000 Copies (e-STUDIO250 Series)

(1) Preparation

- ① Ask user about the current machine condition and note them down.
- ② Before starting maintenance, make some sample copies and save them.
- ③ Turn OFF the power, and be sure to unplug the copier.

(2) Perform preventive maintenance using the following checklist and the illustrations. Refer to the Service Manual and Parts List if necessary.

(3) When the maintenance is finished, plug in the copier, turn ON the power, and make a few copies to confirm that the copier is working properly.

2.2 Preventive Maintenance Check List

Symbols used in the check list

	Cleaning	Lubrication	Replacing	Operation check	Date
A	Cleaning with alcohol	GR GR Grease (X5-6020)	27K Every 27,000 copies 33K Every 33,000 copies	After cleaning or replacing, check for no abnormality	User's name
○	Cleaning with soft pad, cloth or vacuum cleaner	W White grease (Molykote HP-300)	81K Every 81,000 copies 99K Every 99,000 copies		Serial No.
		FL FL Floil (GE-334C)	135K Every 135,000 copies 165K Every 165,000 copies		Inspector's name
		SI Silicon oil AV Alvania No. 2	△ Replace if deformed or damaged		Remarks

Notes: 1. Perform cleaning and apply lubrication every 81,000 copies for e-STUDIO160/200 series and 99,000 copies for e-STUDIO250 series.

2. <P-I> under "Remarks" indicates page and item number in the Parts List.

3. Replacement cycle of the parts of the feeding section depends on the number of papers fed from each paper source.


4. Values under "Replacement" indicates the replacement cycle for the e-STUDIO160/200 series e-STUDIO250 series.

5. Do not put oil on the rollers and belts when lubricating them.

6. Replace the parts with the life of 27,000 copies (e-STUDIO160/200 series) and 33,000 copies (e-STUDIO250 series) listed in the check list.

7. Replace the heat roller (metallic gold or dark green) and PM kit (FU-KIT-1600N and FU-KIT-2500N) at every 135,000 copies (e-STUDIO160/200 series) and 165,000 copies (e-STUDIO250 series).


MAIN (Front view)



2-1-1

* For an unspecified number, refer to the Parts List.

MAIN (Rear view)



* For an unspecified number, refer to the Parts List.

Section	Item to check	Cleaning	Lubri- cation	Replacement	Operation check	Remarks <P-I>
Process unit	1. Process unit			△		
	Photoconductive drum			27K/33K	*1	
	Drum cleaning blade			27K/33K	*2	
	Recoverly sheet			27K/33K		
	Charger case	○			*3	
	Charger wire			27K/33K	*3	
	Charger wire cleaner			81K/99K		
	Grid			27K/33K		
	Separation claw for drum			27K/33K	*4	
	Sheet cover			27K/33K		
	Sheet cover B			27K/33K		
	Developer material			81K/99K		
	Discharge lamp	○				
	Magnetic roller	*5				
	Magnetic roller spacer				*6	
	Drum gear	*7				
	Cleaner paddle drive gear	*7				
	Toner recovery auger drive gear	*7				
	Doctor blade				*8	
	2. Ozone filter 1			81K/99K		
	Ozone filter 2			81K/99K		<P2-I23>
	Main charger wire	○			*9	
	HVPS contacts	○			*10	
Around-Process unit area	5. Toner supply motor		GR			Gear teeth
	7. Registration roller	○				
	8. Pinch roller gear		GR			Gear teeth <P15-I20> (e-STUDIO200/250 series)
	Ground plate	○	FL		*10	Between the shaft of registration roller and ground plate <P15-I22>
Fuser unit	12. Fuser unit			△		
	13. Pressure roller			81K/99K or 135K/165K	*11	
	14. Heat roller (Brown) Heat roller (Metallic gold) Heat roller (Dark green)			81K/99K 135K/165K 135K/—	*12, *13	
	15. Heater lamp			△		
	16. Separation claw for heat roller			81K/99K or 135K/165K	*14	
	17. Cleaning roller			81K/99K or 135K/165K	*15	
	18. Thermostat 1/2			△		
	19. Heater thermistor 1/2			△		
	Pressure roller cover	○		△	*16	<P27-I3> (e-STUDIO160 series) <P28-I3> (e-STUDIO200/250 series)
	Pressure roller case	○		△	*17	<P27-I4> (e-STUDIO160 series) <P28-I4> (e-STUDIO200/250 series)
	22. HR drive gear 1		W			Shaft
	23. HR drive gear 3		W			Shaft
	23. Inner HR drive gear 3		W			Shaft (e-STUDIO200/250 series)
	92. HR drive gear 2		W		*13	<P27-I9> (e-STUDIO160 series) <P28-I9> (e-STUDIO200/250 series)

Section	Item to check	Cleaning	Lubri- cation	Replacement	Operation check	Remarks <P-I>
Scanner	24. Shading sheet	○		△	*18	
	25. Reflecting mirror 1	○		△	*19	
	26. Reflecting mirror 2	○		△	*19	
	27. Reflecting mirror 3	○		△	*19	
	28. Original glass	○ or A		△	*20	
	29. ADF glass	○ or A		△	*20	
	30. CCD unit	○		△	*21	Using the blower (Do not use a cloth)
	31. Exposure lamp			△		
Laser scanner unit	32. Laser scanner unit	○		△		Using the blower (Do not use a cloth)
Transfer charger unit	33. Transfer charger unit			△		
	Transfer wire	○		81K/99K	*22	<P7-I9>
	35. Transfer guide roller	○			*23	<P7-I16>
Tray-up unit	36. Tray-up Motor		GR			Gear teeth
Main drive unit	37. Tray-up gear 1		GR			Gear teeth
	38. Tray-up gear 2		GR			Gear teeth
	39. Tray-up gear 3		GR			Gear teeth
	40. Tray-up gear 4		GR			Gear teeth
	41. Tray-up gear 5		GR			Gear teeth
Main drive unit	42. Cassette feed gear 2		GR			Gear teeth (Never apply the timing belt)
	43. Cassette feed gear 3		GR			Shaft and gear teeth
	44. Cassette feed gear 4		GR			Shaft and gear teeth
	45. Cassette feed gear 5		GR			Shaft and gear teeth
	46. Cassette feed gear 6		GR			Shaft and gear teeth
	47. Cassette feed gear 7		GR			Shaft and gear teeth
	48. Cassette feed gear 8		GR			Shaft and gear teeth
	49. Transmission gear 1		GR			Shaft and gear teeth
	50. Transmission gear 2		GR			Shaft and gear teeth
	51. Transmission gear 3		GR			Shaft and gear teeth
	52. Registration drive gear		GR			Shaft and gear teeth
	53. Main drive gear 1		GR			Shaft
	54. Main drive gear 2		GR			Shaft and gear teeth
	55. Main drive gear 3		GR			Shaft and gear teeth
	56. Main drive gear 4		GR			Shaft and gear teeth
	57. Main drive gear 5		GR			Shaft and gear teeth
	58. Main drive gear 6		GR			Shaft and gear teeth
	E-ring E-8		GR			<P11-I103>
	73. Drum drive gear		GR			Gear teeth
	74. 2nd feed clutch		GR			Gear teeth
Exit drive	60. Exit drive gear 2		GR			Gear teeth
	61. Exit drive gear 3		GR			Gear teeth
	62. Exit drive gear 4		GR			Gear teeth
	63. Exit drive gear 6		GR			Gear teeth
	64. Exit roller				*24	<P8-I43>
Paper feed unit	65. Pickup roller	○		81K/99K	*25	
	66. 2nd pinch roller	○			*26	
	2nd paper guide	○			*27	<P16-I11>
	Paper guide	○			*27	<P16-I1>
	69. 2nd feed roller	○			*28	
Paper guide unit	Spring		AV			<P16-I4>
	71. Separation roller	○		81K/99K	*29	
	72. Feed roller			81K/99K	*30	Shaft and gear teeth

* Notes on the Preventive Maintenance Checklist

*1. Photoconductive drum

Refer to "3.6 Checking and Cleaning of Photoconductive Drum".

*2. Drum cleaning blade

Since the edge of the blade is breakable and can be easily damaged by matters such as the adherence of paper dust. Replace the cleaning blade with a new one if poor images are copied due to the damaged blade regardless of the number of copies which have been made.

*3. Main charger case/main charger wire

Clean the main charger case and wire with a cloth soaked in water and then squeezed tightly.

Note: Be careful of the following when attaching a new wire (length: 358mm).

- Do not twist the wire.
- Do not touch the wire with your bare hand.

*4. Separation claws for the drum

The paper jam may be caused if the tip of the separation claw is damaged or deformed. If there is any problem with it, replace the claw with a new one regardless of the number of copies which have been made.

If any mark which was made by the claw appears on the copied image, clean the tip of the claw.


Notes: 1. Wipe the tip of the claw lightly with a dry cloth trying not to deform it.

Do not leave the lint on the tip.

2. Apply patting power to the tip of the claws and drum surface after replacing or cleaning them to reduce the load on the drum surface by the claw.

*5. Magnetic roller

If a white banding appears on the magnetic roller, clean the area between the magnetic roller and doctor blade with the doctor blade cleaning jig.



2-6


*6. Magnetic roller spacer

Confirm that the magnetic roller spacer is rotated. If not rotated, replace the magnetic roller spacer with a new one.

*7. Drum gear/Cleaner paddle drive gear/Toner recovery auger drive gear

Confirm that toner or foreign matters is not stuck to the drum gear, cleaner paddle drive gear or toner recover auger drive gear.

If stuck, remove the drum rear cover and clean the gear as required.



2-7

*8. Doctor blade

Confirm that the doctor-sleeve gap is within the specified value. If not, adjust the gap. (For the specified value and adjustment procedure, refer to section 1.13 "Adjustment of the doctor-sleeve gap" on page 1-95.)

*9. Main charger wire

To clean the wire, use a charger cleaner.

*10. HVPS contacts (Feed roller contact/DEV. Contact/PU contact)/Ground plate

Use a cloth which should be soaked in water and then wrung strongly to clean the contacts surface.

*11. Pressure roller


Refer to "3.2 Checking and Cleaning of the Pressure Roller".

*12. Heat roller

Refer to "3.4 Checking and Cleaning of the Heat Roller".

*13. HR drive gear 2

Every time when the HR drive gear 2 or heat roller (metallic gold or dark green) is replaced (135K/165K), wipe the old oil up and apply 0.075g of white grease (molykote HP-300) to the area around the boss inside of HR drive gear 2.



*14. Cleaning roller

Refer to "3.3 Checking and Cleaning of the Cleaning Roller".

*15. Separation claw

Replace any claws if its tip is damaged, regardless of the specified number of the copies for replacement. If toner is fused tightly on the tip of claws, the tip may be damaged if you try to scrape the toner off forcefully. So, replace any claws that are heavily

*16. Pressure roller cover

To clean the inside of the pressure roller cover, use a cloth which should be soaked in water and then wrung lightly.

*17. Pressure roller case

Check if the outside surfaces including the bottom surfaces are dirty, and clean if necessary.

*18. Shading sheet

To clean the backside of the original glass, use a cloth which should be soaked in water and then wrung strongly.

*19. Reflecting mirror 1/Reflecting mirror 2/Reflecting mirror 3

To clean the surface of the reflecting mirrors, use a cloth which should be soaked in water and then wrung strongly.

*20. Original glass/ADF glass

To clean the surface of the glasses, use a cloth which should be soaked in water and then wrung strongly.

*21. CCD unit

To clean the lens of the CCD, use a blower.

*22. Transfer wire

To clean the wire, use a charger cleaner.

*23. Transfer guide roller

Refer to “3.5 Checking and Replacing the Transfer Guide Roller”.

*24. Exit roller

To clean the surface of the exit roller, use a cloth which should be soaked in water and then wrung strongly.

*25. Pickup roller

To clean the surface of the pickup roller, use a cloth which should be soaked in water and then wrung strongly.

*26. 2nd pinch roller

To clean the surface of the 2nd pinch roller, use a cloth which should be soaked in water and then wrung strongly.

*27. Paper guide/2nd paper guide

To clean the surface of the paper guides, use a cloth which should be soaked in water and then wrung strongly.

*28. 2nd feed roller

To clean the surface of the 2nd feed roller, use a cloth which should be soaked in water and then wrung strongly.


*29. Separation roller

To clean the surface of the separation roller, use a cloth which should be soaked in water and then wrung strongly.


*30. Feed roller

To clean the surface of the feed roller, use a cloth which should be soaked in water and then wrung strongly.

MY-1015




2-1



2-3


Section	Item to check	Cleaning	Lubri- cation	Replace- ment	Operation check	Remarks <P-I>
Tray-up unit	1. Tray-up Motor		GR			Gear teeth, see page 2-3/2-5
	2. Tray-up gear 1		GR			Gear teeth, see page 2-3/2-5
	3. Tray-up gear 2		GR			Gear teeth, see page 2-3/2-5
	4. Tray-up gear 3		GR			Gear teeth, see page 2-3/2-5
	5. Tray-up gear 4		GR			Gear teeth, see page 2-3/2-5
	6. Tray-up gear 5		GR			Gear teeth, see page 2-3/2-5
Gears	7. PFU joint gear 06B		GR			Shaft and gear teeth
	8. PFU joint gear 06A		GR			Shaft and gear teeth
Rollers	10. Feed roller			△		<P3-I16>
	11. Pickup roller			△		<P3-I29>
	12. Separation roller			△		<P3-I20>
Other	13. Spring		AV			<P3-I19>



2-2

Section	Item to check	Cleaning	Lubri- cation	Replace- ment	Operation check	Remarks
Motor gears	1. Gear GG0SSW4/USS044		GR			Shaft and gear teeth
	2. Gear 08S024-06		GR			Shaft and gear teeth
	3. Gear 08S018-06		GR			Shaft and gear teeth
	4. Gear 08S18-06CL		GR			Gear teeth
	5. ADU motor		GR			Gear teeth

MY-1016



2-4

Section	Item to check	Cleaning	Lubri- cation	Replace- ment	Operation check	Remarks <P-I>
Rollers	1. Feed roller			△		
	2. Pickup roller			△		
	3. Separation pad			△		
Other	4. Spring		SI			<P2-I28>
	5. Document tray upper		SI			<P1-I5>

MR-3011


Section	Item to check	Cleaning	Lubri- cation	Replace- ment	Operation check	Remarks
Clutch gears	1. RADF clutch gear 56/16		GR			Gear teeth
	2. RADF clutch gear 40/24		GR			Gear teeth
	3. RADF clutch gear 20		GR			Gear teeth
	4. RADF clutch gear 66		GR			Gear teeth
	5. RADF clutch gear 25		GR			Gear teeth
Rollers	6. Feed roller			△		
	7. Pickup roller			△		
	8. Separation pad			△		
	9. Separation roller			△		

MJ-5002

Section	Item to check	Cleaning	Lubri- cation	Replace- ment	Operation check	Remarks <P-I>
Roller	1. OCT exit roller		GR FL			Shaft <P2-I19>
Frame	2. OCT gear frame		GR			Shaft <P1-I17>

MJ-5001

Section	Item to check	Cleaning	Lubri- cation	Replace- ment	Operation check	Remarks <P-I>
Gears	1. Gear 08S012-05H		GR			Shaft <P1-I66>
	2. JSP gear pulley		GR			Shaft <P1-I61>
Other	3. JSP flapper		GR			Shaft <P1-I54>
	4. JSP exit roller shaft		GR			Shaft <P1-I42>

KD-1009

2-5

Section	Item to check	Cleaning	Lubri- cation	Replace- ment	Operation check	Remarks
Gears	1. Gear GG10S018/05H073		GR			Shaft and gear teeth
	2. Gear GG10S018/05H048		GR			Shaft and gear teeth
	3. Gear GP10S018/3GT031		GR			Shaft and gear teeth
	4. Gear 10S031-06		GR			Shaft and gear teeth
	5. Gear 10S016-06		GR			Shaft and gear teeth
	6. Gear GP10S016/2GT027		GR			Shaft and gear teeth
	7. Gear GP10S028/3GT031		GR			Shaft and gear teeth
	8. Gear 10S028-06		GR			Shaft and gear teeth
	9. Gear 10S020-06		GR			Shaft and gear teeth
	10. Gear 10S16-06		GR			Gear teeth
	11. Gear 22-clutch		GR			Gear teeth
Other (MY-1017)	12. Feed roller			△		
	13. Bush (POM)		GR			
	14. Tension pulley		GR			Shaft
	15. Pickup roller			△		
	16. Separation roller			△		

MR-2012

Section	Item to check	Cleaning	Lubri- cation	Replace- ment	Operation check	Remarks
Rollers	1. Feed roller			△		
	2. Pickup roller			△		
	3. Separation pad			△		
	4. Separation roller			△		


KD-1010

Section	Item to check	Cleaning	Lubri- cation	Replace- ment	Operation check	Remarks
Rollers	1. Feed roller (Upper/Lower)	A		△		
	2. Pickup roller (Upper/Lower)	A		△		
	3. Separation roller (Upper/Lower)	A		△		
Gears	4. Drive gears		W			Gear teeth

2.3 PM Kit

Kit name	Classification of kits	PART NAME	Q'ty	No. of copies for replacement cycle	
				e-STUDIO160/ 200 series	e-STUDIO250 series
CH-KIT-1600	Transfer wire	WIRE-TC	2	81K	99K
	Guide roller gear	GEAR-RLR-GUIDE	1		
	Defense sheet R	SHEET-DEFENSE-R	1		
	Defense sheet F	SHEET-DEFENSE-F	1		
	Guide roller	ROLLER-GUIDE	1		
	Guide roller bush	BUSH-RLR-GUIDE	2		
ROL-KIT-16CST	Separation roller	K-ROLL-SPT	1	81K	99K
	Feed roller	K-ROLL-FEED	1		
	Pickup roller	ROLLER-PICK-AT	1		
PU-KIT-1600	Drum cleaning blade	BL-1600D	1	27K	33K
	Recovery sheet	SHEET-RECOV	1		
	Sheet cover	SHEET-COVER	1		
	Sheet cover	CHEET-COVER-B	1		
	Drum scraper	SCRAPER-DRUM-S	3		
	Charger	WIRE-CHG-S	1		
	Grid	K-GRID-13	1		
DEV-KIT-1610	Developer	D-1600	1	81K	99K
	Cleaning pad	K-HLDR-PAD	2		
	Ozone filter 1	FILTER-OZON-TY1	1		
	Ozone filter 2	FILTER-OZON-TY2	1		
FU-KIT-1600N	Cleaning roller	RLR-FUS-CLN	1	135K (e-STUDIO160 series)	-
	Cleaning roller bush	BUSH-CL-RLR	2		
	Heat roller bush	BUSH-HR/RLR	2		
	Idle gear	GEAR-HT/IDLE	1		
	Separation finger	SEP-HT/RLR	6		
	Pressure roller	HR-1600-L	1		
	Heat roller (Metallic gold)	HR-1600-UN	1		
FU-KIT-2500N	Cleaning roller	RLR-FUS-CLN	1	135K (e-STUDIO200 series)	165K
	Cleaning roller bush	BUSH-CL-RLR	2		
	Heat roller bush	BUSH-HR/RLR	2		
	Idle gear	GER1-HT/IDLE-AW	1		
		GER2-HT/IDLE-AW	1		
	Separation finger	SEP-HT/RLR	6		
	Pressure roller	HR-2500-L	1		
	Heat roller (Metallic gold)	HR-2500-UN	1		
ROL-KIT-1010	Pickup roller	ROL-PICK-UP	1	160K (e-STUDIO200 series)	160K
	Feed roller	ROL-PAPER-FED-F	1		
	Separation roller	ROL-PAPER-FED-S	1		

2.4 List of Adjustment Tools



No.	Classification of tools	Name	Parts List	
			Page	Item
1	Clip jig	ASM-HLD-W-AT	20	1
2	CCD jig	JIG-CCDUNIT-AT	20	2
3	Spring jig (wire)	SPE-TENS-WIRE	20	3
4	Spring jig (belt)	SPE-TENS-BELT	20	4
5	Drive gear jig	ASM-GBOX-JIG	20	5
6	High-voltage measurement jig	ASM-P/U-TOOL	20	6
7	Scanner recovery PWA	PWA-F-SCNRCV-AT	20	7
8	Main recovery PWA	PWA-F-RCV-AT	20	8
9	Doctor-sleeve jig	K-JIG-DC-SL	20	16
10	Doctor-blade cleaning jig	MYLER-SCRAPER	20	17
11	Belt tension jig	PLT-JIG-ADJ-MOT	20	21
12	Fuser gap jig	ASY-JIG-FGAP	20	22

2.5 List of Grease

Lubrication	Name	Volume	Container	Parts List	
				Page	Item
GR Grease (X5-6020)	MOLYKOTE-100	100g	Tube	20	11
SI Silicon oil (TSF451-1M)	ASM-SILICONE-1M	100cc	Bottle	20	12
AV Alvania grease No.2	ASM-PG-ALV2-S	100g	Tube	20	13
W White grease (Molykote HP-300)	ASM-PG-HP300-S	100g	Bottle	20	14A
W White grease (Molykote HP-300)	GREASE-HP300-S	10g	Bottle	20	14B
FL Floil (GE-334C)	ASM-GE334C-S	20g	Bottle	20	15

3. PRECAUTIONS FOR STORING & HANDLING SUPPLIES

3.1 Precautions for Storing TOSHIBA Supplies

A. Toner cartridge

Toner cartridge and process unit should be stored in a shaded place where the ambient temperature is between 10 to 35°C (no condensation), and should also be protected against direct sunlight during transportation.

B. Process unit (Developer material, Photoconductive drum, Drum cleaning blade)

Like toner cartridge, process unit should be stored in a dark place where the ambient temperature is between 10 to 35°C (no condensation). Be sure to avoid places where process unit may be subjected to high humidity, chemicals and/or chemical gas.

C. Pressure roller

Avoid places where the pressure roller may be subjected to high humidity, chemicals and/or chemical gas.

D. Cleaning roller

Avoid places where the cleaning roller may be subjected to high humidity, chemicals and/or chemical gas. It should also be stored “horizontally” on a flat surface.

E. Heat roller

Avoid places where the heat roller may be subjected to high humidity, chemicals and/or chemical gas.

F. Copy paper

Avoid storing copy paper in places where it may be subjected to high humidity.

After a package is opened, be sure to place and store it in a storage bag.

3.2 Checking and Cleaning of the Pressure Roller

(1) Handling precautions

- ① Do not allow any hard object to hit or rub against the surface.
- ② Do not stain the pressure roller surface with any oil of fingerprints, etc.
- ③ Do not allow solvents such as paint thinner to touch the pressure roller surface.

(2) Cleaning procedure

Use a cloth which should be soaked in water and then wrung strongly to clean the pressure roller surface.

3.3 Checking and Cleaning of the Cleaning Roller

(1) Handling precautions

- ④ Do not allow any hard object to hit or rub against the surface.
- ⑤ Do not stain the pressure roller surface with any oil of fingerprints, etc.
- ⑥ Do not allow solvents such as paint thinner to touch the pressure roller surface.

(2) Checking

Defective heat roller cleaning should be judged by the toner deposited on the pressure roller surface

If toner is heavily adhered on the heat roller surface, defective cleaning may occur. If this happens, replace the cleaning roller.

Replace it preferably after about 81K copies for e-STUDIO160 series and 99K copies for e-STUDIO200/250 series have been made.

(3) Cleaning procedure

Use a cloth which should be soaked in water and then wrung strongly to clean the cleaning roller surface.

3.4 Checking and Cleaning of the Heat Roller

(1) Handling Precautions

- ① Do not leave any oil (fingerprints, etc.) on the heat roller.
- ② Be careful not to allow any hard object to hit or rub against the heat roller, or they may be damaged, possibly resulting in defective cleaning.

(2) Checking

- ① Check for stain and damage on the heat roller and clean if necessary.
- ② Clean the separation claws and check for chipped claw tips.
- ③ Check the cleaning effect of the cleaning roller.
- ④ Check the thermistor for proper contact with the heat roller.
- ⑥ Check the fused condition of the toner image.

(3) Cleaning Procedure for Heat Roller

When heat roller become dirty, they will cause jamming. If this happens, wipe the heat roller surface clean with a suitable cloth. For easier cleaning, clean the heat roller while they are still warm.

Note: Be careful not to rub the heat roller surface with your fingernails or hard objects because it can be easily damaged. Do not use silicone oil on the heat roller.

3.5 Checking and Replacing of the Transfer Guide Roller

(1) Handling Precautions

- ① Do not touch the transfer guide roller surface with your bare hands.
- ② Be careful not to leave any scratch or dent on the transfer guide roller surface.

3.6 Checking and Cleaning of the Photoconductive Drum

(1) Use of gloves

Since fingerprints or oil stains on the drum surface affects the quality of the copy image and degrades the characteristics of the photoconductor, do not touch the drum surface with your bare hands.

(2) Handling precautions

As the drum surface is very sensitive, be sure to handle the drum carefully when installing or removing it so as not to damage its surface.

When the drum is replaced with a new one, apply patting powder (lubricant) on the entire surface of the new drum (including both edges to where the OPC is not coated) and separation claw of the cleaner before installing them. The drum counter must be cleared to 0 (zero) in the setting mode 08-673.

Notes: 1. Application of the patting powder is to reduce friction among the drum, the cleaning blade and the separation claw. If this process is not performed, the drum and the cleaning blade may be damaged.

2. Remove any fibers or lint adhering to the blade since they can damage the drum and blade, or allows defective cleaning.

(3) Installation of the copier and storage of the drum

Do not install the copier in a place where it may be exposed to high temperature, high humidity, chemicals and/or chemical gas.

Do not leave the drum in a brightly lit place for a long time. Otherwise, it would be fatigued and causes background fogging on the copied image right after it is installed in the machine. However, this phenomenon will decrease as time elapses.

(4) Cleaning the drum

At the preventive maintenance, wipe the entire surface of the drum softly using the specified cleaning cotton (dry soft pad). Use sufficiently thick cleaning cotton so as not to touch the drum surface directly with your fingertips or nails. Remove your rings and wristwatch before cleaning so as not to damage the drum.

Do not use organic solvents such as alcohol or silicone oil as they have a bad influence on the drum. Do not use selenium refresher either.

(5) Scratches on the photoconductive drum surface

If the surface is scratched and the aluminum base is exposed, black spots or streaks will appear on the copied images. Since those scratches can damage the cleaning blade, replace the drum with a new one.

(6) Used photoconductive drums

Dispose of the used drums following the regulations regarding industrial waste established by your local municipal office.

3.7 Checking and Cleaning of the Drum Cleaning Blade

(1) Handling Precautions

Since the edge of the cleaning blade performs the cleaning operation, pay attention to the followings:

- Do not hit or rub the blade edge with anything hard.
- Do not rub the edge with a dry cloth or soft pad.
- Do not stain the edge with oil or fingerprints, etc.
- Do not put solvents such as paint thinner or the blade.
- Do not leave lint or dirt on the blade edge.
- Do not put the blade close to a heat source.

(2) Cleaning

Clean the blade edge softly with a cloth soaked in water and afterwards squeezed hard.

4. TROUBLESHOOTING

Before starting any repair work, strictly obey the following instructions.

CAUTION:

- When replacing parts, be sure to turn the main switch OFF and unplug the power-cord plug from the outlet.

Notes:

- Be sure to output a dial list and a system function list and keep them until the troubleshooting is completed so that if the user's set data is lost it can be re-entered.
- Before turning the main switch OFF, be sure to confirm that the residual memory is 100% and no memory reception documents exist. If there is such a document, it will be lost if the service activity requires the battery backup to be unplugged.
- Cover the process unit with a cloth, etc., whenever it is removed from the machine to protect the photosensitive material from deterioration by exposure to light.
- Be sure to perform each adjustment and setting when replacing the following part.

Main PWA	: Refer to 1.10 MAIN PWA replacement procedure.
CCD unit	: Refer to 1.4.3 Printer unit adjustment and 1.8.5 CCD unit.
Scanner control PWA	: Refer to 1.4.3 Scanner unit adjustment.
Carriage 1	: Refer to 1.8.3 Adjusting the Carriage 1.
Carriage 2	: Refer to 1.8.4 Adjusting the Carriage 2.
Laser scanner unit	: Refer to 1.4.2 Printer unit adjustment and 1.4.4 Printer.
Original length sensor (RADF)	: Automatic sensor adjustment (05-356)
Read sensor (RADF)	: Automatic sensor adjustment (05-356)
Reverse sensor (RADF)	: Automatic sensor adjustment (05-356)

4.1 Troubleshooting Based on Error Code

4.1.1 Transporting jam in the main body

E01 Paper jam inside the machine

E02 Paper jam near the fuser unit

When recording paper is left inside the machine, remove it. If this error occurs frequently, the following items should be checked.

Where was the paper stopped?

Before reaching the registration roller

Is the registration roller clutch working? (using the test mode 10, Output Test, CODE 108)

YES

Check to see if there are any foreign obstacles on the recording paper path near the registration roller.

NO

1. Check if each connector between the registration roller clutch and relay PWA (CN37) is disconnected.
2. Check if each connector pin is removed or the harness is broken.
3. Check if any conductor pattern on the relay and main PWA is open- or short-circuited.
4. Replace the registration roller clutch.
5. Replace the relay PWA.
6. Replace the main PWA.

Near the fuser unit


Is the HR drive gear 1 of the fuser unit driven when the main motor is manually rotated clockwise?


YES


Check to see if there are any foreign obstacles on the recording paper path near the fuser unit.

NO

1. Check to see if the gear in the fuser unit is damaged.
2. Check to see if each gear of the main drive gear assembly is damaged.








E03 Paper remaining inside the machine at power ON


When recording paper is left inside the machine, remove it. If this error occurs frequently, refer to **E01**, **E02** and **E11** to **E19**.

E08 Transporting jam inside the ADU

If recording paper is left in the ADU, remove it. If this error occurs frequently, the following items should be checked.

Do the gears of the drive gear assembly rotate when the ADU motor (Upper) is driven in the reverse direction? (using test mode 10, Output Test, CODE 224)





4.1.2 Paper feeding jam


E11 Paper feeding jam at the ADU

If recording paper is left in the ADU, remove it. If this error occurs frequently, the following items should be checked.

1. Check to see if the pinch roller or feed roller in the ADU is damaged.
2. Check to see if there are any foreign obstacles on the recording paper path in the ADU.

E12 Paper feeding jam at the SFB

When recording paper is left inside the SFB, remove it. If this error occurs frequently, the following items should be checked.



E13 Tray 1 feeding jam

When recording paper is left on the recording paper path, remove it. If this error occurs frequently, the following items should be checked.

Where was the paper stopped?

Near the registration roller

Is the feed sensor working? (using the test mode 04, Sensor Test, DATA No. 6 Bit 2)

NO

1. Check if each connector between the feed sensor and the relay PWA (CN33) is disconnected.
2. Check if each connector pin is removed or the harness is broken.
3. Check if any conductor pattern on the relay and main PWA is open- or short-circuited.
4. Replace the feed sensor.
5. Replace the Relay PWA.
6. Replace the main PWA.

YES

Check to see if there are any foreign obstacles on the recording paper path.

Before reaching the pickup feed roller

Is the pickup clutch working? (using the test mode 10, Output Test, CODE 201)

NO

1. Check if each connector between the pickup clutch and the relay PWA (CN37) is disconnected.
2. Check if each connector pin is removed or the harness is broken.
3. Check if any conductor pattern on the relay and main PWA is open- or short-circuited.
4. Replace the pickup clutch.
5. Replace the relay PWA.
6. Replace the main PWA.

YES

Activate the pickup clutch. (using test mode 10, Output Test, CODE 201)

Do the pickup and pickup feed rollers rotate when the main motor is driven? (using test mode 10, Output Test, CODE 101)

NO

1. Check to see if each gear of the main drive gear assembly is damaged.
2. Check to see if each pulley or the timing belt of the pickup assembly is damaged.

YES

Check to see if there are any foreign obstacles on the recording paper path.

E14 Tray 2 feeding jam

When recording paper is left on the recording paper path, remove it. If this error occurs frequently, the following items should be checked.

Where was the paper stopped?

— Near the registration roller

↓
Is the 2nd feed roller sensor working? (using the test mode 04, Sensor Test, DATA No. 20 Bit 6)

NO


1. Check if each connector between the 2nd feed roller sensor and the PFC PWA (CN205) is disconnected.
2. Check if each connector between the PFC PWA (CN201) and the relay PWA (CN36) is disconnected.
3. Check if each connector pin is removed or the harness is broken.
4. Check if any conductor pattern on the PFC, relay and main PWA is open- or short-circuited.
5. Replace the 2nd feed roller sensor.
6. Replace the PFC PWA.
7. Replace the relay PWA.
8. Replace the main PWA.

YES

↓
Check to see if there are any foreign obstacles on the recording paper path.

— Before reaching the 2nd feed roller

↓
Is the 2nd feed roller clutch working? (using the test mode 10, Output Test, CODE 203)




E15 Tray 3 feeding jam

E19 LCF feeding jam


When recording paper is left on the recording path, remove it. If this error occurs frequently, the following items should be checked.

Is the PFP paper feed sensor (Upper) working? (using the test mode 04, Sensor Test, DATA No.17 Bit 4)



Activate the PFP pickup clutch. (using test mode 10, Output Test, CODE 226)


Do the pickup and pickup feed rollers installed on the upper side of the PFP rotate when the PFP main motor is driven? (using test mode 10, Output Test, CODE 109)



E16 Tray 4 feeding jam

When recording paper is left on the recording path, remove it. If this error occurs frequently, the following items should be checked.


Is the PFP paper feed sensor (Lower) working? (using the test mode 04, Sensor Test, DATA No.18 Bit 4)



YES

Activate the CM pickup clutch. (using test mode 10, Output Test, CODE 227)

Do the pickup and pickup feed rollers, which are installed on the lower side of the PFP rotate when the PFP main motor is driven? (using test mode 10, Output Test, CODE 109)



YES

Check to see if there are any foreign obstacles on the recording paper path.


4.1.3 Transporting jam for the optional trays

E31 Paper not reach to feed sensor from tray 2

E32 Paper not reach to feed sensor from tray 3/4

E33 Paper not reach to feed sensor from LCF

When recording paper is left on the recording paper path, remove it. If this error occurs frequently, the following items should be checked.



E34 Paper not reach to option cassette feed sensor from tray 3/4

E36 Paper not reach to option cassette feed sensor from LCF

When recording paper is left on the recording path, remove it. If this error occurs frequently, the following items should be checked.

Where was the paper stopped?

Near the registration roller

Is the 2nd feed roller sensor working? (using the test mode 04, Sensor Test, DATA No. 20 Bit 6)

NO

1. Check if each connector between the 2nd feed roller sensor and the PFC PWA (CN205) is disconnected.
2. Check if each connector between the PFC PWA (CN201) and the relay PWA (CN36) is disconnected.
3. Check if each connector pin is removed or the harness is broken.
4. Check if any conductor pattern on the PFC, relay and main PWA is open- or short-circuited.
5. Replace the 2nd feed roller sensor.
6. Replace the PFC PWA.
7. Replace the relay PWA.
8. Replace the main PWA.

YES

Check to see if there are any foreign obstacles on the recording paper path.

Before reaching the 2nd feed roller


Is the 2nd feed roller clutch working? (using the test mode 10, Output Test, CODE 203)

NO


1. Check if each connector between the 2nd feed roller clutch and the PFC PWA (CN205) is disconnected.
2. Check if each connector between the PFC PWA (CN201) and the relay PWA (CN36) is disconnected.
3. Check if each connector pin is removed or the harness is broken.
4. Check if any conductor pattern on the PFC, relay and main PWA is open- or short-circuited.
5. Replace the 2nd feed roller clutch.
6. Replace the PFC PWA.
7. Replace the relay PWA.
8. Replace the main PWA.


YES

Check to see if there are any foreign obstacles on the recording paper path.




E35 Paper not reach to PFP paper feed sensor (upper) from tray 4






4.1.4 Paper jam if some cover is opened


E41 Front cover or side cover is opened during copying




E42 PFU side door is opened during copying



E43 ADU is opened during copying



E45 Side cover of LCF opened during printing




4.1.5 Paper transporting jam at the ADF


E71 Original feeding jam at the feeding area of the ADF

When original is left inside the ADF, remove it. If this error occurs frequently, the following items should be checked.

[Two or more originals are fed simultaneously.]




[The original does not reach the feed roller.]



E72 Original transporting jam at the transporting area of the ADF

E73 Original exiting at the exiting area of the ADF

When original is left inside the ADF, remove it. If this error occurs frequently, the following items should be checked.




4.1.6 Paper transporting jam at the RADF

E71 Original feeding jam at the feeding area of RADF

When original is left inside the RADF, remove it. If this error occurs frequently, the following items should be checked.

[Two or more originals are fed simultaneously.]


Have too many originals been placed?




Are the original sheets curled or folded too much?



Are different-size originals placed together?




Is the separation roller stained?




[The original does not reach the feed roller.]


Does the paper thickness satisfy the specifications?



Is the pickup roller, feed roller or separation roller stained?




Is the transporting force of the pickup roller, feed roller or separation roller insufficient?



E72 Original transporting jam at transporting area of the RADF.


E73 Original exiting at the exiting area of RADF.

When original is left inside the RADF, remove it. If this error occurs frequently, the following items should be checked.




E74 Original reversing jam

When recording paper is left inside the machine, remove it. If this error occurs frequently, the following items should be checked.




4.1.7 Paper jam in finisher


EA1 Finisher paper transport delay jam




EA2 Finisher paper transport stop jam




EA3 Paper remaining in finisher at power ON




EA4 Finisher front cover opened during printing




EA5 Finisher stapling jam




EA6 Finisher early arrival jam



EA7 Stack transport jam before stapling



EAF Stapled stack transport jam




4.1.8 Drive system service call

C01 Abnormal operation of the main motor


1. Check if each connector between the main motor (CN1, CN2) and the relay PWA (CN29, CN28) is disconnected.
2. Check if each connector between the relay PWA (CN21) and the main PWA (CN15) is disconnected.
3. Check if each connector pin is removed or the harness is broken.
4. Check if any conductor pattern on the main motor, relay and main PWA is open- or short-circuited.
5. Replace the main motor.
6. Replace the relay PWA.
7. Replace the main PWA.

C04 Abnormal operation of the PFP main motor


Is the PFP main motor working? (using the test mode 10. Output Test, CODE 109)



Is the LED on the PFP main motor lit continuously?




Does the PLL lock signal CN246-8 on the PFP PWA continuously display 'L'?




C06 Abnormal operation of the LCF transport motor

Is the LCF transport motor working? (using the test mode 10. Output Test, CODE 270)




4.1.9 Temporary paper supply mechanism service call

C13 Abnormal operation of the paper tray in the main body




C14 Abnormal operation of the 2nd tray


Does the PFU tray move up? (using the test mode 10, Output Test, CODE 243)



Is the PFU pickup sensor working? (using the test mode 04, Sensor Test, DATA No. 16 Bit 0)




C15 Abnormal operation of the 3rd tray in the PFP




C16 Abnormal operation of the 4th tray in the PFP

Does the PFP tray (lower) move up? (using the test mode 10, Output Test, CODE 276)



Is the CM pickup sensor working? (using the test mode 04, Sensor Test, DATA No.18

Bit 0)



C18 LCF tray-up motor is abnormal

Does the LCF tray move ? (using the test mode 10, Output Test, CODE271.)

NO

1. Check the connector of the LCF tray-up motor for disconnection.
2. Check the connectors CN100, CN101 and CN103 on the LCF PWA for disconnection.
3. Check the connector CN206 on the PFC PWA for disconnection.
4. Check the connector pins for disconnection and the harnesses for breaks.
5. Check the LCF PWA and PFC PWA for short-circuits and breaks.
6. Replace the LCF PWA.
7. Replace the PFC PWA.

YES

Is the LCF tray-up sensor working? (using the test mode 04, Sensor Test, DATA No. 18 Bit 2.)

NO


1. Check the connector of the LCF tray-up sensor for disconnection.
2. Check the connectors CN100, CN104 and CN105 on the LCF PWA for disconnection.
3. Check the connector CN206 on the PFC PWA for disconnection.
4. Check if the slit reaches the LCF tray-up sensor.
5. Check the connector pins for disconnection and the harnesses for breaks.
6. Check the LCF PWA and PFC PWA for short-circuits and breaks.
7. Replace the LCF tray-up sensor.
8. Replace the LCF PWA.
9. Replace the PFC PWA.

YES


1. Check the PFC PWA for short-circuits and breaks.
2. Replace the PFC PWA.

C19 LCF end fence motor is abnormal

Is the end fence working? (using the test mode 10, Output Test, CODE268.)




Are the end fence stop position sensor and end fence home position sensor working? (using the test mode 04, Sensor Test, DATA 18 Bit 6 & 7.)



1. Check the PFC PWA for short-circuits and breaks.
2. Replace the PFC PWA.

4.1.10 Optical system service call

C21 Carriage initialization error



C25 Scanner unit watch dog error

This error occurs when the watchdog register fails to be cleared within every certain time interval on the scanner control PWA (occurrence of a watchdog interrupt).

If C25 still occurs even after the power is turned off and then on, replace the scanner control PWA.

C26 Peak detection error

Does the lamp light up during initialization after the power is turned on?

NO (=The lamp does not light)

1. Check if the connector of the lamp is disconnected, or the harness is broken.
2. Check if the connector of the inverter is disconnected, or the harness is broken.
3. Check if any conductor pattern on the inverter and scanner control PWA is open- or short-circuited.
4. Replace the lamp.
5. Replace the inverter.
6. Replace the scanner control PWA.
7. Replace the relay PWA.
8. Replace the main PWA.

YES (=The lamp lights)

1. Check if the shading plate behind the document scale is dirty.
2. Check if the lens can be seen when looking the first carriage from the top.
3. Check if the optical system is extremely dirty or damaged.
4. Check if the FFC of the CCD PWA is disconnected.
5. Check if any conductor pattern on the CCD and scanner control PWA is open- or short-circuited.
6. Replace the CCD unit.
7. Replace the scanner control PWA.
8. Replace the relay PWA.
9. Replace the main PWA.

4.1.11 Process system service call

C38 Replaced process unit error

Replace the relay PWA.

Replace the main PWA.

4.1.12 Fuser system service call

C41 Abnormality of the thermistor or heater disconnection when the power is turned on

Note: To prevent the danger, the following 1 and 2 should be done after the power-cord plug is unplugged.

1. Check the thermistor.

- (1) Is the connector between the heater thermistor 1/2 and the relay PWA (CN44) disconnected?
- (2) Is the harness of the heater thermistor 1/2 broken?
- (3) Is the connector pin removed?
- (4) Does the heater thermistor 1/2 connect to the heat roller firmly?

2. Check the heater lamp

- (1) Is the heater lamp broken?
- (2) Is the connector between the heater lamp and the PSU (CN3) disconnected?
- (3) Is the heater thermostat open?
- (4) Is the switching power supply broken?

3. Check the relay PWA.

- (1) Is the connector CN44 disconnected?
- (2) Is the connector pin removed?
- (3) Is there a circuit abnormality, such as open or short circuit?
- (4) Replace the relay PWA.

4. Reset the status counter

- (1) The following processes are carried out after completing repair of the cause for the C41 error message.
- (2) Press the [0] and [8] keys simultaneously to turn on the power.
- (3) Input 400 using the numeric keys, and press the start key.
- (4) Change the displayed status counter from [2] to [0], and press the SET key (Reset C41).
- (5) Turn the power on again, and check that it returns to the normal standby mode.

C43 Thermistor abnormal

C44 Heater disconnection

1 - 3 is the same check as for the C41.

With 4, the displayed status counter for the C43 is [4] or [6], and the displayed status counter for the C44 is [5], [7], or [9] so change these displayed status counters to [0] using the same procedure as for C41.

C45 Thermistor 2 abnormality

1. Check the thermistor 2

- (1) Is the connector between the heater thermistor 2 and the relay PWA (CN44) disconnected?
- (2) Is the harness of the heater thermistor 2 broken?
- (3) Is the connector pin removed?
- (4) Does the heater thermistor 2 connect to the heat roller firmly?

2. Check the relay PWA

- (1) Is the connector CN44 disconnected?
- (2) Is the connector pin removed?
- (3) Is there a circuit abnormality, such as open or short circuit?
- (4) Replace the relay PWA.

3. Reset the status counter

Change the status counter from 8 to 0 using the same procedure as for C41.

4.1.13 Communications system service call

C56 Communications error between the PFC and the CPU on the main PWA

- 1. Check if the connector CN36 or CN35 on the relay PWA is disconnected.
- 2. Check if any conductor pattern (PFRXD, PFREQ, PFACK, MACK/PF, PFTXD, or MREQ/PF between the IC, IC2 and CN36) on the relay PWA is open- or short-circuited.
- 3. Replace the relay PWA.
- 4. Replace the PFC PWA.
- 5. Replace the main PWA.

C57 Communication error between the IPC PWA and the CPU on the main PWA

1. Check the circuit patterns on the main PWA for short-circuits and breaks.
2. Check the IPC PWA for short-circuits and breaks.
3. Replace the IPC PWA.
4. Replace the main PWA.


C58 Communication error between the IPC PWA and the finisher

1. Check if the specified finisher is attached.
2. Check the IPC PWA for short-circuits and breaks.
3. Check if the pin of the connector being connected to the connector J2 on the IPC PWA is disconnected or the harness is breaking.
4. Check if the fuse F3 of the power supply unit is blown.
5. Check the control PWA in the finisher for short-circuits and breaks.
6. Check the connections between the finisher and copier if the connector pins are disconnected, or the harnesses are breaking.
7. Replace the IPC PWA.
8. Replace the main PWA.

4.1.14 ADF or RADF system service call

C71 RADF DC motor lock error

Is the RADF DC motor working (forward/reverse)? (using the test mode 10, Output Test, CODE 281/282)



C73 RADF EEPROM initialization error


1. Check if any conductor pattern (IC12 and surrounding area) on the RADF PWA is open- or short-circuited.
2. Replace the RADF PWA.

C74 RADF SB sensor adjustment error

1. Check there are any foreign obstacles between the sensor and the reflection mirror.
2. Check if the sensor or mirror is dirty.
3. Check if each connector between the RADF SB sensor and the RADF PWA (CN4) is disconnected.
4. Check if each connector between the RADF PWA and the scanner control PWA (CN6) is disconnected.
5. Check if each connector between the scanner control PWA (CN4) and the main PWA (CN8) is disconnected.
6. Check if each connector pin is removed or the harness is broken.
7. Check if any conductor pattern on the RADF, scanner control and main PWA is open- or short-circuited.
8. Replace the RADF SB sensor.
9. Replace the RADF PWA.
10. Replace the scanner control PWA.
11. Replace the main PWA.

C81 RADF fan motor error

Is the motor working? (using the test mode 10, Output Test, CODE 298)



C82 Read Sensor Adjustment Error (ADF/RADF)

(ADF)

1. Check there are any foreign obstacles between the read sensor and the reflection mirror.
2. Check if the read sensor or reflection mirror is dirty.
3. Check if each connector between the read sensor and the ADF PWA (CN4) is disconnected.
4. Check if each connector between the ADF PWA (CN1) and the scanner control PWA (CN6) is disconnected.
5. Check if each connector between the scanner control PWA (CN4) and the main PWA (CN8) is disconnected.
6. Check if each connector pin is removed or the harness is broken.
7. Check if any conductor pattern on the ADF, scanner control and main PWA is open- or short-circuited.
8. Replace the read sensor.
9. Replace the ADF PWA.
10. Replace the scanner control PWA.
11. Replace the main PWA.

(RADF)

1. Check there are any foreign obstacles between the read sensor and the reflection mirror.
2. Check if the read sensor or reflection mirror is dirty.
3. Check if each connector between the read sensor and the RADF PWA (CN6) is disconnected.
4. Check if each connector between the RADF PWA and the scanner control PWA (CN6) is disconnected.
5. Check if each connector between the scanner control PWA (CN4) and the main PWA (CN8) is disconnected.
6. Check if each connector pin is removed or the harness is broken.
7. Check if any conductor pattern on the RADF, scanner control and main PWA is open- or short-circuited.
8. Replace the read sensor.
9. Replace the RADF PWA.
10. Replace the scanner control PWA.
11. Replace the main PWA.

C83 Original length sensor adjustment error

1. Check there are any foreign obstacles between the original length sensor and the reflection mirror.
2. Check if the original sensor or reflection mirror is dirty.
3. Check if each connector between the original length sensor and the RADF PWA (CN3) is disconnected.
4. Check if each connector between the RADF PWA and the scanner control PWA (CN6) is disconnected.
5. Check if each connector between the scanner control PWA (CN4) and the main PWA (CN8) is disconnected.
6. Check if each connector pin is removed or the harness is broken.
7. Check if any conductor pattern on the RADF, scanner control and main PWA is open- or short-circuited.
8. Replace the original length sensor.
9. Replace the RADF PWA.
10. Replace the scanner control PWA.
11. Replace the main PWA.

4.1.15 Other abnormal service call

C91 SRAM abnormality

1. Turn the main switch OFF. Perform the RAM clear ([1] [3] [*] + ON).
2. If C91 appears again after the RAM clear, go to step 3.
3. Confirm that the J1 short pin on the main PWA is inserted properly into the pin 1 side.
4. When the power is off, check that the voltage of the lithium battery (SY1) is 2.4V or more.
5. When the power is off, check that the SRAM backup voltage is 2.0V or more.
(Between IC58 or pin 14 (GND) of IC74 and pin 28 (+5VB))
6. Replace the lithium battery (SY1).
7. Replace the main PWA.

C95 Power supply unit fan motor abnormality

1. Check if each connector between the power supply unit fan motor and the relay PWA (CN50) is disconnected.
2. Check if each connector between the relay PWA (CN21) and the main PWA (CN15) is disconnected.
3. Check if each connector pin is removed or the harness is broken.
4. Check if any conductor pattern on the relay and main PWA is open- or short-circuited.
5. Replace the power supply unit fan motor.
6. Replace the relay PWA.
7. Replace the main PWA.

C96 Process unit fan motor abnormality


1. Check if each connector between the process unit fan motor and the relay PWA (CN50) is disconnected.
2. Check if each connector between the relay PWA (CN21) and the main PWA (CN15) is disconnected.
3. Check if each connector pin is removed or the harness is broken.
4. Check if any conductor pattern on the relay and main PWA is open- or short-circuited.
5. Replace the process unit fan motor.
6. Replace the relay PWA.
7. Replace the main PWA.

C97 Vacuum fan motor abnormality

1. Check if each connector between the paper guide assembly and the relay PWA (CN34) is disconnected.
2. Check if each connector between the relay PWA (CN21) and the main PWA (CN15) is disconnected.
3. Check if each connector pin is removed or the harness is broken.
4. Check if any conductor pattern on the relay and main PWA is open- or short-circuited.
5. Replace the paper guide assembly.
6. Replace the relay PWA.
7. Replace the main PWA.


C98 Clock IC abnormality

Is the service call generated even if the switch of the body is turned off and on again?



C99 PFC microcomputer abnormality

Is the service call generated even if the switch of the body is turned on again?



4.1.16 Laser optical system service call

CA1 Polygon motor abnormality


1. Check if each connector between the laser scanner unit and the relay PWA (CN26) is disconnected.
2. Check if each connector pin is removed or the harness is broken.
3. Check if any conductor pattern on the relay and main PWA is open- or short-circuited.
4. Replace the relay PWA.
5. Replace the main PWA.
6. Replace the laser scanner unit.

CA2 HSYNC abnormality


1. Check if each connector between the laser scanner unit and the main PWA (CN18) is disconnected.
2. Check if each connector pin is removed or the harness is broken.
3. Check if any conductor pattern on main PWA is open- or short-circuited.
4. Replace the main PWA.
5. Replace the laser scanner unit.

4.1.17 Finisher related service call


CB2 Delivery motor is abnormal




CB5 Staple motor is abnormal




CC8 Front jogging motor is abnormal




CC9 Upper stack tray lift motor is abnormal



CCA Lower stack tray lift motor is abnormal



CCB Rear jogging motor is abnormal



4.1.18 Scanner related service call

F11 Scanner I/F error


1. Check if each connector between the scanner control PWA (CN6) and the main PWA (CN8) is disconnected.
2. Check if each connector pin is removed or the harness is broken.
3. Check if any conductor pattern on the scanner control and main PWA is open- or short-circuited.
4. Replace the scanner control PWA.
5. Replace the main PWA.

F12 Scanner unit program download write error

F13 Scanner unit program download sector error

1. Check if the recovery ROM PWA is firmly connected to the scanner control PWA (CN3).
2. Check if the connector pin is removed.
3. Check if any conductor pattern on the scanner control PWA is open- or short-circuited.
4. Replace the scanner control PWA.

F14 Scanner unit FROM error



4.1.19 Printer related service call

F21 Printer PWA memory error

1. Check if the printer PWA is firmly connected to the main PWA (CN5).
2. Check if the connector pin is removed.
3. Check if any conductor pattern on the main PWA is open- or short-circuited.
4. Replace the main PWA

F22 Printer PWA NV-RAM error

Replace the Printer PWA.

4.1.20 Fax related service call

F31 Modem IC abnormality

1. Check if the Fax PWA is firmly connected to the main PWA (CN6).
2. Check if the connector pin is removed.
3. Check if any conductor pattern on the Fax and main PWA is open- or short-circuited.
4. Replace the Fax PWA.
5. Replace the main PWA

4.1.21 OCT system service call

F41 Initial detection error of the offset tray

1. Check if each connector between the OCT motor and the OCT PWA (CN261) is disconnected.
2. Check if each connector between the OCT PWA (CN261) and the relay PWA (CN41) is disconnected.
3. Check if each connector pin is removed or the harness is broken.
4. Check if any conductor pattern on the OCT, relay and main PWA is open- or short-circuited.
5. Replace the OCT motor.
6. Replace the OCT PWA.
7. Replace the relay PWA.
8. Replace the main PWA.

4.1.22 Other service call

Error message “Set process unit” is re-displayed

1. Check if each connector between the relay PWA (CN54) and the DEV. motor assembly (terminals) is disconnected.
2. Check if the harnesses have been connected to the designated terminals of DEV. motor assembly correctly. (Refer to Chapter 12.6 of the Service Manual)
3. Check if each connector pin is removed or the harness is broken.
4. Replace the relay PWA.
5. Replace the main PWA.

Error message “Broken Registration” is re-displayed

This error occurs when an error is found on the phonebook data stored in the flash ROM (IC50) on the main PWB or the machine is failed to read the phonebook data correctly.

1. Turn the main switch OFF. Perform the RAM clear ([1] [3] [*] + ON).

Warning: Before performing the RAM clear, press the [CLEAR/STOP] key to clear the error and print out the TELEPHONE NUMBER LIST, FUNCTION LIST, and FUNCTION LIST FOR MAINTENANCE.

2. Set the functions and program the dial numbers according to the list printed out.
3. If the error persists, replace the main PWA.


4.2 Troubleshooting of Image

(1) Uneven pitch and blur

<Symptoms>


Condition	Location	Phenomenon
All modes	Occurs cyclically at right angles to paper feeding direction	Uneven pitch

Feeding
direction




Defect area	Step	Cause		
		Main-Classification	Sub-Classification	Specific-Classification
—	1	—	—	—
Abnormal paper transport speed	2	Paper transport speed in registration section	Low speed	Registration roller aging change
			Low speed	Registration roller life worn out
Drum drive system	3	Drum	Surface condition	—
				Damage
				Attached foreign matter
	4	Main drive gear assembly	Installation condition	—
		Drum Drive Gear	Damaged	—
			Deformation	—
Laser scanner unit	5	Polygonal mirror	Surface inclined	Deformation

	Check item	Criteria	Measures
	Output built-in halftone pattern on A3/LD. (Code 109)	Perform following procedures from 2 and after.	—
	—	—	Clean rubber roller. Surface with alcohol or replace it with new one.
	Check condition of registration rubber roller surface.	Does the roller surface lack in friction and is it slippery?	Replace registration roller.
	Check pattern.	Uneven pitch approx. 94 mm overall?	—
	Check drum surface.	Is there damage?	Replace process unit or drum.
	Check drum surface.	Is there any attached foreign matter?	Clean drum, replace process unit or drum.
	Check pattern.	Uneven pitch approx. 2.4 mm overall?	Reinstall main drive gear assembly properly.
	Check pattern.	—	Replace drum drive gear.
	Check pattern.	—	Replace drum drive gear.
	Check pattern.	Uneven pitch approx. 0.3 mm overall?	Replace unit.




(3) Blank copy




Step	Cause/Defect area	Check items	Measures
1	Transfer charger unit	Transfer charger unit securely installed?	Re-install transfer charger unit securely.
2		Transfer charger wire cut off?	Replace transfer charger unit.
3	Process unit (terminals)	Drum ground terminals/developing bias terminals and corresponding terminals of main body stained?	Clean drum ground terminals, developing bias terminals and corresponding terminals of main body.
4	Process unit drive system	Is sleeve gear and agitator gear driven when main motor is manually rotated clockwise?	If any is damaged, replace process unit or damaged part.
5		Is drum coupling driven when main motor is manually rotated clockwise?	If any is damaged, replace process unit or damaged part.
6	Process unit deformation	Process unit deformed?	Replace process unit.
7	Laser scanner unit	Foreign matter or stain on lens?	Remove foreign material or stain with blower. (Do not use a cloth.)
8	HVPS (transfer charger and developer bias)	High-voltage output defective?	Adjust output from HVPS, or replace defective HVPS.
9		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in right column.	Replace process unit, laser scanner unit, HVPS or main PWA.

(4) Solid copy




Step	Cause/Defect area	Check items	Measures
1	Process unit installation	Process unit securely installed?	Re-install process unit securely.
2	Process unit (main charger)	Charger wire terminals/grid terminals (process unit) and corresponding terminals (main body) stained?	Clean terminals.
3		Is there any disconnection in the charger wire?	Replace the process unit or charger wire.
4	HVPS (main charger)	High-voltage output defective?	Adjust output from HVPS, or replace defective HVPS.
5		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in right column.	Replace the process unit, laser scanner unit, HVPS, or main PWA.

(5) White banding (in feeding direction)




Step	Cause/Defect area	Check items	Measures
1	Paper feed path	Does toner image touch foreign matter after separation, before entering fuser unit.	Remove the foreign matter.
2	Laser scanner unit	Foreign matter or dust on lens?	Remove the foreign matter or dust with blower. (Do not use a cloth.)
3		Is there a foreign matter blocking off laser beam in the path?	Remove the foreign matter.
4	Transfer charger unit	Does a foreign material or stain adhere to the transfer wire?	Clean the wire, or remove the foreign matter.
5		Transfer charger wire slacked?	Replace the transfer charger unit.
6		Transfer charger case deformed?	Replace the transfer charger unit.
7	Process unit (Magnetic roller)	White banding on the magnetic roller? (Is there a foreign matter between the magnetic roller and doctor blade?)	Clean the area between the magnetic roller and doctor blade with the doctor blade cleaning jig.
8	Process unit (Doctor blade)	Is the doctor-sleeve gap within the specified value?	Adjust the doctor-sleeve gap. If the problem persists, replace the doctor blade.
9	Process unit (Drum)	Any abnormalities on drum surface?	If the problem persists, replace process unit or drum. Note: Never touch drum surface.
10		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in the right column.	Replace the process unit, laser scanner unit, or transfer charger unit.

(6) White banding (at right angles to feeding direction)




Step	Cause/Defect area	Check items	Measures
1	Process unit (developer)	Developing bias terminals (process unit) and corresponding terminals (main body) stained?	Clean terminals.
2	Transfer charger unit	Transfer charger unit securely installed?	Re-install transfer charger unit securely.
3		Transfer charger wire terminals and corresponding terminals stained?	Clean terminals.
4		Is guide roller stained or rotating improperly? Guide roller stained or rotating improperly? Guide roller shaft grounded improperly?	Clean guide roller. Ground shaft properly. When guide roller rotates improperly, replace transfer charger unit.
5	Process unit (drum)	Any abnormalities on drum surface?	Replace process unit or drum.
6	Fuser unit	Toner on heat roller surface? Scratches on heat roller surface?	Clean heat roller. If problem persists, replace heat roller.
7	Gear and roller	Check each gear or roller for paper feed and transport is damaged?	Replace defective gear or roller.
8	HVPS (main charger, transfer charger and developer bias)	High-voltage output defective?	Adjust output from HVPS, or replace defective HVPS.
9		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in right column.	Replace process unit or transfer charger unit.

(7) Black banding (in feeding direction)




Step	Cause/Defect area	Check items	Measures
1	Scanner	Foreign matter in optical path?	Clean slit, lens and mirrors.
2	Process unit	Main charger wire stained?	Clean charger wire.
3	(main charger)	Foreign matter on grid?	Remove foreign matter.
4		Grid dirty or deformed?	Clean grid, replace process unit or grid.
5	Process unit (Drum)	Scratches on drum surface?	Replace process unit or drum.
6	Fuser unit	Dirt or scratches on heat roller surface?	Clean or replace heat roller?
7		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in right column.	Replace process unit or fuser unit.

(9) White Spots




Step	Cause/Defect area	Check items	Measures
1	Transfer charger unit	Foreign matter on guide roller?	Clean guide roller.
2		Guide roller shaft grounded improperly?	Ground guide roller shaft properly by applying conductive oil.
3		Transfer charger wire slacked?	Replace transfer charger unit.
4		Transfer charger case deformed?	Replace transfer charger unit.
5	Process unit (drum)	Any abnormalities on drum surface?	Replace process unit or drum.
6	Fuser unit	Toner on heat roller surface? Scratches on heat roller surface?	Clean heat roller. If problem persists, replace heat roller.
7	Process unit (Developer)	Is toner running short?	Check to see toner sensor works properly, and then check toner replenishing procedure.
8	HVPS (main charger/ developer bias/transfer charger)	High-voltage output defective?	Adjust output from HVPS, or replace defective HVPS.
9		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in right column.	Replace process unit, transfer unit, fuser unit, or HVPS.

(10) Uneven image density




Step	Cause/Defect area	Check items	Measures
1	Paper	Paper in cassette or LCF damp?	Change paper. Avoid storing paper in damp place.
2	Laser scanner unit	Foreign matter or dust on lens?	Remove foreign matter or dust with blower. (Do not use a cloth.)
3	Process unit (main charger)	Main charger wire stained?	Clean charger wire.
4	Process unit (developer)	Is toner put in process unit in an unbalanced manner?	Shake process unit horizontally to place toner evenly.
5	Transfer charger unit	Transfer charger unit securely installed?	Re-install transfer charger unit securely.
6		Transfer charger wire dirty?	Clean transfer charger wire.
7		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in right column.	Replace process unit, transfer charger unit, or laser scanner unit.

(11) Blotched image




Step	Cause/Defect area	Check items	Measures
1	Paper	Paper too thin?	Change paper.
2		Paper too dry?	Change paper.
3	Transfer charger unit	Transfer charger case dirty?	Clean case.
4		Transfer charger wire dirty?	Clean wire.
5	HVPS (transfer/separation charger)	High-voltage output defective?	Adjust output from HVPS, or replace defective HVPS.
6		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in right column.	Replace process unit.

(12) Poor image transfer




Step	Cause/Defect area	Check items	Measures
1	Paper	Paper in cassette or LCF curled?	Reinsert paper with reverse side up or change paper.
2		Paper in cassette or LCF damp?	Change paper. Avoid storing paper in damp place.
3	Transfer charger	Transfer charger case dirty?	Clean transfer charger case.
4		Transfer charger wire dirty?	Clean transfer charger wire.
5	Registration roller	Registration roller malfunctioning?	Clean roller, or replace defective clutch-related parts.
6	Pinch roller	Pinch roller spring out of place?	Re-mount or replace spring.
7	HVPS (transfer/separation charger/guide bias)	High-voltage output defective?	Adjust output from HVPS, or replace defective HVPS.
8		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in right column.	Replace process unit, laser scanner unit, or the transfer unit.

(13) Poor cleaning




Step	Cause/Defect area	Check items	Measures
1	Process unit (drum)	Scratches on drum surface?	Replace process unit or drum.
2	Cleaning roller	Cleaning roller damaged or their life ended?	Replace cleaning roller.
3	Heat roller	Bubbles on heat roller (94 mm pitch on copy)?	Replace heat roller. Check and fix heater control circuit.
4		Heat roller life ended?	Replace heat roller.
5		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in right column.	Replace the process unit or the fuser unit.

(14) Faded image (low density, abnormal gray balance)




Step	Cause/Defect area	Check items	Measures
1	Toner empty	"ADD TONER" symbol flashing?	Replace toner cartridge.
2	Transfer charger unit	Transfer charger unit securely installed?	Re-install transfer charger unit securely.
3		Transfer charger wire cut off?	Replace transfer charger unit.
4	Process unit drive system	Is auger gear of process unit driven when the PU pulley is manually rotated clock wise?	Replace process unit.
5	Toner cartridge	Any abnormalities in toner cartridge?	Replace toner cartridge.
6	Process unit (developer)	Magnetic roller pressure mechanism working normally?	Check mechanism.
7	Process unit (main charger)	Main charger dirty?	Clean main charger wire, replace process unit or charger wire.
8	Process unit (drum)	Film formed on drum surface?	If problem persists, replace process unit or drum. Note: Never touch drum surface.
9	DEV. motor assembly (terminal)	Have harnesses been connected to designated terminals of DEV. motor assembly correctly? (Refer to chapter 12.6 of Service Manual.)	Re-install the harness.
10	HVPS	High-voltage output defective?	Adjust output from HVPS, or replace defective HVPS.
11		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in right column.	Replace process unit or transfer charger unit.

(15) Background Fogging




Step	Cause/Defect area	Check items	Measures
1	Density reproduction	Image density reproduction defect?	Adjust density.
2	Main charger	Main charger dirty?	Clean main charger wire, replace process unit or charger wire.
3	Process unit (developer)	Magnetic roller pressure mechanism working normally?	Check mechanism.
4	Process unit (drum)	Film formed on drum surface?	If problem persists, replace process unit or drum. Note: Never touch drum surface.
5	HVPS (main charger/ developer bias/ transfer charger)	High-voltage output defective?	Adjust output from HVPS, or replace defective HVPS.
6		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in right column.	Replace process unit.

(16) Toner offset




Step	Cause/Defect area	Check items	Measures
1	Density	Density too high?	Adjust density.
2	Paper	Recommended paper used?	Use recommended paper.
3	Fuser	Fuser unit ground place damaged?	Replace ground plate.
4		Scratch on heat roller surface?	Replace heat roller.
5		Heat roller life ended?	Replace heat roller.
6		Heat roller temperature proper?	Check heater control circuit.
7		If problem persists after measures are applied, or there is no problem found in above check, follow procedure described in right column.	Replace process unit or heat roller.

(17) Poor fusing




Step	Cause/Defect area	Check items	Measures
1	Paper	Paper dump?	Change paper.
2	Fuser unit	Pressure springs working normally?	Check mechanism.
3		Heat roller temperature too low?	Check heater control circuit.
4		If problem persists after measures are applied, or there is no problem found in the above check, follow procedure described in right column.	Replace process unit or fuser unit.

(18) Defect of image density/Gray balance



Step	Cause/Defect area	Check items	Measures
1	Density/Gray balance	Check density/gray balance.	Adjust density.
2	Printer section	Check test print image (Code 113).	Go to step 4 if there is any problem on image.
3	Scanner	Original glass, mirrors or lens filter dirty?	Clean them.
4	Printed image	Is there any faded image (low density)?	Perform troubleshooting for faded image.
		Is there any fog in background?	Perform troubleshooting for background fogging.
		Is there any blotch image?	Perform troubleshooting for blotch image.
		Is there any transfer defect?	Perform troubleshooting for poor fusing.

(19) Moire/lack of sharpness




Moire

Step	Cause/Defect area	Check items	Measures
1	Density reproduction	Image density reproduction defect?	Adjust density.
2	Parameter adjustment value	Check image processing parameters.	Check adjustment value for sharpness.

Lack of sharpness


Step	Cause/Defect area	Check items	Measures
1	Density reproduction	Image density reproduction defect?	Adjust density.
2	Parameter adjustment value	Check image processing parameters.	Check adjustment value for sharpness.
3	Print section	Adjust image processing parameters.	Check the above encircled area A and B, and change the sharpness intensity in the sharpness adjustment mode.

(20) Uneven light distribution



Step	Cause/Defect area	Check items	Measures
1	Original glass	Original glass dirty?	Clean glass.
2	Process unit (main charger)	Main charger wire dirty?	Clean main charger wire, replace process unit or charger wire.
3	Laser scanner unit	Foreign matter or dust on lens?	Remove foreign matter or dust with blower. (Do not use a cloth)


(21) Skew (inclined image)



Moire


Step	Cause/Defect area	Check items	Measures
1	Cassette/LCF	Cassette or LCF properly installed?	Re-install cassette or LCF properly.
2		Too much paper loaded in cassette or LCF?	Reduce paper to 550 sheets or less. (1250 sheets each or less for LCF.)
3		Paper in cassette or LCF curled?	Reinsert paper with reverse side up or change paper.
4		Cassette or LCF side guides properly installed?	Adjust side guide.
5	Paper feed roller	Paper feed roller dirty?	Clean roller surface with alcohol, or replace roller.
6	Registration roller	Registration roller dirty?	Clean roller surface with alcohol, or replace roller.
7	Pinch roller	Pinch roller spring out of place?	Re-mount or replace spring.
8	Paper guide	Paper guide improperly mounted?	Re-install paper guide securely.
9	Original scale	Original scale slanted?	Adjust original scale.
10	Carriage 1	Carriage 1 slanted?	Adjust carriage 1

(22) Image dislocation in feeding direction



Step	Cause/Defect area	Check items	Measures
1	Registration roller	Registration roller dirty?	Clean roller surface with alcohol, or replace roller.
2	Pinch roller	Pinch roller spring out of place?	Re-mount or replace spring.
3	Paper guide	Paper guide improperly mounted?	Re-install paper guide.
4	Scanner/printer adjustment defect	Same dislocation on every copy?	Adjust scanner/printer using adjustment mode.

(23) Jittering image



Step	Cause/Defect area	Check items	Measures
1	—	Toner image paper on drum normal?	If normal, perform step 2 to 4. Otherwise perform step 5 and after.
2	Registration roller	Registration roller dirty?	Clean roller surface with alcohol, or replace roller.
3	Pinch roller	Pinch roller spring out of place?	Re-mount or replace spring.
4	Heat roller	Heat roller rotation defective?	Check heat roller drive system. Replace gear or roller if necessary.
5	Process unit (Drum gear, cleaner paddle drive gear, toner recovery auger drive gear)	Foreign matter or toner on gears?	Clean gears.
6	Process unit (Drum)	Large scratch on drum?	Replace process unit or drum.
7	Carriage operation	Slider sheet defective?	Replace slider sheet.
8		Any abnormalities on carriage feet?	Replace feet.
9		Tension of timing belt inappropriate?	Adjust the tension.
10		Carriage drive system malfunctioning?	Check carriage drive system.
11	Scanner	Mirror loosely mounted?	Fix mirror properly.
12		Wire and timing belt tension proper?	Re-install wire and timing belt with jig.
13	Drum drive system	Drum drive system malfunctioning?	Clean or replace gears if they have stain or scratches.
14	Main drive gear assembly	Main drive gear assembly improperly mounted?	Re-install main drive gear assembly with jig.

5. UPDATING THE FIRMWARE

5.1 Outline

When you want to use the latest version of the firmware, or when the firmware is damaged and the copier is inoperable, the following procedure is used to update the firmware.

The firmware contains two types of data: Main Data (program data/function data/language data) stored in the flash ROM on the main PWA, and Scanner Data stored in the flash ROM on the scanner control PWA.

The updating procedures vary with the data types. For details, refer to each procedure.

- Important:**
- Before updating, be sure to print "FUNCTION LIST." In case the updating fails for some reason disabling this machine from operating, set the functions by checking with this list and then restore the machine.
 - If updating is performed with the FAX kit (GD-1061) installed, the communication journal data, communication error history data, communication protocol data, and job data will be erased. Before updating, check that there is no job data and print each list of communication journal data, communication error history data, and communication protocol data if necessary.

Downloading data from the recovery PWA.

→ Refer to 5.2 Using the recovery PWA (on page 5-2).

Using the batch file of the MS-DOS, downloading data from the PC.

→ Refer to 5.3 Using the batch file (on page 5-8).

Using the TOSHIBA Viewer, downloading data from the PC.

→ Refer to 5.4 Using the TOSHIBA Viewer (on page 5-20).

Using the RDC (Remote Diagnosis Configuration), downloading data.

* The GD-1061 (FAX kit: Option) is required.

→ Refer to the RDC Manual.

Note: The version of the firmware currently installed can be confirmed in the "FUNCTION LIST (In SERVICE MODE)."

5.2 Using the Recovery PWA


Downloading procedures differ with the main data and the scanner data. Refer to the following sections:

- Main data: → 5.2.1 Using the main recovery PWA (this page)
- Scanner data: → 5.2.2 Using the scanner recovery PWA (on page 5-5)

5.2.1 Using main recovery PWA

Important: While downloading, do not turn off the power of the copier. Data may be damaged, causing the copier not to operate normally.

- (1) On the main recovery PWA, install the ROM that stores data for the update.
Closely follow the ROM installation direction.



05-02-01

Fig 5-2-1

- (2) Turn off the power.
- (3) Remove the rear cover.




Fig 5-2-2

05-02-02-1

- (4) Insert the main recovery PWA into CN10 of the main PWA, with the ROM mounting side facing down.




Fig 5-2-3


05-02-03

- (5) Turn on the power.


Downloading of the main data starts.

The downloading status is displayed on the LCD of the copier as follows:


- Data is being downloaded from the ROM on the recovery PWA to the DRAM on the main PWA.
The number of displayed squares (■) increases.



- Data is being stored in the flash ROM from the DRAM.
The number of displayed squares (■) decreases.



- Downloading is completed.
All dots are blinking.



Note: It takes approx. 5 minutes to download the main data.

(6) Turn off the power.

(7) Remove the main recovery PWA and attach the rear cover.

Important: Only when the main data is downloaded after changing the main PWA.

In such a case, follows the step (a) through (g) described below.

(a) Holding down the [0] and [8] keys, turn on the power.

The copier enters the System mode.

(b) Enter "388" using the numeric keys and press the [SET]/[START] key.

The total counter value is baked up.

(c) Turn off the power.

(d) Holding down the [1], [3] and [*] keys, turn on the power and wait until "Please wait" message is displayed.

(e) Turn off the power.

(f) Holding down the [1], [3] and [#] keys, turn on the power and wait until "Please wait" message is displayed.

(g) Turn off the power.

(8) Holding down the [*], and [#] keys, turn on the power and wait until "Please wait" message is displayed.
The memory is cleared.


Important: After downloading the data, perform memory clear by turning the power ON while holding down the [*] and [#] keys. This machine may not operate normally if this operation is not performed. Also, if memory clear is performed by any operation other than the above, the function setting data, user setting data, etc. may be erased. Do not perform any memory clear operation other than the above.

(9) Turn off the power.

5.2.2 Using the scanner recovery PWA

Important: Do not turn off the power of the copier while downloading. Data may be damaged, causing the copier not to operate normally.


- (1) On the scanner recovery PWA, install the ROM that stores data for the update. Closely follow the ROM installation direction.



05-02-04

Fig 5-2-4


- (2) Turn off the power.
- (3) Open the Original cover (KA-1600PC)/ADF (MR-2012)/RADF (MR-3011).
- (4) Removes the original glass and the original glass stay.



05-02-05

Fig 5-2-5


- (5) Remove the blind plate.



05-02-06-1

Fig 5-2-6

- (6) Insert the main recovery PWA into CN3 of the scanner control PWA, with the ROM mounting side facing outside the copier.



05-02-07-1

Fig 5-2-7

- (7) Turn on the power.

Downloading of the scanner data starts.

The exposure lamp flashes as follows depending on the downloading status.

- The exposure lamp flashes once: Downloading starts.
- The exposure lamp flashes twice: Downloading ends.

Note: It takes approx. 10 to 20 seconds to download the scanner data.

- (8) Turn off the power.

- (9) Remove the scanner recovery PWA.

- (10) Attach the blind plate.

- (11) Attaches the original glass and the original glass stay.

Note: When attaching the original glass and the original glass stay, adjustment is required. For adjusting procedure, refer to the following section:

→ (b) Installing original glass of 1.8.1 Installing glass

Important: When the power is turned ON after completing the updating, an error may occur with "F14" displayed on the LCD. In such a case, follow the steps (12) through (15) described below.

- (12) Turn off the power.

- (13) Holding down the [0] and [8] keys, turn on the power.

The copier enters the System mode.

- (14) Enter "389" using the numeric keys and press the [SET] / [START] key.

The total counter value is backed up.

- (15) Turn off the power.

5.3 Using the Batch File

You can execute the download program from the batch file on MS-DOS and download the firmware into the copier from the PC for update.

This method consists of the following two procedures: "Download Disk Creation" and "Download Run Operation." Once download disks are created, you can update the firmware in more than one copier or other machines to the one of the same latest version simply by performing the download operation using the created download disks.

- Important:**
- The following environment is required to execute the download program.
PC: IBM PC/AT or compatible machine
(Requires a parallel interface conforming to IEEE1284)
OS: MS-DOS or Windows 95/98
Cable: Parallel cable conforming to IEEE1284
 - While the data is being updated, do not turn the copier or PC power OFF, or the data may be destroyed and the copier may fail to operate normally.

5.3.1 Creating Download Disks

For downloading, it is necessary to create "download disks" containing the download program and update data. This procedure requires two blank floppy disks. They should be prepared before following the procedure described below.

- Important:**
- Do not remove the floppy disk from the drive until you are instructed to do so. The disk or drive may be damaged.
 - The download program consists of the following files:
MKRPCDSK.BAT
DISK.EXE

These two files must be stored under the same directory (folder). If they are stored under different directories, the download program cannot be run normally.

Described below is an example where a "work" directory is created under the route directory on drive C and then the program files are stored.

The MS-DOS prompt screen shows the following:

```
C:\work>dir

Volume in drive C has no label
Volume Serial Number is XXXX-XXXX
Directory of C:\work

<DIR>          11-15-00  1:19p .
<DIR>          11-15-00  1:19p ..
DISK      EXE      X,XXX,XXX  XX-XX-XX XX:XX  Disk.exe
MKRPCDSK  BAT      XXX  XX-XX-XX XX:XX  mkrpcdsk.bat
  2 file(s)      X,XXX,XXX bytes
  2 dir(s)      X,XXX,XXX,XXX bytes free

C:\work>
```

05-03-001

- (1) Type “mkrpcdsk” and press the [Enter] key.

```
C:\work>mkrpcdsk
```

05-03-002

The batch file is executed and the download disk creation program is started.

```
Attached the label "xxxxxxx Disk1" to the new diskette and insert
It into the device (For Disk1).
Press any key to continue...
```

05-03-003

- (2) Insert a blank floppy disk (Disk 1) in the drive and press the [Enter] key.

```
Insert new diskette for drive A:
And press ENTER when ready...
```

05-03-004

- (3) Press the [Enter] key.

Formatting of Disk 1 begins.

```
Formatting 1.44M
XX percent completed.
```

05-03-005

When formatting is completed, the following screen appears.

```
Formatting 1.44M
Format complete.
System transferred

Volume label (11 characters, ENTER for none)?
```

05-03-006

(4) Press the [Enter] key.

(5) Type “n” and press the [Enter] key.

```
X,XXX,XXX bytes total disk space
  XXX,XXX bytes used by system
X,XXX,XXX bytes available on disk

      XXX bytes in each allocation unit.
    X,XXX allocation units available on disk.

Volume Serial Number is XXXX-XXXX

Format another (Y/N)? n
```

05-03-007

The download program is copied to Disk 1.

```
Copying files to FDD.

AUTOEXEC. BAT
CONFIG. SYS
FINDRAMD. EXE
POUT16. EXE
RPC. BAT
SETRAMD. BAT
ROM. 01
HIMEM. SYS
RAMDRIVE. SYS
```

05-03-008

When copying to Disk 1 is completed, the following screen appears.

```
Attached the label "xxxxxx Disk2" to the new disk and insert
It into the device (For Disk2).
Press any key to continue...
```

05-03-009

(6) Remove Disk 1 from drive A.

(7) Insert a blank floppy disk (Disk 2) in drive A, press the [Enter] key.

```
Insert new diskette for drive A:  
And press ENTER when ready...
```

05-03-010

(8) Press the [Enter] key.

Formatting of Disk 2 begins.

```
Formatting 1.44M  
XX percent completed.
```

05-03-011

When formatting is completed, the following screen appears.

```
Formatting 1.44M  
Format complete.  
System transferred  
  
Volume label (11 characters, ENTER for none)?
```

05-03-012

(9) Press the [Enter] key.

(10) Type "n" and press the [Enter] key.

```
X,XXX,XXX bytes total disk space  
XXX,XXX bytes used by system  
X,XXX,XXX bytes available on disk  
  
XXX bytes in each allocation unit.  
X,XXX allocation units available on disk.  
  
Volume Serial Number is XXXX-XXXX  
  
Format another (Y/N)? n
```

05-03-013

The download program is copied to Disk 2.

```
Copying files to FDD.
```

```
ROM.02  
SR0M.EXE
```

05-03-014

When copying to Disk 2 is completed, the following screen appears.

```
...  
...  
    2 files have been successfully copied.  
The diskette has been created.  
Press the [Enter] key to terminate.
```

05-03-015

(11) Press the [Enter] key.

Creation of the download disks (Disks 1 and 2) is now completed. Using the created download disks, you can update the firmware in more than one copier or other machines to the one of the same latest version simply by performing the download operation. For the download operating procedure, refer to “5.3.2 Downloading.”

5.3.2 Downloading

Download the firmware by using the download disks (Disks 1 and 2) created in the procedure of “5.3.1 Creating Download Disks”

- Important:**
- The download program cannot be run normally at the MS-DOS prompt after Windows 95/98 is started. Once end Windows, insert the download disk (Disk 1) in the drive, and turn the power ON to directly start the program from the floppy disk.
 - While the data is being updated, do not turn the copier or PC power OFF, or the data may be destroyed and the copier may fail to operate normally.
 - Do not remove the floppy disk from the drive until you are instructed to do so. The disk or drive may be damaged.

(1) Insert the download disk (Disk 1) in the floppy disk drive and turn the PC power ON.

The download menu screen appears.

```
Microsoft Windows 98 Startup Menu

1.Start PC recovery (Main)
2.Start PC recovery (Scanner Unit)
3.Start PC recovery (Main + Scanner Unit)

Enter a choice:1    Time remaining:60
```

05-03-016

(2) Select download data by pressing the [↑] or [↓] key on the PC and press the [Enter] key.

Notes: • The relations between the menu and the data to be downloaded are as follows:

1. Start PC Recovery (Main) → The main data only is downloaded.
 2. Start PC Recovery (Scanner Unit) → The scanner data only is downloaded.
 3. Start PC Recovery (Main + Scanner Unit)
→ Both the main data and scanner data are downloaded.
(The main data is downloaded, followed by the scanner data.)
- If 60 seconds elapse without performing any operation after the download menu is displayed, “1. Start PC recovery (Main)” will be selected automatically.

The necessary files are copied to the temporary area in the PC from Disk 1.

```
Copying to the temporary area.  
1 file(s) copied.  
1 file(s) copied.  
1 file(s) copied.
```


05-03-017

When copying is completed, the following screen appears.

```
Insert the Disk2.  
Press any key to continue.
```

05-03-018


- (3) Remove Disk 1 from the drive and insert Disk 2. Then press any key. The necessary files are copied to the temporary area in the PC from Disk 2.



Copying to the temporary area.
1 file(s) copied.

05-03-019

When copying is completed, the following screen appears.



Turn off the main power of the copier.
By pressing the [2], [*] and [#] keys, turn on the main power
Of the copier.
Connect the parallel cable.
Press any key to continue..

05-03-020

The following operations are different depending on the menu selected in step (2).

When 1. Start PC Recovery (Main) is selected:

→ Refer to "Downloading procedure for main data." (this page)

When 2. Start PC Recovery (Scanner Unit) is selected:

→ Refer to "Downloading procedure for scanner data." (on page 5-17)

When 3. Start PC Recovery (Main + Scanner Unit) is selected:

→ Refer to "Downloading procedure for main data" and "Downloading procedure for scanner data."

Downloading procedure for main data: Steps (4) through (7)

(4) Turn the copier power OFF and connect it to the PC through the parallel cable.

(5) While pressing the [2], [*] and [#] keys on the copier, turn the power ON.

The following appears on the LCD.



- (6) Press any key on the PC.
Downloading of the main data begins.

Screen display on the PC

```
Writing main unit program.  
  
/*****/  
/* PC recovery application */  
/* Copyright (C) Toshiba TEC */  
/*****/
```

05-03-021

LCD display on the copier

Boxes (■) are displayed one by one
(2 rounds).




Boxes (■) are erased one by one.



Important: Some time after downloading begins, the message prompting you to perform the next operation appears on the PC screen. However, downloading is in progress until the LCD of the copier blinks as shown below. Do not perform any operation. Performing any operation during this period may cause the downloading to be discontinued and fail and the copier may not be recovered unless you use the recovery PWA.

Note: The downloading time is about 8 minutes.

When downloading ends, all the dots on the copier LCD will blink.



- (7) After confirming that all the dots on the copier LCD screen are blinking, perform the following operation according to the items in the download menu selected.

When 1. Start PC Recovery (Main) is selected:

→ Proceed to step (11). (on page 5-19)

When 3. Start PC Recovery (Main + Scanner Unit) is selected:

→ The following screen appears on the PC. Thereafter, perform downloading of scanner data by referring to "Downloading procedure for scanner data."

```
Turn off the main power of the copier.  
By pressing the [2], [*] and [#] keys, turn on the main power  
Of the copier.  
Connect the parallel cable.  
Press any key to continue...
```


05-03-022

Downloading procedure for scanner data: Steps (8) through (11)

- (8) Turn the copier power OFF and connect it to the PC through the parallel cable.

- (9) While pressing the [2], [*] and [#] keys on the copier, turn the power ON.

The following appears on the copier LCD.



(10) Press any key on the PC.

Downloading of the main data begins.

Screen display on the PC


```
Writing scanner unit program.

/*****/
/* PC recovery application */
/* Copyright (C) Toshiba TEC */
/*****/
```

05-03-023

LCD display on the copier


Boxes (■) are displayed one by one.



Important: Some time after downloading begins, the message prompting you to perform the next operation appears on the PC screen. However, downloading is in progress until the LCD of the copier blinks as shown below. Do not perform any operation. Performing any operation during this period may cause the downloading to be discontinued and fail and the PC may not be recovered unless you use the recovery PWA.

Note: The downloading time is about 1 minute and 30 seconds.

When downloading ends, all the dots on the copier LCD will blink.



(11) When downloading ends, the following screen appears.

```
Would you like to have the device programmed data into the next
Machine?
YES  — press [Enter]
NO   — press [Ctrl]+C
```

05-03-024

To perform downloading again:

→ Press the [Enter] key and follow the selected menu again.

To update the main data, proceed to step (4). (on page 5-15)

To update the scanner data, proceed to step (8). (on page 5-17)

To terminate the download program:

→ Press the [C] key while pressing the [Ctrl] key and follow step (12) and subsequent.

(12) Press the [Y] key.

```
Terminate batch job (Y/N)?y
```

(13) Turn the copier and PC power OFF.

Only when the main data is downloaded, perform the following operation to clear the memory.

(14) While pressing the [*] and [#] keys on the copier, turn the power ON and wait until "Please wait" message is displayed.

(15) Turn the copier power OFF.

5.4 Using the TOSHIBA Viewer

Using the TOSHIBA Viewer, you can download the firmware from the PC to this copier for updating.

- Important:**
- Data to be downloaded should be stored in the same drive as the TOSHIBA Viewer program. If the data is stored in a different drive (including a floppy disk or the drive of another PC connected to the network), downloading may not be performed normally.
 - Do not turn off the power of the copier and the PC while data is being updated. Data may be damaged causing the copier not to operate normally.

(1) Start the TOSHIBA Viewer, and then Click “Setup” on the main welcome menu.




Fig. 5-4-1

The Toshiba Setup screen appears.

- (2) Double click "Download" in Data sources.




Fig. 5-4-2

The Service setting dialog box appears.

- (3) Enter the password "TSBSERVICE".




Fig. 5-4-3

- (4) Click "OK".

The Download firmware update dialog box appears.

- (5) Select the file for the download firmware.




Fig. 5-4-4

Click "Browse" to select the file to be downloaded.

The selected files are displayed in File.




Fig. 5-4-5

- Notes:**
- The files with the checked boxes are downloaded. Up to four files can be downloaded.
 - The following files should be selected for the banks. Select files according to bank.
 - Bank 1 : Program data
 - Bank 2 : Function data
 - Bank 3 : Language data
 - Bank 4 : Scanner data

When an inappropriate file is selected for the bank, the following message is displayed.
Select the appropriate file.



Fig. 5-4-6

- (6) Click "OK".

Downloading starts and the file that is downloaded is displayed.




Fig. 5-4-7

- Notes:**
- It takes approx. 20 minutes to download the data (when four files are downloaded).
 - The copier is automatically reset while downloading.

When the downloading is completed, the following dialog box is displayed.





Fig. 5-4-8

- (7) Click "OK".



6.3 Connector Table

PWA-F-MAN			
Pin No.	Symbol	Name	Active
1	TX1	FAX transmit data signal	-
2	RX1	FAX receive data signal	-
3	TXCLK	FAX clock control signal	H
4	LD1	LD pulse generate signal	H/Idle make
6	ATX0B1	Non connection	-
7	RD0J1	Return loss adjust signal 1	-
8	RD0J2	Return loss adjust signal 2	-
9	NC	Non connection	-
10	SG	Signal ground	-
11	-12V	Signal ground	-
12	AG	Analog ground	-
13	-12V	Signal ground	-
14	NC	Non connection	-
15	SG	Signal ground	-
16	AG	Analog ground	-
17	NC	Non connection	-
18	ANS0TG	Analog tone detect signal	-
19	REVA1	Line current detect signal	-
20	REVB1	Line current detect signal	-
21	H0OK1	Hook detect signal	L/Off hook H/On hook
22	SVPS	+5V (When Power save mode = Supplied)	-
23	SG	Signal ground	-
24	-12V	Signal ground	-
25	-12V	Signal ground	-
26	SG	Signal ground	-
27	-12V	Signal ground	-
28	NC	Non connection	-
29	NC	Non connection	-
30	NC	Non connection	-

PWA-F-MAN (CN4) ↔ PWA-F-RIF (CN2)			
Pin No.	Symbol	Name	Active
1	PCPWR	ODI gate control signal	N/Open
2	PCPWENA	PC PFI direction signal	L/Up PG H/Down PG
3	PCP0EN	PC PFI0 enable signal	-
4	PCP0F0	PC PFI0 data bus 0	-
5	PCP0F1	PC PFI0 data bus 1	-
6	PCP0F2	PC PFI0 data bus 2	-
7	PCP0F3	PC PFI0 data bus 3	-
8	PCP0F4	PC PFI0 data bus 4	-
9	PCP0F5	PC PFI0 data bus 5	-
10	PCP0F6	PC PFI0 data bus 6	-
11	PCP0F7	PC PFI0 data bus 7	-
12	PCDET	PC PFI0 detect signal	L/Connected
13	PCP0F8	PC PFI0 data bus 8	-
14	NATPO	PC PFI0 nAttoBus/HostAck signal	-
15	NATPI	PC PFI0 nAttoBus/HostAck signal	-
16	2WNIN1	PC PFI0 interrupt signal	-
17	NSELIN	PC PFI0 nSelect1284 active signal	-
18	PCP0F9	PC PFI0 data bus 9	-
19	BUSET	PC PFI0 Busy/PCP0F9/PerfAck signal	-
20	PCP0F10	PC PFI0 data bus 10	-
21	PCP0F11	PC PFI0 data bus 11	-
22	PCP0F12	PC PFI0 data bus 12	-
23	PCP0F13	PC PFI0 data bus 13	-
24	PCP0F14	PC PFI0 data bus 14	-
25	PCP0F15	PC PFI0 data bus 15	-
26	PCP0F16	PC PFI0 data bus 16	-
27	PCP0F17	PC PFI0 data bus 17	-
28	PCP0F18	PC PFI0 data bus 18	-
29	PCP0F19	PC PFI0 data bus 19	-
30	PCP0F20	PC PFI0 data bus 20	-
31	PCP0F21	PC PFI0 data bus 21	-
32	PCP0F22	PC PFI0 data bus 22	-
33	PCP0F23	PC PFI0 data bus 23	-
34	PCP0F24	PC PFI0 data bus 24	-
35	PCP0F25	PC PFI0 data bus 25	-
36	PCP0F26	PC PFI0 data bus 26	-
37	PCP0F27	PC PFI0 data bus 27	-
38	PCP0F28	PC PFI0 data bus 28	-
39	PCP0F29	PC PFI0 data bus 29	-
40	PCP0F30	PC PFI0 data bus 30	-
41	PCP0F31	PC PFI0 data bus 31	-
42	PCP0F32	PC PFI0 data bus 32	-
43	PCP0F33	PC PFI0 data bus 33	-
44	PCP0F34	PC PFI0 data bus 34	-
45	PCP0F35	PC PFI0 data bus 35	-
46	PCP0F36	PC PFI0 data bus 36	-
47	PCP0F37	PC PFI0 data bus 37	-
48	PCP0F38	PC PFI0 data bus 38	-
49	PCP0F39	PC PFI0 data bus 39	-
50	PCP0F40	PC PFI0 data bus 40	-
51	PCP0F41	PC PFI0 data bus 41	-
52	PCP0F42	PC PFI0 data bus 42	-
53	PCP0F43	PC PFI0 data bus 43	-
54	PCP0F44	PC PFI0 data bus 44	-
55	PCP0F45	PC PFI0 data bus 45	-
56	PCP0F46	PC PFI0 data bus 46	-
57	PCP0F47	PC PFI0 data bus 47	-
58	PCP0F48	PC PFI0 data bus 48	-
59	PCP0F49	PC PFI0 data bus 49	-
60	PCP0F50	PC PFI0 data bus 50	-
61	PCP0F51	PC PFI0 data bus 51	-
62	PCP0F52	PC PFI0 data bus 52	-
63	PCP0F53	PC PFI0 data bus 53	-
64	PCP0F54	PC PFI0 data bus 54	-
65	PCP0F55	PC PFI0 data bus 55	-
66	PCP0F56	PC PFI0 data bus 56	-
67	PCP0F57	PC PFI0 data bus 57	-
68	PCP0F58	PC PFI0 data bus 58	-
69	PCP0F59	PC PFI0 data bus 59	-
70	PCP0F60	PC PFI0 data bus 60	-
71	PCP0F61	PC PFI0 data bus 61	-
72	PCP0F62	PC PFI0 data bus 62	-
73	PCP0F63	PC PFI0 data bus 63	-
74	PCP0F64	PC PFI0 data bus 64	-
75	PCP0F65	PC PFI0 data bus 65	-
76	PCP0F66	PC PFI0 data bus 66	-
77	PCP0F67	PC PFI0 data bus 67	-
78	PCP0F68	PC PFI0 data bus 68	-
79	PCP0F69	PC PFI0 data bus 69	-
80	PCP0F70	PC PFI0 data bus 70	-
81	PCP0F71	PC PFI0 data bus 71	-
82	PCP0F72	PC PFI0 data bus 72	-
83	PCP0F73	PC PFI0 data bus 73	-
84	PCP0F74	PC PFI0 data bus 74	-
85	PCP0F75	PC PFI0 data bus 75	-
86	PCP0F76	PC PFI0 data bus 76	-
87	PCP0F77	PC PFI0 data bus 77	-
88	PCP0F78	PC PFI0 data bus 78	-
89	PCP0F79	PC PFI0 data bus 79	-
90	PCP0F80	PC PFI0 data bus 80	-
91	PCP0F81	PC PFI0 data bus 81	-
92	PCP0F82	PC PFI0 data bus 82	-
93	PCP0F83	PC PFI0 data bus 83	-
94	PCP0F84	PC PFI0 data bus 84	-
95	PCP0F85	PC PFI0 data bus 85	-
96	PCP0F86	PC PFI0 data bus 86	-
97	PCP0F87	PC PFI0 data bus 87	-
98	PCP0F88	PC PFI0 data bus 88	-
99	PCP0F89	PC PFI0 data bus 89	-
100	PCP0F90	PC PFI0 data bus 90	-

PWA-F-MAN (CN5) ↔ PWA-F-PCL			
Pin No.	Symbol	Name	Active
1	PCPWR	ODI gate control signal	N/Open
2	PCPWENA	PC PFI0 enable signal	L/Up PG H/Down PG
3	NATPO	PC PFI0 nAttoBus/HostAck signal	-
4	2WNIN1	PC PFI0 interrupt signal	-
5	NC	Non connection	-
6	PCP0F0	PC PFI0 data bus 0	-
7	PCP0F1	PC PFI0 data bus 1	-
8	PCP0F2	PC PFI0 data bus 2	-
9	PCP0F3	PC PFI0 data bus 3	-
10	PCP0F4	PC PFI0 data bus 4	-
11	PCP0F5	PC PFI0 data bus 5	-
12	PCP0F6	PC PFI0 data bus 6	-
13	PCP0F7	PC PFI0 data bus 7	-
14	PCP0F8	PC PFI0 data bus 8	-
15	PCP0F9	PC PFI0 data bus 9	-
16	PCP0F10	PC PFI0 data bus 10	-
17	PCP0F11	PC PFI0 data bus 11	-
18	PCP0F12	PC PFI0 data bus 12	-
19	PCP0F13	PC PFI0 data bus 13	-
20	PCP0F14	PC PFI0 data bus 14	-
21	PCP0F15	PC PFI0 data bus 15	-
22	PCP0F16	PC PFI0 data bus 16	-
23	PCP0F17	PC PFI0 data bus 17	-
24	PCP0F18	PC PFI0 data bus 18	-
25	PCP0F19	PC PFI0 data bus 19	-
26	PCP0F20	PC PFI0 data bus 20	-
27	PCP0F21	PC PFI0 data bus 21	-
28	PCP0F22	PC PFI0 data bus 22	-
29	PCP0F23	PC PFI0 data bus 23	-
30	PCP0F24	PC PFI0 data bus 24	-
31	PCP0F25	PC PFI0 data bus 25	-
32	PCP0F26	PC PFI0 data bus 26	-
33	PCP0F27	PC PFI0 data bus 27	-
34	PCP0F28	PC PFI0 data bus 28	-
35	PCP0F29	PC PFI0 data bus 29	-
36	PCP0F30	PC PFI0 data bus 30	-
37	PCP0F31	PC PFI0 data bus 31	-
38	PCP0F32	PC PFI0 data bus 32	-
39	PCP0F33	PC PFI0 data bus 33	-
40	PCP0F34	PC PFI0 data bus 34	-
41	PCP0F35	PC PFI0 data bus 35	-
42	PCP0F36	PC PFI0 data bus 36	-
43	PCP0F37	PC PFI0 data bus 37	-
44	PCP0F38	PC PFI0 data bus 38	-
45	PCP0F39	PC PFI0 data bus 39	-
46	PCP0F40	PC PFI0 data bus 40	-
47	PCP0F41	PC PFI0 data bus 41	-
48	PCP0F42	PC PFI0 data bus 42	-
49	PCP0F43	PC PFI0 data bus 43	-
50	PCP0F44	PC PFI0 data bus 44	-
51	PCP0F45	PC PFI0 data bus 45	-
52	PCP0F46	PC PFI0 data bus 46	-
53	PCP0F47	PC PFI0 data bus 47	-
54	PCP0F48	PC PFI0 data bus 48	-
55	PCP0F49	PC PFI0 data bus 49	-
56	PCP0F50	PC PFI0 data bus 50	-
57	PCP0F51	PC PFI0 data bus 51	-
58	PCP0F52	PC PFI0 data bus 52	-
59	PCP0F53	PC PFI0 data bus 53	-
60	PCP0F54	PC PFI0 data bus 54	-
61	PCP0F55	PC PFI0 data bus 55	-
62	PCP0F56	PC PFI0 data bus 56	-
63	PCP0F57	PC PFI0 data bus 57	-
64	PCP0F58	PC PFI0 data bus 58	-
65	PCP0F59	PC PFI0 data bus 59	-
66	PCP0F60	PC PFI0 data bus 60	-
67	PCP0F61	PC PFI0 data bus 61	-
68	PCP0F62	PC PFI0 data bus 62	-
69	PCP0F63	PC PFI0 data bus 63	-
70	PCP0F64	PC PFI0 data bus 64	-
71	PCP0F65	PC PFI0 data bus 65	-
72	PCP0F66	PC PFI0 data bus 66	-
73	PCP0F67	PC PFI0 data bus 67	-
74	PCP0F68	PC PFI0 data bus 68	-
75	PCP0F69	PC PFI0 data bus 69	-
76	PCP0F70	PC PFI0 data bus 70	-
77	PCP0F71	PC PFI0 data bus 71	-
78	PCP0F72	PC PFI0 data bus 72	-
79	PCP0F73	PC PFI0 data bus 73	-
80	PCP0F74	PC PFI0 data bus 74	-
81	PCP0F75	PC PFI0 data bus 75	-
82	PCP0F76	PC PFI0 data bus 76	-
83	PCP0F77	PC PFI0 data bus 77	-
84	PCP0F78	PC PFI0 data bus 78	-
85	PCP0F79	PC PFI0 data bus 79	-
86	PCP0F80	PC PFI0 data bus 80	-
87	PCP0F81	PC PFI0 data bus 81	-
88	PCP0F82	PC PFI0 data bus 82	-
89	PCP0F83	PC PFI0 data bus 83	-
90	PCP0F84	PC PFI0 data bus 84	-
91	PCP0F85	PC PFI0 data bus 85	-
92	PCP0F86	PC PFI0 data bus 86	-
93	PCP0F87	PC PFI0 data bus 87	-
94	PCP0F88	PC PFI0 data bus 88	-
95	PCP0F89	PC PFI0 data bus 89	-
96	PCP0F90	PC PFI0 data bus 90	-

PWA-F-MAN (CN6) ↔ PWA-F-FAX (CN101)			
Pin No.	Symbol	Name	Active
1	INTPTX1	FAX CODEC interrupt signal	H
2	EM0EXT1	FAX CODEC DMA request signal	-
3	RESE1TX	Reset signal	-
4	PM1UD0	FAX CODEC input data bus 0	-
5	PM1UD1	FAX CODEC input data bus 1	-
6	PM1UD2	FAX CODEC input data bus 2	-
7	PM1UD3	FAX CODEC input data bus 3	-
8	PM1UD4	FAX CODEC input data bus 4	-
9	PM1UD5	FAX CODEC input data bus 5	-
10	PM1UD6	FAX CODEC input data bus 6	-
11	PM1UD7	FAX CODEC input data bus 7	-
12	PM1UD8	FAX CODEC input data bus 8	-
13	PM1UD9	FAX CODEC input data bus 9	-
14	PM1UD10	FAX CODEC input data bus 10	-
15	PM1UD11	FAX CODEC input data bus 11	-
16	PM1UD12	FAX CODEC input data bus 12	-
17	PM1UD13	FAX CODEC input data bus 13	-
18	PM1UD14	FAX CODEC input data bus 14	-
19	PM1UD15	FAX CODEC input data bus 15	-
20	PM1UD16	FAX CODEC input data bus 16	-
21	PM1UD17	FAX CODEC input data bus 17	-
22	PM1UD18	FAX CODEC input data bus 18	-
23	PM1UD19	FAX CODEC input data bus 19	-
24	PM1UD20	FAX CODEC input data bus 20	-
25	PM1UD21	FAX CODEC input data bus 21	-
26	PM1UD22	FAX CODEC input data bus 22	-
27	PM1UD23	FAX CODEC input data bus 23	-
28	PM1UD24	FAX CODEC input data bus 24	-
29	PM1UD25	FAX CODEC input data bus 25	-
30	PM1UD26	FAX CODEC input data bus 26	-
31	PM1UD27	FAX CODEC input data bus 27	-
32	PM1UD28	FAX CODEC input data bus 28	-
33	PM1UD29	FAX CODEC input data bus 29	-
34	PM1UD30	FAX CODEC input data bus 30	-
35	PM1UD31	FAX CODEC input data bus 31	-
36	PM1UD32	FAX CODEC input data bus 32	-
37	PM1UD33	FAX CODEC input data bus 33	-
38	PM1UD34	FAX CODEC input data bus 34	-
39	PM1UD35	FAX CODEC input data bus 35	-
40	PM1UD36	FAX CODEC input data bus 36	-
41	PM1UD37	FAX CODEC input data bus 37	-
42	PM1UD38	FAX CODEC input data bus 38	-
43	PM1UD39	FAX CODEC input data bus 39	-
44	PM1UD40	FAX CODEC input data bus 40	-
45	PM1UD41	FAX CODEC input data bus 41	-
46	PM1UD42	FAX CODEC input data bus 42	-
47	PM1UD43	FAX CODEC input data bus 43	-
48	PM1UD44	FAX CODEC input data bus 44	-
49	PM1UD45	FAX CODEC input data bus 45	-
50	PM1UD46	FAX CODEC input data bus 46	-
51	PM1UD47	FAX CODEC input data bus 47	-
52	PM1UD48	FAX CODEC input data bus 48	-
53	PM1UD49	FAX CODEC input data bus 49	-
54	PM1UD50	FAX CODEC input data bus 50	-
55	PM1UD51	FAX CODEC input data bus 51	-
56	PM1UD52	FAX CODEC input data bus 52	-
57	PM1UD53	FAX CODEC input data bus 53	-
58	PM1UD54	FAX CODEC input data bus 54	-
59	PM1UD55	FAX CODEC input data bus 55	-
60	PM1UD56	FAX CODEC input data bus 56	-
61	PM1UD57	FAX CODEC input data bus 57	-
62	PM1UD58	FAX CODEC input data bus 58	-
63	PM1UD59	FAX CODEC input data bus 59	-
64	PM1UD60	FAX CODEC input data bus 60	-
65	PM1UD61	FAX CODEC input data bus 61	-
66	PM1UD62	FAX CODEC input data bus 62	-
67	PM1UD63	FAX CODEC input data bus 63	-
68	PM1UD64	FAX CODEC input data bus 64	-
69	PM1UD65	FAX CODEC input data bus 65	-
70	PM1UD66	FAX CODEC input data bus 66	-
71	PM1UD67	FAX CODEC input data bus 67	-
72	PM1UD68	FAX CODEC input data bus 68	-
73	PM1UD69	FAX CODEC input data bus 69	-
74	PM1UD70	FAX CODEC input data bus 70	-
75	PM1UD71	FAX CODEC input data bus 71	-
76	PM1UD72	FAX CODEC input data bus 72	-
77	PM1UD73	FAX CODEC input data bus 73	-
78	PM1UD74	FAX CODEC input data bus 74	-
79	PM1UD75	FAX CODEC input data bus 75	-
80	PM1UD7		

APPENDIX

Appendix A. Specifications

- Copy process Indirect electrophotographic process (dry)
- Type Desktop type (console type when the paper feed pedestal and Large capacity feeder are installed)
- Original table Fixed table (the left rear corner used for standard original placement)
- Acceptable originals Type: sheet, book, and 3-dimensional object.

However, the automatic document feeder (option) only accepts sheets of paper (Multi-sheet: 50 - 105 g/m², or 13 - 29 lb/Single-sheet: 105 - 127 g/m², or 29 - 34 lb.), excluding carbon paper, pasted sheets and stapled sheets.

Max size: A3/LD

- Copy speed

e-STUDIO160 series

(Copies/min.)

Paper supply Paper size	Upper cassette	PFU	PFP		LCF	Bypass feeding (SFB)	
			Upper cassette	Lower cassette (with CM)		No paper size designated	Paper size designated
A4, LT	16	16	16	-	-	9	16
A4-R	12	12	12	-	-	9	12
LT-R	13	13	13	-	-	9	13
B4	11	11	11	-	-	9	11
LG	11	11	11	-	-	9	11
A3, LD	9	9	9	-	-	9	9

e-STUDIO200 series

(Copies/min.)

Paper supply Paper size	Upper cassette	PFU	PFP		LCF	Bypass feeding (SFB)	
			Upper cassette	Lower cassette (with CM)		No paper size designated	Paper size designated
A4, LT	20	20	20	20	20	12	20
A4-R	16	16	16	16	-	12	16
LT-R	16	16	16	16	-	12	16
B4	14	14	14	14	-	12	14
LG	14	14	14	14	-	12	14
A3, LD	12	12	12	12	-	12	12

e-STUDIO250 series

(Copies/min.)

Paper supply Paper size	Upper cassette	PFU	PFP		LCF	Bypass feeding (SFB)	
			Upper cassette	Lower cassette (with CM)		No paper size designated	Paper size designated
A4, LT	24.6	24.6	24.6	24.6	24.6	14	24.6
A4-R	19	19	19	19	-	14	19
LT-R	20	20	20	20	-	14	20
B4	16	16	16	16	-	14	16
LG	16	16	16	16	-	14	16
A3, LD	14	14	14	14	-	14	14

* "-" shows "Cannot be used".

* The copy speeds in the above table are available when originals are manually placed for single-side, multiple copying.

• System copy speed

(Copies/min.)

Copy mode		e-STUDIO160 series	e-STUDIO200 series	e-STUDIO250 series
Single-sided originals	1 set	12	15	15
↓	3 sets	14	17	19
Single-sided copies (Non sort)	5 sets	15	18	21
Single-sided originals	1 set	5	6	6
↓	3 sets	8	10	11
Two-sided copies (Sort)	5 sets	9	12	13
Two-sided originals	1 set	6	7	7
↓	3 sets	10	12	14
Single-sided copies (Sort)	5 sets	12	14	17
Two-sided originals	1 set	5	6	6
↓	3 sets	8	11	11
Two-sided copies (Sort)	5 sets	10	12	13

* Copy speeds include the first copy time.

They are available when the copy modes in the above table are selected and 10 LT-size originals are set in the automatic document feeder.

• Copy paper


	Cassette	Duplexing	Bypass copy	Remarks
Size	A3 - A5-R, FOLIO LD - ST-R, COM		A3 - A5-R, FOLIO LD - ST-R, COM	
Weight	64 - 80 g/m ² 17 - 21 lbs		Continuous copy: 64 - 80 g/m ² , 17 - 21 lbs Single copy: 80 - 163 g/m ² , 21 - 43 lbs	
Special paper	—	—	Recommended OHP film/Thick paper	

- e-STUDIO160/200/250 APPENDIX


- Weight Standard: 50 Kg (110 lb.) (with Process unit/Toner cartridge)
Full system: 92 Kg (203 lb.) (e-STUDIO160 series)/
124 Kg (273 lb.) (e-STUDIO200/250 series)
- Power requirements 115VAC, 50Hz/60Hz
120VAC, 50Hz/60Hz
127VAC, 50Hz/60Hz
220-240VAC, 50Hz/60Hz
- Power consumption 1.4 KW or less
- Dimensions: (W) x (D) x (H) mm

	e-STUDIO160 series	e-STUDIO200/250 series
Standard	530 x 554 x 600 mm	530 x 554 x 600 mm
Standard + Original cover	530 x 554 x 643 mm	530 x 554 x 643 mm
Standard + ADF	530 x 554 x 731 mm	530 x 554 x 731 mm
Standard + RADF	545 x 599 x 772 mm	545 x 599 x 772 mm
Standard + ADU + RADF	607 x 599 x 772 mm	607 x 599 x 772 mm
Standard + Original cover + PFU	530 x 554 x 757 mm	530 x 554 x 757 mm
Standard + Original cover + PFU + PFP	530 x 554 x 1039 mm	530 x 554 x 1039 mm
Standard + Original cover + JSP	604 x 554 x 643 mm	604 x 554 x 643 mm
Standard + Original cover + SFB	801 x 554 x 643 mm	801 x 554 x 643 mm
Standard + Original cover + OCT	604 x 554 x 643 mm	604 x 554 x 643 mm
Standard + Original cover + Stapler	787 x 554 x 676 mm	787 x 554 x 676 mm
Standard + Original cover + Finisher	-----	957 x 554 x 643 mm

e-STUDIO160 series





03-3



03-4

e-STUDIO200/250 series



Appendix B. Accessories

Setup instructions	1pc.
Operator's manual	1pc.
Setup report	1pc. (for NAD and MJD)
Warranty sheet	1pc. (for NAD)
CS card	1pc. (for MJD)
Process unit	1pc.
Toner cartridge	1pc.
Detouchable power cord	1pc.

* Machine version

NAD: North America

MJD: Europe

AUD: Australia

ASD: Asia

SAD: Saudi Arabia

CND: China

Appendix C. Options

Original cover	KA-1600PC, KA-1600PC-N
Paper feed pedestal-1 (PFP)	KD-1009, KD-1009-N
Automatic duplexing unit-1(ADU)	MD-0101, MD-0101-N
Automatic document feeder (ADF)	MR-2012, MR-2012-N
Reverse automatic document feeder-1 (RADF)	MR-3011
Paper feed unit (PFU)	MY-1015, MY-1015-N
Cassette module (CM)	MY-1017, MY-1017-N (for e-STUDIO200/250 series)
Large capacity feeder (LCF)	KD-1010, KD-1010-N (for e-STUDIO200/250 series)
Paper feed controller (PFC)	GH-1030, GH-1030-N
Job separator (JSP)	MJ-5001, MJ-5001-N
Offset tray	MJ-5002, MJ-5002-N
Stack feed bypass (SFB)	MY-1016, MY-1016-N
Printer kit (Printer control)	GA-1031
Memory kit	GC-1050, GC-1050-N
Fax board kit	GD-1061-EU, GD-1061-NA, GD-1061-AU, GD-1060-SA, GD-1061C
Internet fax kit	GD-1070
NIC kit (Network interface card)	GF-1110
Staple with surface	KK-1600
Finisher	MJ-1011 (for e-STUDIO200/250 series)

Appendix D. Replacement Units/Supplies

(1) Replacement units

Fuser unit	FUSER-1600-120, FUSER-1600-240 (for e-STUDIO160 series)
	FUSER-2500-120, FUSER-2500-240 (for e-STUDIO200/250 series)
Transfer charger unit	MAIN-CH-1600

(2) Process unit

Process unit	PU-1610S, PU-1610ES, PU-1610DS, PU-1610DSN, PU-1610CS
--------------	---

(3) Supplies

Toner cartridge	T-1600, T-1600E, T-1600D, T-1600C (for e-STUDIO160 series)
	T-2500, T-2500E, T-2500D, T-2500C (for e-STUDIO200/250 series)

Appendix E. System List




Fig. E-1

01-05-01

Appendix F. Power Supply Unit

1. Outline

The power supply unit provides AC and DC power for each part of this machine. The unit is made up of the following circuits.




Fig. F-1

15-01-02

2. DC Output Circuit

This circuit converts the AC voltage input from the inlet to each DC voltage (+24V, +12V, -12V, +5V, +3.3V) and delivers it to each part of the machine. Turning on the main switch causes the supply of all DC voltages to begin.

Each DC voltage is supplied or cut off when the Power Save mode is activated or the following covers are opened or closed as shown in the table below.

DC Voltage	Voltage Value (V)	In Power Save mode (PWS signal = Low)	Front Cover = Open	Side Cover = Open
24VSW	+24	-	-	-
24VFU2	+24	-	○	○
24VFU1	+24	-	○	○
24V	+24	-	○	○
12V	+12	-	○	○
-12V	-12	-	○	○
5VPS	+5	○	○	○
5V	+5	-	○	○
3.3V	+3.3	-	○	○

○ : Output - : Cut off

Output Protection

An overcurrent and an overvoltage protective circuit are configured for each DC voltage output. If the output is shorted for some reason or an abnormal condition occurs in a circuit, these circuits prevent overcurrent and overvoltage from flowing through the entire circuitry of this machine.

TOSHIBA

TOSHIBA TEC CORPORATION

1-1, KANDA NISHIKI-CHO, CHIYODA-KU, TOKYO, 101-8842 JAPAN